

V-Card^{VC-1}

Owner's Manual

Thank you, and congratulations on your choice of the Roland D-50 for V-Synth/
VariOS: VC-1. The VC-1 brings Roland's famed D-50 back to life in the form of
the V-Synth/VariOS for an all-hardware simulation.

Before using this unit, carefully read the sections entitled: "USING THE UNIT
SAFELY" and "IMPORTANT NOTES" (p. 2; p. 3). These sections provide
important information concerning the proper operation of the unit. Additionally, in
order to feel assured that you have gained a good grasp of every feature
provided by your new unit, Owner's manual should be read in its entirety. The
manual should be saved and kept on hand as a convenient reference.

- * *Microsoft and Windows are registered trademarks of Microsoft Corporation.*
- * *Windows® is known officially as: "Microsoft® Windows® operating system."*
- * *Apple and Macintosh are registered trademark of Apple Computer, Inc.*
- * *MacOS is a trademark of Apple Computer, Inc.*
- * *All product names mentioned in this document are trademarks or registered trademarks of their respective owners.*





Copyright © 2004 ROLAND CORPORATION

All rights reserved. No part of this publication may be reproduced in any form
without the written permission of ROLAND CORPORATION.




USING THE UNIT SAFELY

INSTRUCTIONS FOR THE PREVENTION OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

About ⚠ WARNING and ⚠ CAUTION Notices






| | |
|--|--|
|  WARNING | Used for instructions intended to alert the user to the risk of death or severe injury should the unit be used improperly. |
|  CAUTION | Used for instructions intended to alert the user to the risk of injury or material damage should the unit be used improperly. * Material damage refers to damage or other adverse effects caused with respect to the home and all its furnishings, as well to domestic animals or pets. |

About the Symbols






| | |
|---|--|
|  | The ⚠ symbol alerts the user to important instructions or warnings. The specific meaning of the symbol is determined by the design contained within the triangle. In the case of the symbol at left, it is used for general cautions, warnings, or alerts to danger. |
|  | The 🔞 symbol alerts the user to items that must never be carried out (are forbidden). The specific thing that must not be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the unit must never be disassembled. |
|  | The 🔌 symbol alerts the user to things that must be carried out. The specific thing that must be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the power-cord plug must be unplugged from the outlet. |

ALWAYS OBSERVE THE FOLLOWING


WARNING

- Before using this unit, make sure to read the instructions below, and the Owner's Manual. 
- Do not open or perform any internal modifications on the unit. 
- Do not attempt to repair the unit, or replace parts within it (except when this manual provides specific instructions directing you to do so). Refer all servicing to your retailer, the nearest Roland Service Center, or an authorized Roland distributor, as listed on the "Information" page. 
- Never use or store the unit in places that are:
 - Subject to temperature extremes (e.g., direct sunlight in an enclosed vehicle, near a heating duct, on top of heat-generating equipment); or are 
 - Damp (e.g., baths, washrooms, on wet floors); or are 
 - Humid; or are
 - Exposed to rain; or are
 - Dusty; or are
 - Subject to high levels of vibration.

WARNING

- Do not allow any objects (e.g., flammable material, coins, pins); or liquids of any kind (water, soft drinks, etc.) to penetrate the unit. 

- In households with small children, an adult should provide supervision until the child is capable of following all the rules essential for the safe operation of the unit. 
- Protect the unit from strong impact. (Do not drop it!) 
- DO NOT play a CD-ROM disc on a conventional audio CD player. The resulting sound may be of a level that could cause permanent hearing loss. Damage to speakers or other system components may result. 

CAUTION

- Never climb on top of, nor place heavy objects on the unit. 

IMPORTANT NOTES

In addition to the items listed under “USING THE UNIT SAFELY” on page 2, please read and observe the following:


Placement

- Do not expose the unit to direct sunlight, place it near devices that radiate heat, leave it inside an enclosed vehicle, or otherwise subject it to temperature extremes. Excessive heat can deform or discolor the unit.

Before Using Cards

Using PC Cards

- Carefully insert the PC card all the way in—until it is firmly in place.



- Never touch the terminals of the PC card. Also, avoid getting the terminals dirty.

Handling CD-ROMs

- Avoid touching or scratching the shiny underside (encoded surface) of the disc. Damaged or dirty CD-ROM discs may not be read properly. Keep your discs clean using a commercially available CD cleaner.

Table of Contents

| | |
|--|----------|
| USING THE UNIT SAFELY | 2 |
| IMPORTANT NOTES | 3 |
| Introduction | 6 |
| Using with the V-Synth | 9 |
| Panel Descriptions..... | 10 |
| Try Out the Sounds..... | 15 |
| Turning On the Power | 15 |
| Selecting Patches and Playing Sounds | 16 |
| Viewing Various Information..... | 18 |
| Applying Effects to the Sound..... | 19 |
| Applying an Effect by Touching to the Pad | 19 |
| Applying an Effect by Passing Over the D Beam | 20 |
| Assigning Parameters to the Controllers | 21 |
| How to Make the Patch Factors..... | 26 |
| Saving Patches You've Created | 33 |
| Naming a Patch..... | 33 |
| Saving Patches..... | 34 |
| Reset to Default Factory Settings | 35 |
| Transferring Patches To and From the D-50/550 | 36 |
| Transferring Patches from the D-50 to the VC-1 | 36 |
| Transferring Patches from the VC-1 to the D-50/550 | 40 |
| Copying a Reverb Type | 42 |
| Overview of the VC-1 | 44 |
| Memory Structure | 44 |
| The Basic Concept of a Tone | 45 |
| Structure of Tone Parameters | 48 |
| Creating a Patch..... | 50 |
| How to Make the Patch Settings | 50 |
| Useful Functions for Editing..... | 51 |
| Tone Parameters..... | 57 |
| Common Parameters | 57 |
| Partial Parameters | 63 |
| Settings for the Entire VC-1 | 78 |
| How to Make the System Function Settings..... | 78 |
| Initializing the System Settings | 82 |
| Connecting to Your Computer via USB | 83 |
| Recovering the System from the CD-ROM..... | 83 |
| Exchanging MIDI Messages with Your Computer..... | 88 |



Using with the VariOS 89

Panel Description90

VariOS Menu93

Try Out the Sounds94

Turning On the Power 94

Selecting Patches and Playing Sounds 95

Applying Effects to the Sound98

Applying Effects by Turning Knobs 98

How to Make the Patch Factors..... 99

Transferring Patches To and From the D-50/550.....101

Transferring Patches from the D-50 to the VC-1 101

Transferring Patches from the VC-1 to the D-50/550 104

Overview of the VC-1.....107

Memory Structure107

The Basic Concept of a Tone 108

Structure of Tone Parameters 111

Creating Patches113

Naming a Patch.....113

Saving Patches..... 114

Initializing Patch Settings..... 115

Reset to Default Factory Settings 115

Copying a Patch Bank 116

Settings for the Entire VC-1117

How to Make the System Function Settings..... 117

Saving the System Settings..... 120

Initializing the System Settings (Init)..... 120

Connecting to Your Computer via USB.....121

Recovering the System from the CD-ROM..... 121

Exchanging MIDI Messages with Your Computer..... 124

Appendices 125

Key Mode Alteration126

Sound List130

Preset Patches..... 130

Patch Factors 133

Tone Parameters 134

System Parameters 137

Waveform 138

MIDI Implementation.....140

Specifications.....149

Index.....150

Introduction

Check The Contents of The Package

This package contains the following items. When you open the package, check that no items are missing (☒). If any items are missing, please contact your dealer.

☐ **VC-1**

☐ **VC-1 CD-ROM**

This CD-ROM contains the VC-1 recovery software and PC editor (UniQuest VC-1).

* *Please be sure to read the included license agreement before you open the CD-ROM case.*

☐ **License Agreement**

This license agreement permits you to use specific software whose copyright is owned by Roland Corporation. You must read this before you open the CD-ROM case.

☒ **VC-1 Owner's Manual**

This is the manual you are holding. It describes how to connect the VC-1 and get it set up, guides you through its basic operation, and offers solutions for some of the problems you may run into.



Main Features

The **VC-1** is a PC card containing the V-Synth/VariOS system program. Just insert the **VC-1** in the **PC CARD** slot of the V-Synth/VariOS, turn on the power, and you are ready to go. The program is automatically loaded from the **VC-1**, transforming the V-Synth/VariOS into a D-50!

Perfect Simulation of the D-50's Tones!

The VC-1 comes complete with all 64 of the D-50's preset patches, including the famous preset tones **"Fantasia"** and **"Digital Native Dance."** It also is programmed with the D-50/D-550 sound libraries **PN-D50-01-04** (with 256 patches). Since it naturally handles **MIDI bulk dumps**, you can use the VC-1 to create your own original tunes exactly as you would with your D-50. Of course, this gives you a perfect simulation of the D-50's tones, from the sound generator algorithms to editing of the parameters! It even reproduces the subtle nuances obtained when playing the instrument.



In addition, it also comes with an additional 64 new patches, which use waves (28 types) that are so large that the original D-50 would have been technologically incapable of containing them.)

Editing and Performances That Surpass the Original!


V-Synth: All sound generator parameters are assignable to the V-Synth's full complement of editing controls. Parameters can also be edited with the touch panel, allowing you to almost instantly turn your creative inspirations (no matter how fleeting) into sounds you can use. Plus, the Time-Trip Pad (used instead of a joystick), the D-Beam controller, the C2 assignable control knobs, and other controls use performance parameters capable of outputting Control Change messages. This allows you to express your emotions directly as you play. Whether the fun of creating sounds or pleasure of performing, this far outdoes the original.



VariOS: The C1, C2, and C3 knobs correspond to Tone Balance, Reverb Balance, and Portamento Time, respectively. In addition, you can install the included **UniQuest VC-1** encoder in your computer for complete freedom in editing a wide variety of sound module parameters, giving you sound creation capabilities far exceeding those of the original D-50.

Pro Spec Legacy Synthesizer!

Internal processing upgraded with the latest technology vastly improves the response and dynamic range from the time you press the keys to the moment the sounds are played. The V-Synth or VariOS hardware is used as the means of outputting sounds, which means it's also compatible with digital outputs (optical/coaxial). This gives you a **legacy synthesizer with professional specs** good enough for the latest recording environments.



What is the digital synthesizer: D-50?

The **D-50**, released in 1987, was Roland's first **fully digital synthesizer**. Equipped with an **LA** (Linear Arithmetic Synthesis) format sound generator that combined PCM and subtractive synthesis, it opened the door to countless new sounds for levels of creativity surpassing anything up to that point. The D-50 is a renowned, historically significant synthesizer that Roland, the company that laid the foundation for digital synthesizers, is proud to have created.

The **D-550**, also released in 1987, shrank the D-50's powerful synthesizer engine into a mere two rack spaces.



Now, more than fifteen years after it came on the scene, the D-50 continues to be used by creative artists around the world. There are numerous sound libraries stocked with many original patches. In the course of time, however, keyboards and buttons age and wear out. It looked like the day would come when the D-50's sounds would no longer be heard.

In taking up the challenge of realizing new possibilities for the synthesizer, Roland has created a revolution in technology. At the same time, we want you to continue to using your treasured D-50 with peace of mind. Hence, the **VC-1**, which transforms your V-Synth/VariOS into a D-50, not only sweeps away any worries about your D-50 growing old, but also offers new potential that goes beyond the original instrument.

We hope that you will discover and enjoy the unrealized potential that the D-50 still offers. And if you have never played the D-50, you definitely need to check out its vintage sounds.




| | | | |
|---|-----------|---|-----------|
| Try Out the Sounds..... | 15 | Creating a Patch | 50 |
| Turning On the Power | 15 | How to Make the Patch Settings..... | 50 |
| Selecting Patches and Playing Sounds | 16 | Useful Functions for Editing | 51 |
| Viewing Various Information..... | 18 | Editing a Value..... | 51 |
| Applying Effects to the Sound..... | 19 | Undoing an editing Operation..... | 51 |
| Applying an Effect by Touching to the Pad..... | 19 | Editing with the Panel Controls (Partial Select)..... | 52 |
| Applying an Effect by Passing Over the D Beam | 20 | Silencing the Sound of the Partial | 52 |
| Assigning Parameters to the Controllers | 21 | Copying Tone Settings..... | 53 |
| How to Make the Patch Factors..... | 26 | Copying Parameter Settings..... | 54 |
| Settings Common to All Screens | 26 | Auditioning the Sound Before Editing..... | 55 |
| CONTROL | 28 | Initializing Patch Settings | 56 |
| OUTPUT (Output Mode)..... | 29 | | |
| CHASE | 31 | Tone Parameters | 57 |
| TONE TUNE | 32 | Common Parameters..... | 57 |
| MIDI..... | 32 | Structure..... | 57 |
| Saving Patches You've Created | 33 | P-ENV (Pitch Envelope)..... | 58 |
| Naming a Patch..... | 33 | LFO (Low Frequency Oscillator)..... | 60 |
| Saving Patches..... | 34 | EQ/CHORUS (Equalizer/Chorus)..... | 61 |
| Reset to Default Factory Settings..... | 35 | Partial Parameters..... | 63 |
| Transferring Patches To and From the D-50/550 | 36 | WG Form (WG Waveform) | 64 |
| Transferring Patches from the D-50 to the VC-1 | 36 | WG PITCH..... | 66 |
| Transfer the patch from the memory card to the D-50/550 | 37 | TVF (Time Variant Filter) | 68 |
| Transferring Patches from the D-50/550 to the VC-1 | 38 | TVA (Time Variant Amplifier) | 73 |
| Saving Transferred Patches with the VC-1 | 39 | MOD (Modulation)..... | 76 |
| Transferring Patches from the VC-1 to the D-50/550..... | 40 | Settings for the Entire VC-1 | 78 |
| Copying a Reverb Type | 42 | How to Make the System Function Settings | 78 |
| Overview of the VC-1 | 44 | Initializing the System Settings..... | 82 |
| Memory Structure..... | 44 | Connecting to Your Computer via USB..... | 83 |
| The Basic Concept of a Tone | 45 | Recovering the System from the CD-ROM..... | 83 |
| Structure of Tone Parameters..... | 48 | Selecting the V-Synth's USB Storage Mode | 83 |
| | | Connecting the V-Synth to Your Computer via USB | 84 |
| | | Recovering the System..... | 86 |
| | | Canceling the USB Connection | 86 |
| | | Exchanging MIDI Messages with Your Computer..... | 88 |

Panel Descriptions

When using the V-Synth with the **VC-1**, the actual functions of the V-Synth's buttons and knobs may not correspond to the functions ascribed to these controls on the V-Synth's panel. Here is a description of the names and functions in each section of the V-Synth when it is used with the VC-1. Please read this material together with "Panel Descriptions" in the V-Synth Owner's Manual. Controls whose functions do not match what is shown on the panel are indicated with a **VC-1** mark.

Front Panel



1 VOLUME slider

Adjusts the overall volume that is output from the rear panel MAIN OUT jacks and PHONES jack. (p. 15)

2 INPUT

Not used with the VC-1. **VC-1**

3 D BEAM

You can apply a variety of effects to sounds simply by moving your hand.

* *The Time Trip effect is not applied.* **VC-1**

| Display | Function |
|-------------------|---|
| Indicators (L, R) | If the D Beam controller is on, these will light when you move your hand over the controller. |
| [TIME TRIP] | Switches the D Beam controller on/off. The effect to be controlled can be selected by pressing the relevant button. (p. 20) |
| [TIME] | |
| [PITCH] | |
| [ASSIGNABLE] | |

4 TIME TRIP PAD

By touching the pad surface with your finger you can apply a variety of effects to the sound.

- * *The Time Trip effect is not applied.* **VC-1**

| Display | Function |
|---------------------|--|
| Indicator | This will light when you touch the Time Trip Pad. |
| [TIME TRIP] | This switches the Time Trip Pad on and off. The effect being controlled switches according to the buttons pressed. (p. 19) |
| [ASSIGNABLE] | |
| [HOLD] | Switches hold on/off for the effect controlled by the Time Trip pad. |

5 V-LINK

Not used with the VC-1. **VC-1**

6 ASSIGNABLE CONTROL

You can use them to modify the sound in realtime.

| Display | Function |
|-------------|--|
| [C1] | Adjusts the Aftertouch Sens (p. 79). VC-1 |
| [C2] | These can be assigned a variety of D-50 different functions, allowing you to change the tone in real time. (p. 22) |

7 ARPEGGIO

You can use them to modify the sound in realtime.

- * *The Arpeggiator is not available for use.* **VC-1**


| Display | Function |
|-----------------|--|
| [TEMPO] | Adjusts the Chase time (p. 31) or the Portamento time (p. 28). VC-1 |
| [ON/OFF] | Switches the Chase function on/off. VC-1 |
| [HOLD] | Switches the Portamento function on/off. VC-1 |

8 KEYBOARD

Here you can change the pitch range of the keyboard.

| Display | Function |
|-----------------------|---|
| [TRANPOSE] | Modifies the pitch range of the keyboard in semitone steps (-12 – +12 semitones). Set the desired amount of transposition by holding down [TRANPOSE] and pressing [+OCT] or [-OCT] . |
| [-OCT], [+OCT] | Pressing [+OCT] or [-OCT] transposes the pitch of the keyboard in 1 octave units (-3 – +3 octaves). |

- * *Changes you make the KEYBOARD settings are only temporary—they will be discarded as soon as the power is turned off. If you want you keep any changes you've made, you must save them in the VC-1. ("How to Make the System Function Settings" (p. 78))*



9 PATCH PALETTE

Here you can recall patches. **VC-1**

| Display | Function |
|----------------|---|
| [NUMBER] (1–8) | These buttons let you select patches. VC-1 |
| [BANK] | You can change the Patch Palette bank by holding down this button and pressing [NUMBER] (1–8) |
| [PATCH ASSIGN] | Not used with the VC-1. VC-1 |

10 Display

This displays information regarding the operation you are performing.

- * The explanations in this manual include illustrations that depict what should typically be shown by the display. Note, however, that your unit may incorporate a newer, enhanced version of the system (e.g., includes newer sounds), so what you actually see in the display may not always match what appears in the manual.

11 Dial and buttons

| Display | Function |
|--------------------|---|
| VALUE Dial | This is used to modify values. If you hold down [SHIFT] as you turn the VALUE dial, the value will change in greater increments. |
| [DEC/-], [INC/+] | This is used to modify values. If you keep on holding down one button while pressing the other, the value change accelerates. If you press one of these buttons while holding down [SHIFT], the value will change in bigger increments. (p. 51) |
| [▲], [▼], [◀], [▶] | Moves the cursor location up/down/left/right. (p. 51) |
| [MODE] | Opens the Mode Menu window. |
| [SHIFT] | This button is used in conjunction with other buttons to execute various functions. |
| [EXIT] | Return to the PATCH TOP screen, or close the currently open window. In some screens, this causes the currently executing function to be aborted. |

12 STRUCTURE

Switches the various functions on/off. **VC-1**

13 EFFECTS

Here you can switch the onboard effects (chorus and reverb) on/off. When an effect is on, the indicator for its button will light.

| Display | Function |
|----------|---|
| [MFX] | Switches chorus of the UPPER tone on and off. VC-1 |
| [CHORUS] | Switches chorus of the LOWER tone on and off. VC-1 |
| [REVERB] | Switches reverb on and off. |

14 OSC1, OSC2

These can be assigned a variety of the D-50's different functions, allowing you to change the tone in real time. (p. 23) **VC-1**

15 COSM1, COSM2

These can be assigned a variety of the D-50's different functions, allowing you to change the tone in real time. (p. 23) **VC-1**

15 TVA

These can be assigned a variety of the D-50's different functions, allowing you to change the tone in real time. (p. 23) **VC-1**

17 Pitch Bend/Modulation Lever


This allows you to control pitch bend or apply vibrato.

Rear Panel



1 POWER Switch

Press to turn the power on/off. (p. 15)



2 AC Inlet

Connect the included power cord to this inlet.

3 PC CARD Slot

The **VC-1** can be inserted here.

- * *Carefully insert the PC card all the way in—until it is firmly in place.*
- * *Never insert or pull out while the VC-1 (V-Synth) is turned on.*

4 USB Connector

You can connect it to your personal computer to send or receive MIDI messages. (p. 83)

5 DIGITAL AUDIO INTERFACE Connector

These connectors input/output a digital audio signal (stereo; conforming to IEC60958). The output signal is identical to the signal that is output from the MAIN OUT jacks.

- * **IEC60958** is a digital interface format used for consumer digital audio devices.

6 LCD CONTRAST Knob

Adjusts the display contrast.

7 MIDI Connectors (IN, OUT, THRU)

These connectors can be connected to original D-50 (or other MIDI devices) to receive and transmit MIDI messages. (p. 83)

8 CTRL 1/2 PEDAL Jacks

You can connect optional expression pedals (EV-5, BOSS FS-5U, etc.) to these jacks.

| Display | Function |
|---------------------|---|
| CTRL 1 PEDAL | Adjusts the volume. |
| CTRL 2 PEDAL | By assigning a desired function to a pedal, you can use it to select or modify sound. (p. 23) |

9 HOLD PEDAL Jack

An optional pedal switch (DP series, BOSS FS-5U, etc.) can be connected to this jack for use as a hold pedal.

10 INPUT Jacks (L, R)

Not used with the VC-1. **VC-1**

11 DIRECT OUT Jacks (L, R)

Not used with the VC-1. **VC-1**

12 MAIN OUT Jacks (L (MONO), R)

These jacks output the audio signal to the connected mixer/amplifier system in stereo. For mono output, use the L jack. (p. 15)

13 PHONES Jack




This is the jack for connecting headphones (sold separately). (p. 15)

Try Out the Sounds

Turning On the Power

To prevent malfunction and/or damage to speakers or other devices, always turn down the volume, and turn off the power on all devices before making any connections.


1. Before hooking anything up, make sure that the power on all of your gear is turned OFF.
2. Connect the V-Synth to your amp/speaker system.
3. After correctly inserting the VC-1 into the PC card slot in the V-Synth's rear panel, switch ON the POWER switch.
 - * Carefully insert the PC card all the way in—until it is firmly in place.
 - * This unit is equipped with a protection circuit. A brief interval (a few seconds) after power up is required before the unit will operate normally.
 - * Always make sure to have the volume level turned down before switching on power. Even with the volume all the way down, you may still hear some sound when the power is switched on, but this is normal, and does not indicate a malfunction.
 - * Never insert or pull out while the VC-1 (V-Synth) is turned on.
4. Turn on the power for any connected amplifiers or speakers.
5. Wait for the VC-1 to start up. When it has started up normally, a screen like the following will appear. The display shows the selected Patch.



Selecting Patches and Playing Sounds

The VC-1 comes with a wide range of onboard sounds, including single tones called **patches**.

A Patch is represented by a **Patch Bank** (Pre1–6, Int1–8), a **Bank** (1–8) and a **Number** (1–8).




| Patch Banks | Included patches | Overwrite | Remarks |
|-------------|------------------|-----------|---------------------------------|
| Pre1 | D-50 | No | Original D-50 preset patches |
| Pre2 | VC-1 | No | Newly added patches VC-1 |
| Pre3 | PN-D50-01 | No | D-50/D-550 sound library |
| Pre4 | PN-D50-02 | No | D-50/D-550 sound library |
| Pre5 | PN-D50-03 | No | D-50/D-550 sound library |
| Pre6 | PN-D50-04 | No | D-50/D-550 sound library |
| Int1 | same as Pre1 | Yes | - |
| Int2 | same as Pre2 | Yes | - |
| Int3 | same as Pre3 | Yes | - |
| Int4 | same as Pre4 | Yes | - |
| Int5 | same as Pre5 | Yes | - |
| Int6 | same as Pre6 | Yes | - |
| Int7 | (blank) | Yes | - |
| Int8 | (blank) | Yes | - |

There are three ways of patch selection.

- Selecting Patches with the VALUE dial.
- Selecting Patches from the list.
- Selecting Patches with Patch Palette.

Selecting Patches with the VALUE dial

1. Make sure the **PATCH TOP** screen is displayed. If the **PATCH TOP** screen—shown right—is not displayed, press **[EXIT]** once or twice until the **PATCH TOP** screen appears.
2. Play the keyboard to hear what the selected patch sounds like. To change to a different patch, touch the **Patch number** to highlight it, and then turn the **VALUE dial** or press **[INC/+]**, **[DEC/-]**. At this time you can switch more rapidly by holding down **[SHIFT]** while you perform these operations.



Selecting Patches from the List

You can easily find the desired patch by selecting it from the patch list.


1. Make sure the **PATCH TOP** screen is displayed. If the **PATCH TOP** screen is not displayed, press **[EXIT]** once or twice until the **PATCH TOP** screen appears.
2. Touch **<List>** in the upper left area of the display. The **PATCH List** window appears.
3. Select a patch from the list. Either turn the **VALUE dial** or use **[INC/+]**, **[DEC/-]** to select a patch. You can also select a patch by touching it on the display.
4. To view higher-numbered patches, touch **<31-48>**—**<71-88>**, located at bottom of the screen. To view other Patch banks, touch **<Pre1>**—**<Pre6>**, **<Int1>**—**<Int8>**, located at either side of the screen.
5. Touch **<OK>**. The patch is selected and the **PATCH LIST** window closes.



Selecting Patches with Patch Palette

You can select patches of currently selected Patch Bank instantly by simply pressing **NUMBER [1]–[8]**.

1. Make sure the **PATCH TOP** screen is displayed.
2. Press **NUMBER [1]–[8]** to select a patch. To switch between patch palette banks, hold down **[BANK]** and press **NUMBER [1]–[8]**.



Viewing Various Information

1. In the upper right of the screen, touch < ▼ >. A pulldown menu appears.
2. In the pulldown menu, touch <INFO>. The **Information** window appears.



3. This window shows the following information.
Ver.: The VC-1's program version
4. When you have finished viewing the information, press [EXIT] to close the window.

Enabling or Disabling the Beep Tone

You can specify whether or not a **beep tone** will be heard when you touch a valid point on the touch screen. At the factory setting, the beep tone will be sounded.


1. In the upper right of the screen, touch < ▼ >. A pulldown menu appears.
2. In the pulldown menu, touch <Beep> to add a check mark (✓).
With this setting, the beep tone will be heard. If you perform the same procedure once again, the check mark will be cleared and the beep tone will no longer be heard.



Applying Effects to the Sound

The performance controlling functions (we call them **factors** in this manual) in each Patch can be edited by taking the following procedure.


A patch consists of several **Factors** as show below.



Applying an Effect by Touching to the Pad

You can apply a variety of effects by touching your fingertip to the **Time Trip pad** located at the left side of the V-Synth's front panel. The Time Trip Pad settings are saved with each patch. This means that you can create patches that contain Time Trip Pad settings you like.

1. Access the **PATCH TOP** Screen.
2. Choose the function that you want to control from the Time Trip pad, and press the **TIME TRIP PAD** button for that function.



| Button | Functions |
|--------------|--|
| [TIME TRIP] | This provides the same effect as the D-50's joystick (tone balance or partial balance). |
| [ASSIGNABLE] | Apply the effect that is specified by each patch. (CTRL Setup; p. 26) |
| [HOLD] | you can cause the effect to be held even after you take your finger off the Time Trip pad. |

3. While you play the keyboard to produce sound, place your fingertip on the Time Trip pad and move your finger in the following way.


If [TIME TRIP] is on

Using the **Time Trip Pad**, the following two volume balance controls can be adjusted at the same time.

- Volume balance of the two Partial sounds of either Tone ; Upper or Lower.
- Volume balance of the Upper and the Lower tones.

Applying Effects to the Sound


The tone for which the partial balance is to be controlled is selected using the **Tone Select button**. When you touch the **Time Trip pad**, the volume balance changes as shown below. Changing the **partial balance** creates huge changes in the tone, providing very distinctive effects.



Tone Select button (On:pressed)

Applying an Effect by Passing Over the D Beam

The **D Beam controller** can be used simply by waving your hand over it. It can be used to apply various effects, depending on the function that is assigned to it. You can also create effects in which the sound changes instantaneously, in a way that would not be possible by operating a knob or the bender lever. The D Beam controller settings are saved with each patch. This means that you can create patches that contain D Beam settings you like.



1. Access the **PATCH TOP** Screen
2. Choose the function that you want to control from the D Beam controller, and press the **D BEAM** button for that function to turn on the D Beam controller.

| Buttons | Functions |
|--------------|---|
| [TIME TRIP] | This provides the same effect as that when, after the key is played, it is then pressed with even greater force. (Aftertouch) |
| [TIME] | This provides the same effect as that achieved by tilting the modulation level away from you. (Modulation) |
| [PITCH] | This provides the same effect as that achieved by tilting the pitch bend level to the left and right. (Pitch Bend) |
| [ASSIGNABLE] | Apply the effect that is specified by each patch. ("How to Make the Patch Factors" (p. 26)) |


3. While playing the keyboard to produce sound, place your hand over the D Beam, and slowly move it up and down.
4. To turn off the D Beam controller, once again press the button that you pressed in step 2, so its indicator goes out.

Assigning Parameters to the Controllers






You can assign a variety of patch factors (p. 133), tone parameters (p. 134), and other settings to the V-Synth's complement of controller sections, such as the Time Trip pad, the D Beam Controller, and the OSC1/OSC2 sections. This is referred to as the **Control Setup**. With intuitive editing of sound sources with the knobs and sliders and greater performance expression with the **Time Trip Pad**, you can use the D-50 in ways that go way beyond the original instrument.

| Controllers | Parameters |
|----------------------------------|--|
| TIME TRIP PAD, D BEAM, C2 Knob | MIDI Control Change Message |
| OSC1, OSC2, COSM1, COSM2, TVA | Patch Factor (p. 133) Tone Parameters (p. 134) Partial Parameters (p. 135) |

1. Access the **PATCH TOP** Screen.
2. Touch **<CTRL SET>** in the lower left of the screen. The **CTRL SETUP** window appears.
3. Touch the Time Trip pad, D-Beam Controller, or other controller to which you want to assign the parameter. The display of that controller section expands in the screen. The screen features at this time function as follows.



4. When editing a parameter that requires you to specify a value, move the cursor to the value box of that parameter. Then modify the value by either turning the **VALUE** dial or pressing **[INC/+]** or **[DEC/-]**. Parameters marked by **CTRL** can be controlled by specific CTRL Setup. For details on each parameter, refer to the corresponding reference page. The on-screen keys have the following functions.


| Keys | Functions |
|---|---|
|  ,  | Switches the set of controllers to be enlarged in the display. |
|  | Displays the parameters to be assigned as a list. |
|  | Returns to the CTRL SET screen. |
|  | Restores the assigned parameters to their original factory condition. |



5. When you have finished CTRL Setup, touch **<OK>** to close the **CTRL Setup** window.

TIME TRIP PAD

- ASSIGNABLE X
- table 1 (p. 22)
- ASSIGNABLE Y
- table 1 (p. 22)



D BEAM

- ASSIGNABLE L
- table 1 (p. 22)
- ASSIGNABLE R
- table 1 (p. 22)
- Sens L
- 0-20
- Sens R
- 0-20



C2

- C2
- table 1 (p. 22)



table 1

You can control the following parameters.

| Display | Parameters |
|--------------------------------------|-------------------|
| Assignable Parameter - MIDI (p. 140) | |
| M-Mod | MIDI Modulation |
| M-Vol | MIDI Volume |
| M-Hold | MIDI HOLD |
| M-After | MIDI Aftertouch |
| M-Bend+ | MIDI Pitch Bend + |
| M-Bend- | MIDI Pitch Bend - |

PEDAL2

PEDAL2 → Off, ToneBal, M-After, M-Mod

| Display | Functions |
|----------------------------------|---|
| Off | The VC-1 is NOT Controlled. |
| ToneBal (Tone Balance) | Controls the volume balance of the Upper and the Lower Tones. |
| M-After (Aftertouch) | Controls the Aftertouch effect. |
| M-Mod (Modulation) | Controls the vibrato effect. |



OSC1, OSC2

| | |
|---------------|-------------------|
| OSC1 PITCH | → table 2 (p. 25) |
| OSC1 TIME | → table 2 (p. 25) |
| OSC1 FORMANT | → table 2 (p. 25) |
| OSC1 LFO DP1 | → table 2 (p. 25) |
| OSC1 LFO DP2 | → table 2 (p. 25) |
| OSC1 LFO DP3 | → table 2 (p. 25) |
| OSC1 LFO RATE | → table 2 (p. 25) |
| OSC1 LEVEL | → table 2 (p. 25) |
| OSC2 PITCH | → table 2 (p. 25) |
| OSC2 TIME | → table 2 (p. 25) |
| OSC2 FORMANT | → table 2 (p. 25) |
| OSC2 LFO DP1 | → table 2 (p. 25) |
| OSC2 LFO DP2 | → table 2 (p. 25) |
| OSC2 LFO DP3 | → table 2 (p. 25) |
| OSC2 LFO RATE | → table 2 (p. 25) |
| OSC2 LEVEL | → table 2 (p. 25) |




COSM1, COSM2

| | |
|--------------|-------------------|
| COSM1 WIDTH | → table 2 (p. 25) |
| COSM1 DETUNE | → table 2 (p. 25) |
| COSM2 WIDTH | → table 2 (p. 25) |
| COSM2 DETUNE | → table 2 (p. 25) |
| TVA Attack | → table 2 (p. 25) |
| TVA Decay | → table 2 (p. 25) |
| TVA Sustain | → table 2 (p. 25) |
| TVA Release | → table 2 (p. 25) |



LIST (OSC1, OSC2, COSM1, COSM2 and TVA)



- Tone Parameters; The Tones (UPPER or LOWER) to be applied are specified with the **Tone Select** button.
- Partial Parameters; The Partials (L1, L2, L3 or L4) to be applied are specified with the **Partial Select** button.



Specify the Tones or the Partials to be applied

The partials to which the tone parameters assigned to the different knobs and sliders (OSC1, OSC2, COSM1, COSM2 and TVA) are applied are specified with the **Tone Select** button or the **Partial Select** button.

- Tone Parameters; The Tones (UPPER or LOWER) to be applied are specified with the **Tone Select** button.
- Partial Parameters; The Partials (L1, L2, L3 or L4) to be applied are specified with the **Partial Select** button.



* The Tone Select or the Partial Select setting will be written by the Patch Write Procedure.

table 2

You can control the following parameters.

| Display | Parameters |
|------------------------------|-----------------------|
| PATCH TOP (p. 26) | |
| ToneBal | Tone Balance |
| PATCH EDIT CONTRL (p. 28) | |
| BendRang | Bender Range |
| AftrPB | Aftertouch Bend Range |
| PortTime | Portamento Time |
| PortMode | Portamento Mode |
| PATCH EDIT OUTPUT (p. 29) | |
| Rev Bal | Reverb Balance |
| TotalVol | Total Volume |
| PATCH EDIT CHASE (p. 31) | |
| ChasLevl | Chase Level |
| ChasTime | Chase Time |
| PATCH EDIT TONE TUNE (p. 32) | |
| LowerKey | Lower Tone Key Shift |
| UpperKey | Upper Tone Key Shift |
| LowerTun | Lower Tone Fine Tune |
| UpperTun | Upper Tone Fine Tune |
| TONE COMMON STRUCT (p. 57) | |
| PartBal | Partial Balance |
| TONE COMMON P-ENV (p. 58) | |
| PEnvVelo | P-ENV Velocity Range |
| PEnvTKF | P-ENV Time Keyfollow |
| PEnvT1 | P-ENV Time 1 |
| PEnvT2 | P-ENV Time 2 |
| PEnvT3 | P-ENV Time 3 |
| PEnvT4 | P-ENV Time 4 |
| PEnvL0 | P-ENV Level 0 |
| PEnvL1 | P-ENV Level 1 |
| PEnvL2 | P-ENV Level 2 |
| PEnvSusL | P-ENV Sustain Level |
| PEnvEndL | P-ENV End Level |
| PModLFOD | P-Mod LFO Depth |
| PModLevr | P-Mod Lever |
| PModAftr | P-Mod Aftertouch |
| TONE COMMON LFO (p. 60) | |
| LFO1Wave | LFO-1 Waveform |
| LFO1Rate | LFO-1 Rate |
| LFO1Dely | LFO-1 Delay Time |
| LFO1Sync | LFO-1 Sync |
| LFO2Wave | LFO-2 Waveform |
| LFO2Rate | LFO-2 Rate |
| LFO2Dely | LFO-2 Delay Time |
| LFO2Sync | LFO-2 Sync |
| LFO3Wave | LFO-3 Waveform |
| LFO3Rate | LFO-3 Rate |

| Display | Parameters |
|-------------------------------|-------------------------|
| LFO3Dely | LFO-3 Delay Time |
| LFO3Sync | LFO-3 Sync |
| TONE COMMON EQ/CHORUS (p. 61) | |
| EQ Lg | Low EQ Gain |
| EQ Hg | High EQ Gain |
| ChorRate | Chorus Rate |
| ChorDpth | Chorus Depth |
| ChorBal | Chorus Balance |
| TONE PARTIAL FORM (p. 64) | |
| Waveform | WG Waveform |
| PCM No# | WG PCM Wave No. |
| PW | WG Pulse Width |
| PW Velo | WG PW Velocity Range |
| PW Aftr | WG PW Aftertouch Range |
| PW LFO | WG PW LFO Select |
| PW LFOD | WG PW LFO Depth |
| TONE PARTIAL PITCH (p. 66) | |
| PichCors | WG Pitch Coarse |
| PichFine | WG Pitch Fine |
| PichKF | WG Pitch Keyfollow |
| PichLFO | WG Mod LFO Mode |
| PichENV | WG Mod P-ENV Mode |
| PichBend | WG Mod Bend Mode |
| TONE PARTIAL TVF (p. 68) | |
| TVF Freq | TVF Cutoff Frequency |
| TVF Reso | TVF Resonance |
| TVF KF | TVF Keyfollow |
| TVF BP | TVF Bias Point/Dir |
| TVF Blvl | TVF Bias Level |
| TVFDpth | TVF ENV Depth |
| TVFVelo | TVF ENV Velocity Range |
| TVF DKF | TVF ENV Depth Keyfollow |
| TVF TKF | TVF ENV Time Keyfollow |
| TVF T1 | TVF ENV Time 1 |
| TVF T2 | TVF ENV Time 2 |
| TVF T3 | TVF ENV Time 3 |
| TVF T4 | TVF ENV Time 4 |
| TVF T5 | TVF ENV Time 5 |
| TVF L1 | TVF ENV Level 1 |
| TVF L2 | TVF ENV Level 2 |
| TVF L3 | TVF ENV Level 3 |
| TVF SusL | TVF ENV Sustain Level |
| TVF EndL | TVF ENV End Level |

| Display | Parameters |
|--------------------------|--------------------------|
| TONE PARTIAL TVA (p. 73) | |
| TVA Levl | TVA Level |
| TVA Velo | TVA Velocity Range |
| TVA BP | TVA Bias Point/Dir |
| TVA Blvl | TVA Bias Level |
| TVA Velo | TVA ENV Velocity Folw |
| TVA TKF | TVA ENV Time Keyfollow |
| TVA T1 | TVA ENV Time 1 |
| TVA T2 | TVA ENV Time 2 |
| TVA T3 | TVA ENV Time 3 |
| TVA T4 | TVA ENV Time 4 |
| TVA T5 | TVA ENV Time 5 |
| TVA L1 | TVA ENV Level 1 |
| TVA L2 | TVA ENV Level 2 |
| TVA L3 | TVA ENV Level 3 |
| TVA SusL | TVA ENV Sustain Level |
| TVA EndL | TVA ENV End Level |
| TONE PARTIAL MOD (p. 76) | |
| TVF LFO | TVF Mod LFO Select |
| TVF LFOD | TVF Mod LFO Depth |
| TVF Aftr | TVF Mod Aftertouch Range |
| TVA LFO | TVA Mod LFO Select |
| TVA LFOD | TVA Mod LFO Depth |
| TVA Aftr | TVA Mod Aftertouch Range |

How to Make the Patch Factors

The Display shows several Factors at a time. If necessary, Scroll up or down the Display to find the Factor to be edited. (Patch Parameters; p. 26)

1. Access the **PATCH TOP** Screen.
2. Touch <**PATCH EDIT**> at the bottom of the screen.
3. Touch one of the tabs in the left of the screen to select the desired editing screen.
 <**CONTRL**>: Control Edit, Portamento Edit (p. 28)
 <**OUTPUT**>: Output Mode (p. 29)
 <**CHASE**>: Chase Edit (p. 31)
 <**TONE TUNE**>: Tone Tune (p. 32)
 <**MIDI**>: MIDI function (p. 32)
4. When editing a parameter that requires you to specify a value, move the cursor to the value box of that parameter. Then modify the value by either turning the **VALUE dial** or pressing [**INC/+**] or [**DEC/-**].
5. Repeat steps 3–4 to set patch factors.
6. If you wish to save the changes you've made, perform the Save operation (p. 34). If you do not wish to save changes, press [**EXIT**] to return to the **PATCH TOP** screen. If you return to the **PATCH TOP** screen without saving, the display will indicate "**EDITED**," reminding you that the patch settings have been modified.
 * If you turn off the power or select a different patch while the display indicates "**EDITED**," your edited patch will be lost.



Settings Common to All Screens

UPPER/LOWER (Tone Select Button)

You can select the tone to be controlled, upper tone, lower tone or both tone, with the Time Trip Pad.

KEY MODE

Key Mode refers to the Upper and Lower Tones are played on the keyboard.

Value: WHOLE, DUAL, SPLIT, SEP, WHOL-S, DUAL-S, SPL-US, SPL-LS, SEP-S




| Display | Description |
|-------------------------------------|---|
| WHOLE | Upper Tone can be played in 16 voice polyphony |
| DUAL | Both Upper and Lower Tones are played by each key in 8 voices polyphony. |
| SPLIT | The Split mode divides the keyboard into upper and lower sections, where two different Tones can be played in 8 voices polyphony. That is, the VC-1 works like two 8 voice synthesizers. The Split Point (where the keyboard is divided into two sections) is shown next to the Key Mode indication. |
| SEP (Separate) | This mode is effective when an external MIDI device is controlling the VC-1. (“ MIDI Implementation ” (p. 140)) |
| WHOL-S (Whole Solo) | The Upper Tone is monophonic. |
| DUAL-S (Dual Solo) | Both Upper and Lower Tones are monophonic. |
| SPL-US (Split Upper Solo) | The Upper Tone is monophonic, and the Lower Tone is 8 voices polyphonic. |
| SPL-LS (Split Lower Solo) | The Lower Tone is monophonic, and the Upper Tone is 8 voices polyphonic. |
| SEP-S (Separate Solo) | This mode is effective when an external a MIDI device is controlling the VC-1. (“ MIDI Implementation ” (p. 140)) |

SPLIT

The Split Point can be changed as follows.

Value: C2–C7



BALANCE (Tone Balance) **CTRL**

The volume balance of the Upper and the Lower Tone can be change.

Value: 0–100

CHASE (Chase Button)

Switches the Chase function on and off. Touch the button once to switch the function on; touch it again to switch the function off again.

Value: OFF, ON

PORTAMENTO (Portamento Button)

Switches the Portamento function on and off. Portamento is a slide from one pitch to another, and is often used for violin performance. Touch the button once to switch the function on; touch it again to switch the function off again.

Value: OFF, ON

CONTROL

Patch Controls determine how the Control Functions actually affect the Upper and the Lower Tones.

Bend (Bender Range) **CTRL**

This sets the variable range of the pitch change caused by moving the Bender lever right and left. The variable range set here may result differently depending on the setting of the Tone Parameter Bender Mode (p. 67).

Value: 0–12

AfterPB (Aftertouch, Pitch Bender) **CTRL**

This sets the sensitivity of the aftertouch effect on pitch. Higher values mean higher sensitivity. A Minus setting decreases the pitch, and a plus setting increases it.

Value: -12+12

Hold (Hold Mode)

This selects the Tone that on the Pedal Hold effect. When the **Key mode** is **Whole**, Pedal Hold always works whichever of the above three modes may be selected.

Value: U, L, UL

Time (Portamento Time) **CTRL**

This sets the portamento time from one note to another. Higher values make the time longer.

Value: 0–100

Mode (Portamento Mode) **CTRL**

This selects the Tone that should take on the Portamento effect. When the **Key Mode** is **Whole**, Portamento always works whichever of the above three modes may be selected.

Value: U, L, UL

* Even when Portamento is set to ON, the Portamento ON/OFF message sent from an external device can change the settings of Portamento.




| Display | Function |
|-----------|--------------------------|
| U | Works on the Upper Tone. |
| L | Works on the Lower Tone. |
| UL | Works on the both Tones. |

| Display | Function |
|-----------|--------------------------|
| U | Works on the Upper Tone. |
| L | Works on the Lower Tone. |
| UL | Works on the both Tones. |

OUTPUT (Output Mode)

The Output Mode determines how the Tones take on the **reverb** effect, and how the Tones appear at the outputs.

A sound reverberated in an acoustic environment consists of three parts. First, you hear the direct sound as it travels from the source outward. Next the early reflection resounds once, or several time, from the walls, ceiling ,and floor. Finally, you hear the reverberated sound as it reflects many times in the environment.



Mode (Output Mode)

Selects one of the following four output modes.

Value: 1–4

| Display | Function |
|---------|---|
| | Stereo reverb works on the mixed sound of Upper and Lower Tones, and id sent out in stereo. |
| | The Mixture of Upper and Lower takes on stereo reverb, and the direct sound is sent out separately for Upper and Lower. |
| | Only the Upper Tone takes on reverb. Upper and lower Tones are sent out separately. |
| | Only the Lower Tone takes on reverb, Upper and Lower Tones are sent out separately. |

RevType (Reverb Type)

Selects one of the 32-reverb types.

Value: 1–32

| Display | Description |
|---------|--------------------------|
| 1 | Small Hall |
| 2 | Medium Hall |
| 3 | Large Hall |
| 4 | Chapel |
| 5 | Box |
| 6 | Small Metal Room |
| 7 | Small Room |
| 8 | Medium Room |
| 9 | Medium Large Room |
| 10 | Large Room |
| 11 | Single Delay (102 ms) |
| 12 | Cross Delay (180 ms) |
| 13 | Cross Delay (224 ms) |
| 14 | Cross Delay (148–296 ms) |
| 15 | Short Gate (200 ms) |
| 16 | Long Gate (480 ms) |

| Display | Description |
|---------|--------------------------|
| 17 | Bright Hall |
| 18 | Large Cave |
| 19 | Steel Pan |
| 20 | Delay (248 ms) |
| 21 | Delay (338 ms) |
| 22 | Cross Delay (157 ms) |
| 23 | Cross Delay (252 ms) |
| 24 | Cross Delay (274–137 ms) |
| 25 | Gate Reverb |
| 26 | Reverse Gate (360 ms) |
| 27 | Reverse Gate (480 ms) |
| 28 | Slap Back |
| 29 | Slap Back |
| 30 | Slap Back |
| 31 | Twisted Space |
| 32 | Space |

* The reverb types **17–32** in individual banks can be used only with the patches (64 patches) contained in that bank. Reverb types from a bank other than the internal banks (any from 1 through 32) can be copied to a reverb type in the internal banks (any from 17 through 32).

RevbAl (Reverb Balance) CTRL

Sets the volume of the reverb and direct sounds.

Value: 0–100

| Display | Function |
|------------|---|
| 100 | The volume of the reverb sound = maximum, the volume of the direct sound = 0. |
| 0 | The volume of the reverb sound = 0, the volume of the direct sound = maximum. |

Vol (Total Volume) CTRL

Sets the volume of both tones, and therefore adjusts the volume difference between Patches.

Value: 0–100

CHASE

The Chase Play function makes it possible to output the Lower Tone slightly later than the Upper Tone, which is actually played on the keyboard. This function, however, is only available in **Dual** or **Whole** Key Mode.

Mode (Chase Mode)

Sets how tones sound. Depending on the **Chase Level** and **Velocity**, the number of repeats of the delayed sound differ.

Value: UL, ULL, ULU



- When the Key Mode is Dual

| Display | | Function |
|---------|--|--|
| UL | | The Upper Tone then the Lower Tone is played. |
| ULL | | The Upper, then the Lower Tone is repeated. |
| ULU | | The Upper, the Lower and the Upper Tone alternate. |

- When the Key Mode is Whole

| Display | | Function |
|---------|--|---------------------------------|
| UL | | The Upper Tone is played twice. |
| ULL | | Upper Tone is repeated. |
| ULU | | Upper Tone is repeated. |

Level (Chase Level) **CTRL**

Sets the volume of the chase sound.

Value: 0–100

Time (Chase Time) **CTRL**

Adjusts the sounding time. Higher value is longer time.

Value: 0–100

TONE TUNE

The relative pitch of the Upper and the Lower Tones can be separately set. By setting slightly different pitches, a detune effect can be obtained. Also, by lowering the pitch of the Upper Tone, and raising the pitch of the Lower Tone, the pitches of the Two Tones can become exactly the same.

LKey (Key Shift of the Lower Tone) **CTRL**

Allows you to shift the pitch of the Lower Tone in semi-tone steps.

Value: -24→+24 (+/- 2 octave)

UKey (Key Shift of the Upper Tone) **CTRL**

Allows you to shift the pitch of the Upper Tone in semi-tone steps.

Value: -24→+24 (+/- 2 octave)

LTune (Fine Tuning of the Lower Tone) **CTRL**

Allows you to Tune the pitch of the Lower Tone.

Value: -50→+50 (approx. +/- 2 cents)

UTune (Fine Tuning of the Upper Tone) **CTRL**

Allows you to Tune the pitch of the Upper Tone.

Value: -50→+50 (approx. +/- 2 cents)



MIDI

You can change the setting of the MIDI Functions included Patch Factor as follows.

TxCH (Transmit Channel)

The transmit channel of each Patch can be set to a deferent number from the basic channel. At B, the channel number is the same as the Basic Channel.

Value: B, 1–16

TxPC (Transmit Program Change Number)

A Program Change number to be transmitted can be set for each patch individually. At OFF, the Program Change number preprogrammed in each Patch is transmitted.

Value: OFF, 1–100

TxBS (Transmit Bank Select Switch) **VC-1**

A Bank Select number MSB to be transmitted can be set for each patch individually (LSB = 0). At OFF, the Bank Select number preprogrammed in each Patch is transmitted.

Value: OFF, 0–99

SepCH (Receive Channel in Separate Mode)

A receive MIDI Channel in separate mode can be set for each Patch individually. At OFF, the receive channel set in MIDI Functions commonly set for System Function is used. (p. 81)

Value: OFF, 1–16



Saving Patches You've Created








When you edit the settings of a patch, the **PATCH TOP** screen displays **<EDITED>** to remind you that the patch's settings have been modified. If **<EDITED>** is displayed, you will lose your edited patch settings if you switch to another patch or turn off the power. If you want to keep a patch whose settings you have edited, assign a name to the patch and then perform the **Save operation**.

Naming a Patch

Before you save the patch, here's how to give it a new name. Editing Patch or Tone names is called **Naming**.

- A Patch name can have up to 18 letters.
 - A Tone name can have up to 10 letters.
1. Make sure that the patch that you want to name is selected.
 2. Touch **<▼>** in the upper right of the screen. A pulldown menu appears.
 3. In the pulldown menu, touch **<PATCH NAME>** (or **<TONE NAME>**). The window for naming appears.
 4. Touch the on-screen alphabetic or numeric keys to enter the new name in the text box. The on-screen keys have the following functions.



| Keys | Functions |
|---|--|
|  ,  | Move the cursor in the text box to the desired input location. |
|  | Turn this on when you want to input uppercase letters or symbols. |
|  | Turn this on when you want to insert a character at the cursor location. |
|  | Erases all characters in the text box. |
|  | Deletes the character at the cursor location. |
|  | Deletes the character that precedes the cursor location. |



* You can also move the input location cursor by pressing the **[◀]** or **[▶]** cursor buttons. Pressing **[▲]** will change the character at the cursor location to uppercase, and pressing **[▼]** will change it to lowercase.

5. When you have finished inputting, touch **<OK>** to finalize the patch name.

Saving Patches

Changes you make to sound settings are temporary, and will be lost if you turn off the power or select another sound. If you keep the modified sound, you must save it in the VC-1 (PATCH WRITE).

When you perform the save procedure, the data that previously occupied the save destination will be lost. However, the factory setting data can be recovered by performing the **Factory Reset**. (p. 35)

* *Never insert or remove the VC-1 while the V-Synth is turned on. Patches cannot be saved to PC cards other than the VC-1.*


1. Make sure that the patch you wish to save is selected.
2. Touch <▼> in the upper right of the screen. A pulldown menu appears.
3. In the pulldown menu, touch <PATCH WRITE>. The **PATCH WRITE** window appears.
4. Turn the **VALUE dial** to specify the save-destination patch.
 - When you touch <ReName>, the **PATCH NAME** window will appear, allowing you to rename the patch.
 - By touching <Compare> you can check the save-destination patch. This can help prevent important patches from being accidentally overwritten and lost.



5. Touch <Compare> to turn it on. Now you can play the patch that is in the currently selected save destination. Play the keyboard to sound the save destination patch, then check whether you really want to overwrite it.

* *The patch auditioned using the Compare function may sound slightly different than when it is played normally.*

6. Touch <Execute> to execute the Save operation.



Reset to Default Factory Settings

This restores all data in the VC-1 to the factory-set condition (Factory Reset).

If there is important data you've created that's stored in the VC-1, all such data is discarded when a Factory Reset is performed. If you want to keep the existing data, save it as describe below.

- Transmit it to an original D-50 (or an external MIDI device), and save it (p. 40).
 - Transmit it to a PC using V-Synth USB function, and save it (p. 83).
1. Press **[MODE]**. The **MODE MENU** window appears.
 2. Touch **<FACTORY RESET>**. The **Factory Reset** screen appears.



3. Touch **<OK>**
4. Touch **<Execute>** to execute the Factory Reset. When the display indicates "**Completed!**," the factory reset operation has been completed.

Transferring Patches To and From the D-50/550

You can use MIDI to transmit patch data (64 patches) saved on your D-50 and receive the data with the VC-1 (V-Synth). This procedure is known as “**bulk load**.” This is an easy and convenient way to take your own original patches (64 patches) created with the D-50 and use them with the VC-1.

Conversely, you can also send patch data edited using the VC-1 via MIDI to the D-50. This procedure is called “**bulk dump**.”


* Read this material together with the D-50/550 Owner’s Manual.

Transferring Patches from the D-50 to the VC-1

- Patches (64 patches) bulk loaded from the D-50 to the VC-1 are temporarily transferred to the **patch bank** that includes the current patch.

| Currently Patch Sample | → | Destination Patch Bank Sample |
|------------------------|---|-------------------------------|
| I1-11:Fantasia | → | Int1-11 – Int1-88 |
| I6-88:Big Wave | → | Int6-11 – Int6-88 |

- The patches (64 patches) originally residing in the bulk load destination will appear to have been overwritten, but actually nothing will have been lost. The patches are restored when you turn the power off, then on again.
- The transferred patch data (64 patches) will be lost if you turn off the power. Be sure to save the data (“**Saving Transferred Patches with the VC-1**” (p. 39)).
- Patches saved to memory cards used with the D-50/550 (M-256D) cannot be transferred directly from these memory cards to the VC-1. First, transfer the patch data to the D-50/550 from the memory card (M-256D), then transfer the patch data from the D-50/550 to the VC-1.



Use the following procedure.

Transfer the patch from the memory card to the D-50/550 (p. 37)



Transferring Patches from the D-50/550 to the VC-1 (p. 38)




Saving Transferred Patches with the VC-1 (p. 39)

Transfer the patch from the memory card to the D-50/550


All the 64 Patches data stored on the Memory Card can be loaded to the D-50/550's internal memory.

Using the D-50



1. Insert the Memory Card (M-256D) into the D-50 Card Slot.
2. Turn the **Memory Protect** of the D-50 to **OFF**.
 - 2-1. Press the **[TUNE/FUNCTION]** button.
 - 2-2. Select "**Protect**" with the **Selector** button and turn it **OFF** with the joystick.
3. Press the **[DATA TRANSFER]** button.
4. Select "**(Card -> Int)**" with the corresponding **Selector** button.
5. Press **[ENTER]** button. When the data transfer is completed, the display shows "**Complete.**"
6. Return the Memory Protect of the D-50 to **On**.
 - 6-1. Press the **[TUNE/FUNCTION]** button.
 - 6-2. Select "**Protect**" with the **Selector** button and turn it **ON** with the joystick.

Using the D-550




1. Insert the Memory Card (M-256D) into the D-550 Card Slot.
2. Press the **[DATA TRANS]** button.
3. Using the [◀] or [▶] buttons, select "**(Card -> Int).**"
4. Press the **[ENTER]** button.
5. Press the **[WRITE]** button to turn the Memory Protect **OFF** temporarily.
6. Press the **[ENTER]** button again. When the data transfer is completed, the display shows "**Complete.**"

Transferring Patches from the D-50/550 to the VC-1


- * You cannot bulk load data when a patch in the Preset Banks (Pre1 – Pre6) is selected.
- * The VC-1 display does not change immediately following the bulk load. This is due to the fact that the work area is the bulk load destination (p. 44). You can confirm the outcome of the transfer by switching patches with the **VALUE** dial.

Using the D-50



1. Use a MIDI cable to connect the D-50's **MIDI OUT** connector to the V-Synth's **MIDI IN** connector.
2. Set the D-50 and V-Synth to the same MIDI channel (the basic channel; p. 80).
3. Press the D-50's **[DATA TRANSFER]** button.
4. While pressing the D-50's **[DATA TRANSFER]** button, specify "**B.Dump**" with the **Selector** button.
5. Press the D-50's **[ENTER]** button to begin the bulk dump. When the data transfer is completed, the D-50's display shows "**Complete.**"
6. Press the **[EXIT]** button on the D-50 to return to the play mode.

Using the D-550



1. Use a MIDI cable to connect the D-550's **MIDI OUT** connector to the V-Synth's **MIDI IN** connector.
2. Set the D-550 and V-Synth to the same MIDI channel (the basic channel; p. 80).
3. Press the D-550's **[DATA TRANS]** button.
4. Select "**(B.Dump)**" with the D-550's **[◀]** or **[▶]** buttons.
5. Hold down the **[DATA TRANS]** button and press the D-550's **[ENTER]** button to begin the bulk dump. When the data transfer is completed, the D-550's display shows "**Complete.**"
6. Press the **[EXIT]** button on the D-550 to return to the play mode.

Saving Transferred Patches with the VC-1

The transferred patch data (64 patches) will be lost if you turn off the power. Be sure to save the data.

1. Press **[MODE]** on the VC-1. The **MODE MENU** window appears.
2. Touch **<DATA TRANSFER>**. The **DATA TRANSFER** screen appears.



3. Touch **<Bank Copy>** in the left of the screen. The **Bank Copy** screen appears.
4. When editing a parameter that requires you to specify a value, move the cursor to the value box of that parameter. Then modify the value by either turning the **VALUE dial** or pressing **[INC/+]** or **[DEC/-]**.

Source Bank

Selects the save-source bank.

Value: P1 – P6, I1 – I8

Destination Bank

Selects the save-destination bank.


Value: I1 – I8



5. Touch **<OK>** to execute the Save operation. If you want to cancel without executing, touch **<Cancel>**.

Transferring Patches from the VC-1 to the D-50/550

Using the D-50



1. Use a MIDI cable to connect the V-Synth's **MIDI OUT** connector to the D-50's **MIDI IN** connector.
2. Set the D-50 and V-Synth to the same MIDI channel (the basic channel; p. 80).
3. Turn the **Memory Protect** of the D-50 to **OFF**.
 - 3-1. Press the **[TUNE/FUNCTION]** button.
 - 3-2. Select "**Protect**" with the **Selector** button and turn it **OFF** with the joystick.
4. Enable reception of bulk load data on the D-50.
 - 4-1. Press the D-50's **[DATA TRANSFER]** button.
 - 4-2. While pressing the D-50's **[DATA TRANSFER]** button, specify **(B.Load)** with the **Selector** button.
 - 4-3. Press the D-50's **ENTER]** button.
5. Turn the **Exclusive Sw** of the V-Synth to **On**.
 - 5-1. Press **[MODE]**.
 - 5-2. Touch **<SYSTEM>**.
 - 5-3. Select "**Exclusive Sw**," then turn the V-Synth's **VALUE** dial to specify **On**.
6. Press **[MODE]** on the V-Synth. The **MODE MENU** window appears.
7. Touch **<DATA TRANSFER>**. The **DATA TRANSFER** screen appears.
8. Touch **<B.Dump>** in the left of the screen. The **MIDI Bulk Dump** screen appears.
9. Modify the value by either turning the **VALUE** dial or pressing **[INC/+]** or **[DEC/-]**.

Source Bank


Selects the Patch Bank in the VC-1 with the patch data to transfer to the D-50.

Value: I1 – I8, P1 – P6

10. Touch **<OK>**. The bulk dump starts. If you want to cancel without executing, touch **<Cancel>**.
11. When the data transfer is completed, the D-50's display shows "**Complete.**"
12. Press the **[EXIT]** button on the D-50 to return to the play mode.



Using the D-550



1. Use a MIDI cable to connect the VariOS's **MIDI OUT** connector to the D-550's **MIDI IN** connector.
2. Set the D-550 and V-Synth to the same MIDI channel (the basic channel; p. 80).
3. Turn the **Memory Protect** of the D-550 to **OFF**.
 - 3-1. Press the D-550's **[TUNE]** button.
 - 3-2. Select "**Protect**" with the **[◀]** or **[▶]** buttons, and turn it **OFF** with the **[VALUE]**.
4. Enable reception of bulk load data on the D-550.
 - 4-1. Press the D-550's **[DATA TRANS]** button.
 - 4-2. Select "**(B.Load)**" with the D-550's **[◀]** or **[▶]** buttons, then press the **[ENTER]** button while holding the **[DATA TRANS]** button.
 - 4-3. Press the **[ENTER]** button again.
5. Turn the **Exclusive Sw** of the V-Synth to **On**.
 - 5-1. Press **[MODE]**.
 - 5-2. Touch **<SYSTEM>**.
 - 5-3. Select "**Exclusive Sw**," then turn the V-Synth's **VALUE** dial to specify **On**.
6. Press **[MODE]** on the V-Synth. The **MODE MENU** window appears.
7. Touch **<DATA TRANSFER>**. The **DATA TRANSFER** screen appears.



8. Touch **<B.Dump>** in the left of the screen. The **MIDI Bulk Dump** screen appears.
9. Modify the value by either turning the **VALUE** dial or pressing **[INC/+]** or **[DEC/-]**.

Source Bank

Selects the Patch Bank in the VC-1 with the patch data to transfer to the D-50.

Value: I1 – I8, P1 – P6

10. Touch **<OK>**. The bulk dump starts. If you want to cancel without executing, touch **<Cancel>**.




11. When the data transfer is completed, the D-50's display shows "**Complete.**"
12. Press the **[EXIT]** button on the D-50 to return to the play mode.

Copying a Reverb Type

In addition to the patches (64 patches), **16 reverb types (17–32)** are also saved to the VC-1's patch banks (Pre 1–6, Int 1–8). Different reverb types **17–32** are saved to each patch bank. The reverb types you can use vary with the selected patch as described below.

- All shared common reverb types (1–16) can be used.
 - The reverb types **17–32** in individual banks can be used only with the patches (64 patches) contained in that bank.
 - Reverb types from a bank other than the internal banks (any from 1 through 32) can be copied to a reverb type in the internal banks (any from 17 through 32).
 - This is convenient when, for example, you want to use Reverb Type 25 (Gate Reverb) from the Patch Bank **Pre 1** as Reverb Type 30 in the Patch Bank **Int 1**.
- * *Reverb Types (17–32) are transferred simultaneously with patch data when patch data is transferred from the D-50 to the VC-1 (bulk loaded) or from the VC-1 to the D-50 (bulk dumped).*



1. Press **[MODE]** on the VC-1. The **MODE MENU** window appears.
2. Touch **<DATA TRANSFER>**. The **DATA TRANSFER** screen appears.



3. Touch **<REVERB COPY>** in the left of the screen. The **REVERB COPY** screen appears.
4. Modify the value by either turning the **VALUE** dial or pressing **[INC/+]** or **[DEC/-]**.

Source Bank

Selects the source Patch Bank of Reverb Type.

Value: P1 – P6, I1 – I8

No.

Selects the source Reverb Type.

Value: 1 – 32

Destination Bank

Selects the destination Patch Bank of Reverb Type.

Value: I1 – I8

No.

Selects the destination Reverb Type.


Value: 17 – 32

5. Touch **<OK>**. The display will ask “Are You Sure?”, then touch **<Execute>** to execute the Reverb Copy operation. If you want to cancel without executing, touch **<Cancel>**.
When the reverb copy is completed, the display shows “**Complete.**”



Overview of the VC-1

Memory Structure



1 Work Area

When the VC-1 is inserted in the V-Synth's PC CARD slot, the system program and patch data is loaded from the VC-1 into the V-Synth. The section where the system and patch data is loaded is called the **Work Area**. Content loaded to the Work Area is cleared when the V-Synth's power is turned off. For this reason, if you remove the VC-1 from the V-Synth and switch the power off, then on again, the V-Synth reverts to its ordinary state.

In addition, banks (containing data for 64 patches) bulk dumped from an original D-50 (or other MIDI device) are also stored temporarily in the Work Area. Bulk dumped data is cleared if the power is simply turned off, so be sure to save the data to the VC-1 (p. 34).


2 Temporary Area

Patch data selected for performance is further taken from the Work Area and placed in memory called the **Temporary Area**. Editing of tones and factors is performed on patches in this Temporary Area. Edited patch data is lost if the power is simply turned off, so be sure to save these to the VC-1 (p. 34).

The Basic Concept of a Tone

Throughout the process of programming the D-50, the operation remains simple and logical.

You can think of the D-50 having powerful synthesizers built in. Each of these hypothetical synthesizers could behave like a convention analog synthesizer, or a PCM sampled synthesizer. Any combination of two synthesizers can achieve some remarkable cross-modulation effects.




1 Partial

The VC-1 (D-50) appears to have four powerful synthesizers built in. Each of these hypothetical synthesizer could behave like a conventional **analog synthesizer**, or a **PCM sampled synthesizer**. Consequently, They are referred to as **Partials**, since they are far more than just a pure synthesizer. These Partials are combined in pairs to form a **TONE**. A Tone could either be a mix of the two Partials, or they could take advantage of the LA version of cross modulation.


Synthesizer sound generator

A Synthesizer sound generator works like a conventional analog type synthesizer with an oscillator, a filter, an amplifier and two ENV's.



PCM sound generator



A PCM sound generator provides 128 different PCM sampled sounds (= waveform).



2 Structure

Structure, which is one of the Common Parameters, determines which two of the hypothetical synthesizers (a **synthesizer sound generator** or a **PCM sound generator**) are to be used as Partial 1 and Partial 2.

- These two Partial sounds (Partial 1 and Partial 2) can simply be mixed as show below. By mixing two Partials, fatter sounds can be obtained. This is effective for making strings or organ type sounds.
- Partial 1 can be mixed with the ring-modulated sound of Partials 1 and 2. (“**Ring Modulator**” (p. 47))




3 Tone

A **Tone** consists of two **Partials** (Partials 1 and 2) and a **Common** block. Some Common parameters apply to both Partials (Partial 1 and 2). “**Structure**” is one of the Common parameters. It decides which of the two sound generators is used for each Partial. Other Common parameters are an ENV for pitch, three LFO modules, equalizer, chorus, etc.


Ring Modulator

The **Ring Modulator** multiplies two sounds, creating an unusual and metallic sound that contains complicated harmonics. For instance, two waveforms (① and ②) are multiplied and waveform ③ is created. This is effective for making metallic sounds.




4 Patch

During live performance, you can easily select a **Patch**, which is the combination of two Tones (Upper and Lower), together with programmed E.Q., chorus and reverb. These other parameters are referred to as **Factor**.



Structure of Tone Parameters

Depending on which **generators** are selected in the **Partial Block**, greatly different Tone Parameters will be used. Some Tone Parameters used for the Synthesizer sound generators are irrelevant to the PCM generator. In a Structure with **Ring modulation**, some parameters of Partial 2 are automatically set to those of Partial 1.



WG (Wave Generator)

In the WG (Wave Generator), the pitch and waveform are controlled.

1 Pitch

The basic pitch of a Partial (sound generator) can be set here. The pitch is a Common parameter, and is therefore controlled by **7 P-ENV** and **10 LFO-1**.

2 Waveform, PCM Wave Number

This selects the waveform of the sound source. When a synthesizer sound generator is selected, the waveform can be controlled by the **3 Pulse Width** controls.

3 Pulse Width

This changes the waveform of the sound source. The pulse width is controlled by any **LFO** (= Common parameter).

TVF (Time Variant Filter)

This filter passes lower frequency harmonics and cuts off the higher ones. By changing the cutoff point and the resonance, the waveform changes.

4 Cutoff Frequency

This sets the cutoff point. The cutoff point can be controlled by **8 TVF ENV** and any **LFO** (= Common parameter).

5 Resonance

This emphasizes the cut off point, making more unusual or electronic sounds.

TVA (Time Variant Amplifier)

This controls the volume of the Partial.

6 Level

This determines the volume of the sound. When a synthesizer sound generators used, the level can be controlled with the **9 TVF ENV** and **LFO** (Common Parameter) . When a PCM sound generator is used, the **9 TVA ENV** controls the level.

ENV (Envelope Generator)

This generates a control signal (envelope curve) which controls the pitch, timbre and volume of each Partial (sound generator).

7 P-ENV

This is the ENV which controls pitch. It can be set for two selected Partial at once.

8 TVF ENV

This ENV controls the cutoff point, and can be set for each Partial separately.

9 TVA ENV

This ENV controls the volume level. This is can be set for each Partial separately.

LFO (Low Frequency)

This oscillator generates low frequencies only.

Any of the three LFO's can be used for the two partials, Vibrato, PWM growl or tremolo effects can be obtained using these LFO's

* A different LFO can be used for each section or a **Partial Parameters**.

10 LFO-1

This can control **1 Pitch**, **3 Pulse Width**, **4 Cutoff Frequency** or **6 Level**.

11 LFO-2

This can control **3 Pulse Width**, **4 Cutoff Frequency** or **6 Level**.

12 LFO-3

This can control **3 Pulse Width**, **4 Cutoff Frequency** or **6 Level**.

Creating a Patch

With the VC-1, you have total control over a wide variety of settings. Each item that can be set is known as a **parameter**. When you change the values of parameters, you are doing what is referred to as **“editing.”** This chapter explains the procedures used in creating patches, and the functions of the patch parameters.

There are two methods of sound creation.

- Editing an existing sound.
- Initializing all the parameters of a certain Partial, and then editing the Partial. (p. 56)
- * *Changes you make to sound settings are temporary, and will be lost if you turn off the power or select another sound. If you want to keep the modified sound, you must save it. (“Saving Patches” (p. 34))*

How to Make the Patch Settings

A number of patch **Factors** and **Tone Parameters** are shown in each window.

1. Access the **PATCH TOP** screen, and select the patch whose settings you wish to modify (p. 16).
 - * *If you want to create all your patches from the ground up, rather than the patches that have already been prepared, carry out the Initialize operation (p. 56).*
2. The parameters are organized into several editing groups. Touch one of the buttons at the bottom of the screen to select the edit group containing the parameters you want to set.



3. Touch one of the tabs in the left of the screen to select the desired editing screen.
4. When editing a parameter that requires you to specify a value, move the cursor to the value box of that parameter. Then modify the value by either turning the **VALUE dial** or pressing **[INC/+]** or **[DEC/-]**. You can also modify a value by dragging over the touch screen.
5. Repeat steps 2–4 to complete a patch.
6. If you wish to save the changes you’ve made, perform the Save operation (p. 34). If you do not wish to save changes, press **[EXIT]** to return to the **PATCH TOP** screen.

- * *If you return to the **PATCH TOP** screen without saving, the display will indicate “EDITED,” reminding you that the patch settings have been modified. If you turn off the power or select a different patch while the display indicates “EDITED,” your edited patch will be lost.*



Useful Functions for Editing

The VC-1 provides numerous ways in which you can edit your own patches more conveniently.

Editing a Value

To edit a value, you can use the **VALUE dial**, **[INC/+]** or **[DEC/-]**. In each VC-1 screen, you can select a value using the cursor as described earlier, and modify its value. Each parameter has its own range of possible values. You **CANNOT** set any value smaller than the minimum value or greater than the maximum value.

Cursor Buttons


Press **[▲]**, **[▼]**, **[◀]**, or **[▶]** (the cursor buttons) to move the cursor.

VALUE dial

- Turning the **VALUE dial** clockwise increases the value, and turning it counterclockwise decreases its value.
- Hold down **[SHIFT]** as you move the **VALUE dial** to increase value increments to make large value changes more quickly.

[INC/+] and [DEC/-]

- Press **[INC/+]** to increase the selected value, and **[DEC/-]** to decrease it.
- Keep the button pressed for continuous adjustment.
- For faster value increases, keep **[INC/+]** pressed down and press **[DEC/-]**. To decrease values quickly, keep **[DEC/-]** pressed down and press **[INC/+]**.
- Hold down **[SHIFT]** while using **[INC/+]** or **[DEC/-]**, the value will change in larger steps.



Undoing an editing Operation

The **Undo** function returns the current value of the parameter to the original value before being edited. This only refers to the last parameter that has been adjusted.


- In the upper right of the screen, touch **<▼>**. A pull-down menu appears.
- In the pull-down menu, touch **<UNDO>**.



Editing with the Panel Controls (Partial Select)

You can assign a variety of parameters (such as TVF Resonance or TVA Level) to the knobs and sliders at the right of the front panel for direct, intuitive editing of the parameters.

The partials to which the tone parameters assigned to the different knobs and sliders are applied are specified in the **PATCH TOP** screen or with **STRUCTURE [1]** at the right of the front panel. You can use the knobs and sliders to edit the tone parameters of the partial whose indicator is lit.





* The Partial select setting will be written into the VC-1 by taking the saving procedure. (p. 34)

Silencing the Sound of the Partial

While editing a Partial parameter, any Partial sound can be muted (Partial Mute).

Partials to be muted are specified in the **PATCH TOP** screen or with **STRUCTURE [3]** at the right of the front panel. The partial is muted when the indicator is off; muting is defeated when the indicator is lit.



* The Partial Mute setting will be written into the VC-1 by taking the saving procedure. (p. 34)

Copying Tone Settings

A Tone from another Patch can be copied to the patch currently selected (Tone Copy).

1. Make sure the **PATCH TOP** screen is displayed.
2. Touch **<▼>** in the upper right of the screen. A pulldown menu appears.
3. In the pulldown menu, touch **<TONE COPY>**. The **TONE COPY** window appears.




4. Touch some buttons (checkbox) in the left side of the screen to select the object you want to copy (✓).

| Display | | Value |
|----------|----------------|------------------------------|
| 1 | <Source> | I1-11-I8-88, P1-11-P6-88 |
| 2 | <TONE> | Off, On (✓), UPPER, LOWER |
| | <PATCH FACTOR> | Off, On (✓) |
| | <CTRL SETUP> | Off, On (✓) |

5. Touch a button (valuebox) in the right side of the screen to select the destination Tone.

| Display | | Value |
|----------|--------|--------------|
| 3 | <TONE> | UPPER, LOWER |



6. Touch **<Execute>** to execute the copy operation. If you want to cancel without executing, touch **<CANCEL>**.

Copying Parameter Settings

A group of Tone parameters can be copied within a Patch (Parameter Copy).

1. Make sure the **PATCH TOP** screen is displayed.
2. Touch <▼> in the upper right of the screen. A pulldown menu appears.
3. In the pulldown menu, touch <PARAM COPY>. The **PARAM COPY** window appears.



4. Touch some button (valuebox) in the left side of the screen to select the object you want to copy.

1 TONE (Source Tone)

Select the Tone to be copied.

Value: UPPER, LOWER

2 PARTIAL (Source Partial)

Select the Partial parameter to be copied.

Value: ALL, COMMON, PART-1, PART-2

| Display | Function |
|----------|------------------------|
| <ALL> | All the parameters |
| <COMMON> | Common parameters |
| <PART-1> | Partial 1's parameters |
| <PART-2> | Partial 2's parameters |

3 BLOCK (Source Block)

If either PART-1 or PART-2 is selected in **2**, any of the following Blocks can be selected.

Value: ALL, WG, TVF, TVA

| Display | Function |
|---------|------------------------|
| <ALL> | All parameters |
| <WG> | WG parameters (p. 64) |
| <TVF> | TVF parameters (p. 68) |
| <TVA> | TVA parameters (p. 73) |



5. Touch some button (valuebox) in the right side of the screen to select the destination Tone.

4 TONE (Destination Tone)

Select the location for the Source Tone.

Value: UPPER, LOWER

5 PARTIAL (Source Partial)

If PART-1 or PART-2 is selected in **2**, select the corresponding block.

Value: PART-1, PART-2

- * When **2** is set to **All** or **COMMON**, **5** setting is ignored.
- 6. Touch **<Execute>** to execute the copy operation. If you want to cancel without executing, touch **<CANCEL>**.

Auditioning the Sound Before Editing

While editing a parameter, you may wish to hear the original sound before it was edited. The **Compare** function allows you to call the original Patch without erasing the edited sound.

1. In the upper right of the screen, touch **<▼>**. A pulldown menu appears.
2. In the pulldown menu, touch **<COMPARE>**. The **PATCH COMPARE** window appears.



3. Touch **<COMPARE>** to turn it on, and the original sound may be heard by playing the keyboard.
4. Touch **<COMPARE>** again to turn it off, and the edited sound will come back.
5. Touch **<OK>** to return to the **PATCH TOP** screen.

Initializing Patch Settings

Initialize means to return the settings of the currently selected patch to a standard set of values. The Initialize operation will affect only the currently selected patch in temporary area; the patches that are stored in internal memory and work area will not be affected. If you wish to restore all of the VC-1's settings to their factory values, perform a **Factory Reset** (p. 35).

1. Access the **PATCH TOP** screen, and select the patch that you wish to initialize (p. 16).
2. Touch <▼> in the upper right of the screen. A pulldown menu appears.
3. In the pulldown menu, touch <INITIALIZE>. The **INITIALIZE** window appears.



4. Touch some buttons (checkbox) in the screen to select the object you want to initialize (✓).
 <Check All>: Mark all object.
 <PATCH FACTOR>: Patch factor settings. (p. 26)
 <CTRL SETUP>: Control setup settings. (p. 57)
 <COMMON>: Common parameter settings. (p. 57)
 <PART-1>: Partial-1 parameter settings. (p. 63)
 <PART-2>: Partial-2 parameter settings. (p. 63)
5. Touch <Execute>. The initialization will be carried out, and you'll be returned to the **PATCH TOP** screen.



Tone Parameters

Common Parameters

<Struct>: (p. 57)
 <P-ENV>: (p. 58)
 <LFO>: (p. 60)
 <EQ/CHORUS>: (p. 61)



Structure

Struct (Structure Number)

Select one of the following seven Structures.

Value: 1–7

| Number | | Partial 1 | Partial 2 | Combination of two Partials |
|--------|--|-----------|-----------|---|
| 1 | | S | S | Mixture of Partial 1 and partial 2. |
| 2 | | S | S | Mixture of Partial 1 and ring-modulation. |
| 3 | | P | S | Mixture of Partial 1 and partial 2. |
| 4 | | P | S | Mixture of Partial 1 and ring-modulation. |
| 5 | | S | P | Mixture of Partial 1 and ring-modulation |
| 6 | | P | P | Mixture of Partial 1 and partial 2. |
| 7 | | P | P | Mixture of Partial 1 and ring-modulation. |

S : Synthesizer Sound Generator

P : PCM Sound Generator, **R** : Ring Modulator

Balance (Partial Balance) **VC-1** **CTRL**

Adjusts the volume balance of the Upper and Lower Tone.

Value: 0–99

P-ENV (Pitch Envelope)

P-ENV Edit (Envelope)

Velo (Velocity Range) **CTRL**

Sets the maximum effect of the velocity that controls the pitch of the P-ENV. At higher values, the keyboard velocity has a greater, effect on the envelope.


Value: 0–2



TKF (Keyfollow (Time)) **CTRL**


Sets the time of the P-ENV depending on the key played. Higher values change the time more drastically.

Value: 0–4



P-ENV Time Edit

The envelope curve is determined by times and levels.



T1 (Time 1) CTRL

Sets the time needed from point 0 (the moment the key is pressed) to point 1.

Value: 0–50

T2 (Time 2) CTRL

Sets the time needed from point 1 to point 2.

Value: 0–50

T3 (Time 3) CTRL

Sets the time needed from point 2 to point 3.

Value: 0–50

T4 (Time 4) CTRL

Sets the time needed from the moment the key is released to point 4.

Value: 0–50

**P-ENV Level Edit****L0 (Level 0) CTRL**

Sets the pitch created the moment a key is pressed.

Value: -50→+50

L1 (Level 1) CTRL

Sets the pitch of the point 1.

Value: -50→+50

L2 (Level 2) CTRL

Sets the pitch of the point 2.

Value: -50→+50

SusL (Sustain Level) CTRL

Sets the pitch of point 3.

Value: -50→+50

EndL (End Level) CTRL

Sets the pitch of point 4.

Value: -50→+50

- * If the Levels of two adjacent points are set to similar values, the time between these two points may prove to be shorter than what is actually set, or even zero.



* The maximum variable range of each level will depend on the Velocity Range in P-ENV. (p. 58)

| Velocity Range | Level | Range |
|----------------|-------|-------------|
| 0 | +50 | +1 octave |
| | -50 | -1 octave |
| 1 | +50 | +1.5 octave |
| | -50 | -1.5 octave |
| 2 | +50 | +2 octave |
| | -50 | -2 octave |

Pitch Mod (Pitch Modulation)

Depending on how the LFO in WG modulation (p. 67) is set, the vibrato set here may have no effect at all.

LFOD (LFO Depth) **CTRL**

Sets the depth of LFO-1, that controls the WG pitch. Higher values deepen the effect.

Value: 0–100

Lever (Pitch Lever Modulation) **CTRL**

Sets the sensitivity of the vibrato depth controlled by the bender lever. Higher values deepen the effect.

Value: 0–100

After (Pitch Aftertouch Modulation) **CTRL**

This sets the sensitivity of the vibrato depth controlled by aftertouch. Higher values deepen the vibrato effect.

Value: 0–100



LFO (Low Frequency Oscillator)

The parameters of LFO-2 and LFO-3 can be set like LFO-1, except for a few parameters.

Wave (LFO Waveform) **CTRL**

Selects the waveform of the LFO.

Value: TRI, SAW, SQU, RND

| Display | Waveform |
|-----------------------|----------------------------|
| TRI (Triangle) | |
| SAW (Sawtooth) | |
| SQU (Square) | |
| RND (Random) | Waveform changes randomly. |



Rate (LFO Rate)

Sets the rate (frequency) of the LFO. Higher values quicken the rate.

Value: 0–100

Delay (Delay Time) CTRL

This sets the time needed for the LFO to appear, from the moment a key is pressed. Higher values increase the delay time.

Value: 0–100

Sync CTRL

Selects the timing of the LFO oscillation as follows. For LFO-2 and LFO-3, KEY cannot be selected.

Value: OFF, ON, KEY

| Display | Description |
|---------|--|
| OFF | LFO does not sync to the keyboard. |
| ON | When a key is played after all keys have been released, the LFO begins its wave generating process from the beginning. |
| KEY | LFO begins its wave generation from the beginning each time a new key is played. |

EQ/CHORUS (Equalizer/Chorus)

EQ Edit (Equalizer)

In the equalizer section, the frequency characteristic of the sound can be modified. The Equalizer consists of the following parameters.

**LowFreq (Low Frequency)**


Sets the frequency where the gain is altered in the low to middle range.

Value: 63, 75, 88, 105, 125, 150, 175, 210, 250, 300, 350, 420, 500, 600, 700, 840 Hz

LowGain (Low Gain) CTRL

Sets the gain of the lower frequencies. “+” settings raise the gain, and “-” settings lower it.

Value: -12→+12 dB



HiFreq (High Frequency)


Sets the frequency where the gain is altered in the middle to high range.

Value: 250, 300, 350, 420, 500, 600, 700, 840 Hz, 1.0, 1.2, 1.4, 1.7, 2.0, 2.4, 2.8, 3.4, 4.0, 4.8, 5.7, 6.7, 8.0, 9.5 kHz

HiQ (High Q) CTRL


Sets the width of the frequency band where the gain is boosted or cut. With a higher value, the frequency band is narrower, and vice versa.

Value: 0.3, 0.5, 0.7, 1.5, 2.0, 3.0, 4.2, 6.0

**HiGain (High Gain) CTRL**

Sets the gain of the Hf frequency. “+” settings raise the gain and “-” settings lower it.

Value: -12+12 dB

**Chorus Edit****Type (Chorus Type)**

Selects one of the 8 basic chorus effects.

Value: 1–8

| Display | Type |
|---------|-----------------|
| 1 | Chorus 1 |
| 2 | Chorus 2 |
| 3 | Flanger 1 |
| 4 | Flanger 2 |
| 5 | Feedback Chorus |
| 6 | Tremolo |
| 7 | Chorus Tremolo |
| 8 | Dimension |

**Rate (Chorus Rate) CTRL**

Sets the rate of the chorus effect. Higher values quicken the rate.

Value: 0–100

Depth (Chorus Depth) CTRL

Sets the depth of the chorus effect. Higher values deepen the effect.

Value: 0–100

Balance (Chorus Balance) CTRL

This sets the volume balance of the chorus of the chorus sound and normal sound.


Value: 0–100

| Value | Balance |
|------------|---------------------------------|
| 100 | Only the chorus sound is heard. |
| 50 | Chorus sound = Normal sound |
| 0 | Only the normal sound is heard. |

Partial Parameters

Restriction of the available parameters caused by Structure

Depending on what **Structure** (p. 57) is used, the available parameters may be different.

1. Some parameters included in a Partial that uses a **PCM sound generator** are invalid. The **PCM** mark is shown when the parameters apply even for PCM sounds.
2. With **Ring Modulation**, some parameters in Partial 2 will automatically become the same as for Partial 1. Therefore, the values shown in the display are irrelevant with the actual values. The **Ring**  mark is shown for such parameters.

<FORM>: (p. 64)
 <PITCH>: (p. 66)
 <TVF>: (p. 68)
 <TVA>: (p. 73)
 <MOD>: (p. 76)





WG Form (WG Waveform)

WG Form (Waveform)

Wave (Waveform) CTRL

Selects the waveform of the synthesizer sound generator.

Value: SQU, SAW

| Display | Waveform |
|-----------------------|---|
| SQU (square) |  |
| SAW (Sawtooth) |  |

* A sawtooth waveform is produced by processing a square Waveform at the TVF, that is, all the waveform are square at WG even when a sawtooth is selected.



PCM (PCM Wave Number) PCM CTRL

This selects one of the 127 different sampled waves of the PCM sound generator. (p. 138)

Value: 1-127

WG PW (WG Pulse Width)




PW (Pulse Width) CTRL

A square waveform has exactly the same width, up and down but a Pulse waveform has different widths. The ratio of upper width to lower is called pulse width. Depending on the set pulse width value, the harmonic content of the sound changes greatly.

Value: 0-100

* When a **sawtooth** is selected with **WG Waveform**, pulse width 50% raises the pitch by an octave.



Velo (Velocity Range) CTRL

Sets the sensitivity of the velocity that controls the pulse width.

With “-” values, the pulse width becomes smaller by playing the keyboard harder, and with “+” values, the pulse width becomes wider by playing the keyboard harder.


Value: -7-+7

After (Aftertouch Range) CTRL

Sets the sensitivity of the aftertouch that controls the pulse width.

With “-” values, the pulse width becomes smaller with stronger aftertouch, and with “+” values, the pulse width becomes wider with stronger aftertouch.


Value: -7-+7

**LFO (LFO Select) CTRL**

Pulse Width Modulation (PWM) means changing the pulse width periodically. LFO Select decides which of the LFO's is to be used for modulating the pulse width.

Value: +1, -1, +2, -2, +3, -3

| Display | LFO (Phase) |
|---------|-------------|
| +1 | LFO-1 (+) |
| -1 | LFO-1 (-) |
| +2 | LFO-2 (+) |
| -2 | LFO-2 (-) |
| +3 | LFO-3 (+) |
| -3 | LFO-3 (-) |

**LFOD (LFO Depth) CTRL**

This sets the depth of the PWM. Higher values Deepen the effect.

Value: 0-100

WG PITCH

WG Pitch

Coars (Pitch Coarse) **PCM** **CTRL**

Sets the standard pitch of a Partial in semi-tone steps. The standard pitch is the pitch at C5 (middle C) key.

Value: C1–C7

Fine (Pitch Fine) **PCM** **CTRL**

The standard pitch can be altered over about +/- 50 cents.

Value: -50—+50



KF (Keyfollow (pitch)) **PCM** **CTRL**


Usually, the keyboard to a synthesizer assigns a semi-tone to each key. This parameter can change the pitch ratio as show below. The value represents how many octaves are changed over 12 keys.

Value: -1, -1/2, -1/4, 0, 1, 1/4, 3/8, 1/2, 5/8, 3/4, 7/8, 1, 5/4, 3/2, 2, s1, s2

* s1 or s2 may be selected for slightly stretching octaves.

s1: Pitch 1 cent higher than one octave.

s2: Pitch 5 cents higher than one octave.



WG Mod (WG Modulation)




LFO (LFO Mode) **PCM** **CTRL**

Selects one of the following four vibrato modes.

Value: OFF, (+), (-), A&L

| Display | Description |
|---------|--|
| OFF | No vibrato is obtained. |
| (+) | Vibrato is on. |
| (-) | Vibrato is on but inverted. |
| A&L | Vibrato can be obtained only by Aftertouch and Bender Lever. |




ENV (P-ENV Mode) **PCM** **CTRL**

Selects one of the following three modes, determining how the pitch is controlled by P-ENV.

Value: OFF, (+), (-)

| Display | Description |
|---------|--|
| OFF | No alteration. |
| (+) | Pitch changes with the set P-ENV curve. |
| (-) | Pitch changes with the P-ENV curve inverted. |



Bend (Bender Mode) **PCM**

Selects how the pitch is controlled by the bender lever as follows.

Value: OFF, KEY, NOM

| Display | Description |
|---------|--|
| OFF | No pitch alteration by moving the lever right or the left. |
| KF | Pitch changes within the Bender range, set in Patch Factors, plus Keyfollow (Pitch) of WG. |
| NOM | Pitch changes within the Bender range, set in Patch Factors. |

Bender Mode Example:

- If the Bender range is set to 12 (1 octave), and the Keyfollow (Pitch) of WG is set to 2, the maximum pitch change caused by moving the Bender Lever is 2 octaves.
- When the Keyfollow (Pitch) of WG is set to zero, there is no pitch change caused by the Bender lever.

TVF (Time Variant Filter)


TVF



Freq (Cutoff Frequency) **CTRL**

Sets the cutoff point of the TVF. As you lower the value, higher frequencies are removed and the waveform gradually become an approximation of a sine wave, then the sound will finally fade out.


Value: 0–100



Reso (Resonance) CTRL

Boosts the cutoff point. As you increase the value, specific harmonics are emphasized and the sound will become more unusual, more electronic in nature.

Value: 0–30

**KF(Keyfollow (Cutoff Point)) CTRL**


Keyfollow can change the cutoff point depending on the key played. Just like the Keyfollow of WG pitch, the value represents how many octaves change over 12 keys.

Value: -1, -1/2, -1/4, 0, 1, 1/4, 3/8, 1/2, 5/8, 3/4, 7/8, 1, 5/4, 3/2, 2

BP (Bias Point) CTRL

You can add a further change (= bias level) to the Keyfollow curve, and set the range (bias direction) where the bias level is valid. The bias range is where the bias level is valid on the keyboard. It can be set with the **bias point** (where the bias range begins) and **bias direction** (< or >).

Value: <A1-<C7, >A1->C7




| Display Example | Example Function |
|-----------------|--|
| >C4 | The bias level is only valid on the keyboard above the C4 key. |
| <C4 | The bias level is only valid on the keyboard below the C4 key. |

BLevel (Bias Level) CTRL

The bias level can be set. “+” values raise the curve, and “-” value lower the curve.

Value: -7–+7

Keyfollow Adjustment



The curve in the picture represents the Keyfollow value with the bias level added.

- **TVF Keyfollow (Cutoff Point):** 0
- **Bias Direction:** >C4

TVF ENV (TVF Envelope)

Depth (ENV Depth) **CTRL**

Sets the depth of the TVF ENV modulation that changes the TVF cutoff Point. Higher values deepen the effect.

Value: 0–100

Velo (Velocity Range) **CTRL**

Sets the sensitivity of the velocity than controls the depth of the TVF ENV. At higher values, the effect is deeper by playing harder.

Value: 0–100



DKF (Keyfollow (Depth)) **CTRL**


This can change the TVF ENV depth depending on the key played. Higher values change the depth more drastically.

Value: 0–4

TKF (Keyfollow (Time)) **CTRL**


This can change the time of the TVF ENV depending on the key played. Higher values change the time more drastically.

Value: 0–4



TVF ENV Time

An envelope curve is determined by times and levels.



T1 (Time 1) **CTRL**

Sets the time needed to reach point 1 from the moment the key is pressed.

Value: 0–100

T2 (Time 2) **CTRL**

Sets the time needed to reach point 2 from point 1.

Value: 0–100

T3 (Time 3) **CTRL**

Sets the time needed to reach point 3 from point 2.

Value: 0–100

T4 (Time 4) **CTRL**

Sets the time needed to reach point 4 from point 3.

Value: 0–100

T5 (Time 5) **CTRL**

Sets the time needed to reach point 5 from the moment the key is released.

Value: 0–100



TVF ENV Level

L1 (Level 1) CTRL

Sets the of point 1.

Value: 0–100

L2 (Level 2) CTRL

Sets the level of point 2.

Value: 0–100

L3 (Level 3) CTRL

Sets the level of point 3.

Value: 0–100

SusL (Sustain Level) CTRL

This sets the level of point 4.

Value: 0–100

EndL (End Level) CTRL

To lower the level after releasing the key, set this to 0, and to raise the level, set it to 100.

Value: 0, 100

- * The End Level is retained until you release and play the key again.
- * If the Levels of two adjacent points are set to similar values, the time between these two points may prove to be shorter than what is actually set, or even zero.



TVA (Time Variant Amplifier)

TVA

Level **PCM** **CTRL**

Sets the volume of a Partial. Higher values may cause sound distortion. If so, lower the value. Even when the Level is set to zero here, the sound may not be completely muted if the TVA ENV curve is high.

Value: 0–100

Velo (Velocity Range) **PCM** **CTRL**

Sets the sensitivity of the velocity that controls the volume of the sound. “-” values lower the level by harder playing, and “+” values raise the level by harder playing.

Value: -50→+50

BP (Bias Point) **PCM** **CTRL**

You can change the overall volume of the keyboard (= bias level) from the set level, and set the range (bias direction) where the bias level is valid.

This bias range is where the bias level is valid on the keyboard. It can be set with the bias point (Where the bias range begins) and bias direction (< or >).

Value: <A1–<C7, >A1→>C7

| Display Example | Function Example |
|-----------------|--|
| >C4 | The bias level is only valid on the keyboard above the C4 key. |
| <C4 | The bias level is only valid on the keyboard below the C4 key. |


BLevel (Bias Level) **PCM** **CTRL**

The curve (bias level) can be set. Lower values make the curve steeper.

Value: -12–0



Volume Adjustment



- **Bias Point:** >C6

TVA ENV (Envelope)

Velo (Velocity Follow (Time 1)) **PCM** **CTRL**

Sets the sensitivity of the velocity than controls the Time 1 of the TVA ENV. Increasing the sensitivity shortens Time 1, by stronger playing.


Value: 0–4



TKF (Keyfollow (Time)) **PCM** **CTRL**


This can change the time of the TVA ENV depending on the key played. 0 to 4 are valid. Higher values change the time more drastically.

Value: 0–4



TVA ENV Time

An envelope curve is determined by times and levels.



T1 (Time 1) **PCM** **CTRL**

Sets the time needed to reach point 1 from the moment the key is pressed.

Value: 0–100

T2 (Time 2) **PCM** **CTRL**

Sets the time needed to reach point 2 from point 1.

Value: 0–100

T3 (Time 3) **PCM** **CTRL**

Sets the time needed to reach point 3 from point 2.

Value: 0–100



T4 (Time 4)

Sets the time needed to reach point 4 from point 3.

Value: 0–100

T5 (Time 5) PCM CTRL

Sets the time needed to reach point 5 from the moment the key is released.

Value: 0–100

TVA ENV Level**L1 (Level 1) PCM CTRL**

Sets the level of point 1.

Value: 0–100

L2 (Level 2) PCM CTRL

Sets the level of point 2.

Value: 0–100

L3 (Level 3) PCM CTRL

Sets the level of point 3.

Value: 0–100

SusL (Sustain Level) PCM CTRL

Sets the level of point 4.

Value: 0–100

EndL (End Level) PCM CTRL

To lower the level after releasing the key, set this to 0, and to raise the level, set it to 100.

Value: 0, 100

- * *The End Level remains until the key is released and played again. That is, at a value of 100, the sound remains. However, the PMC Sound Generator's One-shot sounds do not remain even when set to 100.*
- * *If the levels of two adjacent points are set to similar values, the time between these two points may prove to be shorter than what is actually set, or even zero.*



MOD (Modulation)

TVF MOD


LFO (LFO Select) **CTRL**

Selects the LFO that changes cutoff point periodically (creating growl effects).

Value: +1, -1, +2, -2, +3, -3



| Display | LFO (Phase) |
|---------|-------------|
| +1 | LFO-1 (+) |
| -1 | LFO-1 (-) |
| +2 | LFO-2 (+) |
| -2 | LFO-2 (-) |
| +3 | LFO-3 (+) |
| -3 | LFO-3 (-) |



LFOD (LFO Depth) **CTRL**

Sets the depth of a growl effect. Higher values deepen the effect.

Value: 0–100

After (Aftertouch Range) **CTRL**

Sets the sensitivity of the aftertouch that controls the cutoff point. “-” values lower the cutoff point by stronger Aftertouch, and “+” values raise it.

Value: -7+7

TVA MOD


LFO (LFO Select) **PCM** **CTRL**

Selects the LFO that changes the volume periodically (tremolo effects).

Value: +1, -1, +2, -2, +3, -3



| Display | LFO (phase) |
|---------|-------------|
| +1 | LFO-1 (+) |
| -1 | LFO-1 (-) |
| +2 | LFO-2 (+) |
| -2 | LFO-2 (-) |
| +3 | LFO-3 (+) |
| -3 | LFO-3 (-) |



LFOD (LFO Depth) **PCM** **CTRL**

Sets the depth of the tremolo effect. Higher values deepen the effect.

Value: 0–100

After (Aftertouch Range) **PCM** **CTRL**

Sets the sensitivity of the aftertouch that controls the volume. “-” values lower the volume by stronger aftertouch. And “+” values increase the volume by stronger aftertouch.

Value: -7–+7

Settings for the Entire VC-1

Settings that affect the entire operating environment of the VC-1, such as tuning and MIDI message reception, are referred to as **System functions**. This section explains how to make settings for the System functions and describes the functions of the different System parameters.

How to Make the System Function Settings

1. Press **[MODE]**. The **MODE MENU** window appears.
2. Touch **<SYSTEM>**. The **SYSTEM** screen appears.



3. Move the cursor to the value box of that parameter. Then modify the value by either turning the **VALUE dial** or pressing **[INC/+]** or **[DEC/-]**.
4. Repeat steps 3 to make the settings for the System function.
5. After you have edited the settings of the System function, touch **<Write>**, located in the lower right of the screen.



* Changes you make to the System function settings are only temporary—they will be discarded as soon as the power is turned off. If you want to keep any changes you've made in the system settings, you must save them in VC-1. When you perform the save procedure, the data that previously occupied the save destination will be lost. However, the factory setting data can be recovered by performing the Initialization procedure. (Factory Reset; p. 35)

Sound Setting

Master Tune

Adjusts the overall tuning of the VC-1. The display shows the frequency of the A4 note (center A).

Value: 427 – 452 Hz

Sound Character

Sets whether the output characteristics of the sound are the same as those of the D-50 (D-50) or the V-Synth (V-Synth).

Value: D-50, V-Synth

Digital Freq (Digital Frequency)

Sets the sampling frequency of the digital output.

Value: 44.1, 48, 96 kHz



Keyboard

Octave (Octave Shift)

Transposes the pitch of the keyboard in 1 octave units.

Value: -3 – 3

Transpose

Modifies the pitch range of the keyboard in semitone steps.

Value: -12 – +12



KBD Sens (Keyboard Sensitivity)

Adjusts the keyboard's touch.

Value: LIGHT, MEDIUM, HEAVY

| Display | Function |
|---------|--|
| LIGHT | Light weight synthesizer keyboard like |
| MEDIUM | Standard |
| HEAVY | Acoustic piano simulation |

Aftertouch Sens

Specifies the Aftertouch sensitivity. Higher values will allow Aftertouch to be applied more easily.

Normally you will leave this at "50."

Value: 0 – 100

Pedal Polarity

Hold (Hold Pedal)

Select the polarity of the Hold pedal. On some pedals, the electrical signal output by the pedal when it is pressed or released is the opposite of other pedals. If your pedal has an effect opposite of what you expect, set this parameter to “REVERSE.” If you are using a Roland pedal (that has no polarity switch), set this parameter to “STANDARD.”

Value: STANDARD, REVERSE



Pedal1, Pedal2 (Control Pedal 1, Control Pedal 2)

Selects the polarity of the pedal. On some pedals, the electrical signal output by the pedal when it is pressed or released is the opposite of other pedals. If your pedal has an effect opposite of what you expect, set this parameter to “REVERSE.” If you are using a Roland pedal (that has no polarity switch), set this parameter to “STANDARD.”

Value: STANDARD, REVERSE

MIDI

MIDI CH (MIDI Channel)

Sets the **Basic Channel** (MIDI channel on which the VC-1 receives and transmits messages).

Value: 1 – 16

- * The transmit change can be set to a different number from the Basic Channel individually from each Patch (p. 32).

Control

Determines how to receive messages from an external MIDI device. (“**Key Mode Alteration**” (p. 126))

Value: B.CH, G.CH, MdeOFF



| Display | Function |
|--|--|
| B.CH (Basic Channel mode) | When the VC-1 is being controlled in Mono mode, it receives the Voice messages (except for Note Event, Pitch Bender) on the Basic Channel from the external device. |
| G.CH (Global Channel mode) | When the VC-1 is being controlled in Mono mode, by an external device that has a Global Channel (one number smaller than the basic channel) it can receive all the Voice messages (except for Note Event, Pitch Bender) On the Global Channel. |
| MdeOFF (Mode Message OFF mode) | In this mode, the VC-1 does NOT receive the Mode messages from the external MIDI device, but is assigned to the Key mode as set on the VC-1. |

SeparateCH (Receive Channel in Separate Mode)

When **SEP** (Separate Mode) or **SEP-S** (Separate Solo Mode) is selected, the Upper and Lower Tones can be controlled on different channels. The Lower Tone is controlled by the basic channel, and the Upper Tone is controlled by the receive channel set here. The V-Synth's keyboard can control only the Upper Tone.

Value: 1 – 16

- * *The receive channel of each Patch can be set to a different number from the channel set here. (p. 32)*

Local (Local Switch)

Local OFF separates the keyboard section from the synthesizer section in the VC-1. Therefore, Performance information is sent from the MIDI OUT connector, but the VC-1 does NOT make any sound. The Performance information fed into the MIDI IN connector, however, can control the VC-1's synthesizer section.

Value: Off, On

Prog.C (Program Change Switch)

To receive or transmit Program Change messages, set this to **On**.

Program Change messages are transmitted only when a Patch is selected by operating the V-Synth's panel buttons, or when the Program Change number to be transmitted is altered also on the V-Synth's panel. IN other words, Program Change messages are not transmitted by patch selection with the Program Change messages sent from an external MIDI device.

Value: Off, On

- * *The Program Change Number of each Patch can be set to a different number from the number set here. (p. 32)*

Exclusive (Exclusive Switch)

To receive or transmit Exclusive messages (Roland ID Number only), set this to **On**, **P-Dump** or **TxEEdit**.

Value: Off, On, P-Dump, TxEdit

| Display | Function |
|----------------|--|
| On | Normally. |
| P-Dump | The patch data that you select is transmitted. |
| TxEEDIT | The parameter data that you edited is transmitted. |

- * *When set to **P-Dump**, the Patch you select is transmitted to an external device. However, it cannot be transmitted by Patch Shift with the pedal switch, or by patch selection with the Program Change messages sent from an external device.*

Bank.S (Bank Select Switch)

To receive or transmit Bank Select messages, set this to **On**.

Value: Off, On

USB MIDI (USB MISI Switch)

If you want to exchange MIDI messages with a sequencer or UNI QUEST editor via USB connector, set this to **On**. (“**Exchanging MIDI Messages with Your Computer**” (p. 88))

Value: Off, On

Initializing the System Settings

The current settings of the system functions can be restored to a set of standard settings, or to the factory settings (System Initialize).

1. Access the System Edit screen.
2. Touch **<Init>**, located in the lower right of the screen.
3. If you want the factory settings to be in effect the next time the VC-1 is powered up, touch **<Write>** to save the settings.



Connecting to Your Computer via USB

Recovering the System from the CD-ROM

If while running the VC-1 from a computer you happen to delete (format) any of the VC-1's folders or files or change file or folder names, the VC-1 will fail to operate correctly. In such instances, recover the VC-1's program from the CD-ROM included with the VC-1.

Use the following procedure.

Selecting the V-Synth's USB Storage Mode (p. 83)



Connecting the V-Synth to Your Computer via USB (p. 84)




Recovering the System (p. 86)



Canceling the USB Connection (p. 86)

Selecting the V-Synth's USB Storage Mode

1. Turn off the power of VC-1 (V-Synth) once, then pull out the VC-1 from the **PC CARD** slot.
2. Turn on the power of V-Synth again. Wait for the V-Synth to start up normally.
3. Press **[MODE]** to access the **V-Synth MODE MENU** window.
4. Touch **<SYSTEM>**. The **SYSTEM Com Master** screen appears.



5. In the left side of the screen, touch the **<MIDI USB>** tab. The **SYSTEM Com MIDI/USB** screen appears.
6. Touch **<USB Setup>**. The **SYSTEM Com USB Setting** window appears.



7. Touch USB Mode **<Storage>**. USB Storage mode will be selected.
8. Touch **<OK>**.



9. When a **WARNING** window like the following appears, touch **<ACCEPT>** to close the window.
10. In the lower right of the SYSTEM Com MIDI/USB screen, touch **<Write>** to save the system settings.



Connecting the V-Synth to Your Computer via USB

The installation procedure will differ depending on your system. Please proceed to one of the following sections, depending on the system you use.

- **Windows XP/2000/Me/98** (p. 84)
- **Macintosh** (p. 85)


Windows XP/2000/Me/98

1. Make sure that the power of the VC-1 is turned off.
2. Start up your computer.
3. Connect the V-Synth and your computer using a USB cable.
4. Turn on the power of V-Synth.
5. Insert the **VC-1** into the **PC CARD** slot of the V-Synth rear panel.
6. Press **[MODE]** to access the **V-Synth MODE MENU** window.
7. Touch **<USB>**. The USB Storage screen appears.



8. Touch **<PC Card>** to establish the connection with your computer.
When the USB connection is established for first time, the driver installation will begin. A dialog box of "Found new hardware" will appear near the Windows task tray. Installation is completely automatic. Please wait for it to be completed.
9. When installation is completed, open My Computer and you will see a new drive icon.


| OS | Icon name |
|--------------------|----------------|
| Windows 98/Me/2000 | Removable Disk |
| Windows XP | VC-1 |



Once the V-Synth is connected, you can recover system files by operating your computer. (p. 86)

Macintosh

1. Make sure that the power of the V-Synth is turned off.
2. Start up your computer.
3. Connect the V-Synth and your computer using a USB cable.
4. Turn on the power of V-Synth.
5. Insert the **VC-1** into the **PC CARD** slot of the V-Synth rear panel.
6. Press **[MODE]** to access the **V-Synth MODE MENU** window.
7. Touch **<USB>**. The USB Storage screen appears.



8. Touch **<PC Card>** to establish the connection with your computer.
9. When the USB connection is established, a new drive icon will appear on your desktop.



Once the V-Synth is connected, you can recover system files by operating your computer. (p. 86)

Recovering the System

1. Insert the V-Card CD-ROM into the CD-ROM drive of your computer (**NOT** V-Synth driver CD-ROM!).
2. Using your computer, copy the **SYRB1.BIN** file on the V-Card CD-ROM to the **SYRB1.BIN** file (overwriting it) within the VC-1.
 - * *Do not perform the following actions while "Access" (the access indicator) in the USB Storage screen is blinking. Doing so may cause your computer to freeze, and may also damage the files in the drive.*
 - Do not disconnect the USB cable
 - Do not remove the PC card while it is being accessed
 - Do not sleep, restart, or shut down your computer
 - Do not turn off the power of V-Synth.

Canceling the USB Connection

When recovery of the system data is finished, stop the USB connection to safely disconnect the USB cable and turn off the power to the V-Synth.

1. In the V-Synth's **USB Storage** screen, make sure that "**Access**" (the access indicator) is not blinking.
2. Perform the "Eject" operation on your computer.
 - 2-1.** Windows 98/Me/2000/XP:
In My Computer, right-click the "Removable Disk" icon and execute "Eject."
 - 2-2.** Macintosh:
Select the VC-1 drive icon on your desktop, and either choose "Eject" from the "Special" menu, or drag the icon into the trash. The drive icon will disappear from the desktop, and the USB connection will be cancelled.
3. Press **[EXIT]**. The USB Storage screen will close.




- * *If you press **[EXIT]** without performing the "Eject" operation on your computer, a WARNING window like the following will appear. Touch **<EXECUTE>** to close this window only if you are unable to perform the "Eject" operation on your computer.*



The VC-1's File Structure

As seen from your computer, the VC-1's file structure is as follows.

- You can use the computer to copy (back up) these files to the computer (e.g., the hard disk).
- Do not perform operations on your computer to erase (format) or rename these folders or files. If the VC-1 fails to operate correctly, use the CD-ROM included with the VC-1 to perform the VC-1 recovery. This will erase all the data that has been saved on the VC-1.




Exchanging MIDI Messages with Your Computer

What is the USB MIDI Driver?

The USB MIDI Driver is a software which passes data between the VC-1 and the application (sequencer software, UniQuest editor, etc.) that is running on the USB-connected computer.

The USB MIDI Driver sends data from the application to the VC-1, and passes data from the VC-1 to the application.



In order to use the VC-1 as a USB MIDI device from your computer, you must first install the USB MIDI driver. The USB MIDI driver is on the “V-Synth Driver CD-ROM.” (**NOT** VC-1 CD-ROM!)

In order to use USB in MIDI mode, you must install the driver from the V-Synth Driver CD-ROM into your computer (included the V-Synth package).

The correct driver and the installation procedure will depend on your system and on the other programs you are using. Be sure to read the Readme file on the CD-ROM before installation.

| OS | Folder |
|-----------------------------|--------------------------------|
| Windows XP/2000 | \Midi\Usb_xp2k\Readme_e.htm |
| Windows Me/98 | \Midi\Usb_me98\Readme_e.htm |
| Macintosh (OMS) | \OS_9\English\Readme_OMS-E.HTM |
| Macintosh (FreeMIDI) | \OS_9\English\Readme_FM-E.HTM |
| Mac OS X | \OS_X\Readme-E.HTM |

* The most recent version of the USB-MIDI driver can be downloaded from the Roland Website;
<http://www.roland.com/products/en/VC-1/>. This URL may change without notice.




| | |
|--|------------|
| Panel Description..... | 90 |
| VariOS Menu..... | 93 |
| Try Out the Sounds..... | 94 |
| Turning On the Power..... | 94 |
| Selecting Patches and Playing Sounds..... | 95 |
| Determining the MIDI Keyboard Routings..... | 96 |
| Setting the MIDI Receive Channel..... | 97 |
| Selecting Patches with the VALUE knob..... | 97 |
| Applying Effects to the Sound..... | 98 |
| Applying Effects by Turning Knobs | 98 |
| How to Make the Patch Factors | 99 |
| Transferring Patches To and From the D-50/550 | 101 |
| Transferring Patches from the D-50 to the VC-1 | 101 |
| Transferring Patches from the VC-1 to the D-50/550..... | 104 |
| Overview of the VC-1 | 107 |
| Memory Structure..... | 107 |
| The Basic Concept of a Tone..... | 108 |
| Structure of Tone Parameters..... | 111 |
| Creating Patches..... | 113 |
| Naming a Patch | 113 |
| Saving Patches | 114 |
| Initializing Patch Settings | 115 |
| Reset to Default Factory Settings | 115 |
| Copying a Patch Bank | 116 |
| Settings for the Entire VC-1 | 117 |
| How to Make the System Function Settings | 117 |
| Saving the System Settings | 120 |
| Initializing the System Settings (Init) | 120 |
| Connecting to Your Computer via USB | 121 |
| Recovering the System from the CD-ROM | 121 |
| Exchanging MIDI Messages with Your Computer | 124 |

Panel Description

When using the VariOS with the **VC-1**, the actual functions of the VariOS's buttons and knobs may not correspond to the functions ascribed to these controls on the VariOS's panel. Here is a description of the names and functions in each section of the VariOS when it is used with the VC-1. Please read this material together with "Names of Things and What They Do" in the VariOS User Guide. Controls whose functions do not match what is shown on the panel are indicated with a **VC-1** mark.

Front Panel



1 PC CARD Slot

The **VC-1** can be inserted here.

2 C1/C2/C3 Knobs

| Display | Functions |
|---------------------|---|
| C1 (PITCH) | The volume balance of the Upper and the Lower Tone can be change. VC-1 |
| C2 (TIME) | This sets the volume of the reverb and direct sounds. VC-1 |
| C3 (FORMANT) | This sets the portamento time from one note to another. If Portamento Switch (p. 99) is set to OFF , C3 knob may have no effect. VC-1 |

3 Indicators

| Display | Functions |
|--------------|---|
| MIDI | Lights when a MIDI message is received. |
| TEMPO | This does NOT function for VC-1. VC-1 |
| PC | Lights when the MIDI mode of the VariOS is "PC" (p. 119). |
| USB | Lights when connected to a computer via USB. |

4 Display

Various information is shown here according to the operations you perform.

- * The explanations in this manual include illustrations that depict what should typically be shown by the display. Note, however, that your unit may incorporate a newer, enhanced version of the system (e.g., includes newer sounds), so what you actually see in the display may not always match what appears in the manual.

5 MENU Button

Accesses the various functions of the VariOS.

6 EXIT Button

Returns you to the previously displayed screen. Depending on the content of the menu, this button also functions as CANCEL.

7 CURSOR Buttons

Used to move the cursor.

8 VALUE Dial

Turn this dial to edit a value. Pressing the VALUE dial will function as ENTER (confirm). If you turn the VALUE dial while pressing it, the value will change in larger steps.

9 VOLUME Knob


Adjusts the overall volume that is output from the MAIN OUT jacks and the PHONES jack. By pressing the VOLUME knob you can audition (preview) the current sample.

10 PHONES Jack


You can connect a set of headphones to this jack. Use headphones with an impedance in the range of 32 – 600 ohms.

11 POWER Switch

Turns the power of the VariOS on/off (p. 94). The power is on when the switch is in the inward position, and off when the switch is in the outward position.



Rear Panel



1 AC Inlet

Connect the supplied power cord here.

2 Grounding Terminal

Depending on the circumstances of a particular setup, you may experience a discomforting sensation, or perceive that the surface feels gritty to the touch when you touch this device, microphones connected to it, or the metal portions of other objects. This is due to an infinitesimal electrical charge, which is absolutely harmless. However, if you are concerned about this, connect the ground terminal (see figure) with an external ground. When the unit is grounded, a slight hum may occur, depending on the particulars of your installation. If you are unsure of the connection method, contact the nearest Roland Service Center, or an authorized Roland distributor, as listed on the “Information” page.

Unsuitable places for connection:

- Water pipes (may result in shock or electrocution)
- Gas pipes (may result in fire or explosion)
- Telephone-line ground or lightning rod (may be dangerous in the event of lightning)

3 USB Connector

Use a USB cable to connect the VariOS to your computer.

4 MIDI Connectors

Connect external MIDI devices here (p. 101). Use MIDI cables (sold separately) to make connections.

| Display | Functions |
|---------|---|
| IN | Receives MIDI messages from an external device. |
| OUT | Transmits MIDI messages to an external device. |

5 DIGITAL OUT Connectors

These jacks output digital audio signals (stereo). Two types are provided; optical and coaxial. Output settings are made in the screen where you specify the effect signal flow. You can use both types of OUT connector simultaneously; they will output the same sound.

6 INPUT Jacks

Not used with the VC-1. **VC-1**

7 OUTPUT Jacks

Connect your amp or mixer to these jacks.

| Display | Functions |
|------------|---|
| DIRECT OUT | This does NOT function for VC-1. VC-1 |
| MAIN OUT | Output the audio signal in stereo. If you want to use monaural output, connect only the L jack. |

VariOS Menu

A number of Patch Factors and Parameters are shown in a Menu display. There are several Menu displays as shown below.

| Menu | Page |
|----------------------------|----------|
| Menu1 Patch Setting | |
| 1-1 Chase Switch | (p. 99) |
| 1-2 Portament Switch | (p. 99) |
| 1-3 Key Mode | (p. 99) |
| 1-4 Split Point | (p. 100) |
| 1-5 Partial Mute | (p. 100) |
| Menu2 MIDI Setting | |
| 2-1 MIDI CH | (p. 117) |
| 2-2 Control | (p. 117) |
| 2-3 Separate CH | (p. 118) |
| 2-4 ProgramChange Sw | (p. 118) |
| 2-5 Exclusive Sw | (p. 118) |
| 2-6 BankSelect Sw | (p. 118) |
| Menu3 Utility | |
| 3-1 Patch Name | (p. 113) |
| 3-2 Patch Initialize | (p. 115) |
| 3-3 Bank Copy | (p. 116) |
| 3-4 Bank Dump | (p. 104) |
| 3-5 Factory Reset | (p. 115) |
| Menu4 System | |
| 4-1 Master Tune | (p. 119) |
| 4-2 Sound Character | (p. 119) |
| 4-3 MIDI Mode | (p. 119) |
| 4-4 C1/C2/C3 Knob | (p. 119) |
| 4-5 System Save | (p. 120) |
| 4-6 System Initialize | (p. 120) |
| Menu5 Patch Write | (p. 114) |
| Menu6 Bank Save | (p. 104) |

Try Out the Sounds

Turning On the Power

To prevent malfunction and/or damage to speakers or other devices, always turn down the volume, and turn off the power on all devices before making any connections.

1. Before hooking anything up, make sure that the power on all of your gear is turned OFF.




2. Connect the VariOS to your amp/speaker system.

3. After correctly inserting the VC-1 into the PC card slot in the VariOS's front panel, switch ON the POWER switch.

- * Carefully insert the PC card all the way in – until it is firmly in place.
- * This unit is equipped with a protection circuit. A brief interval (a few seconds) after power up is required before the unit will operate normally.
- * Always make sure to have the volume level turned down before switching on power. Even with the volume all the way down, you may still hear some sound when the power is switched on, but this is normal, and does not indicate a malfunction.
- * Never insert or pull out while the VC-1 (VariOS) is turned on.


4. Turn on the power for any connected amplifiers or speakers.

5. Wait for the VC-1 to start up. When it has started up normally, a screen like the following will appear. The display shows the selected Patch.



Selecting Patches and Playing Sounds

The VC-1 comes with a wide range of onboard sounds, including single tones called **patches**.
A Patch is represented by a **Patch Bank** (Pre1 – 6, Int1 – 8), a **Bank** (1 – 8) and a **Number** (1 – 8).



| Patch Banks | Included patches | Overwrite | Remarks |
|-------------|------------------|-----------|---------------------------------|
| Pre1 | D-50 | No | Original D-50 preset patches |
| Pre2 | VC-1 | No | Newly added patches VC-1 |
| Pre3 | PN-D50-01 | No | D-50/D-550 sound library |
| Pre4 | PN-D50-02 | No | D-50/D-550 sound library |
| Pre5 | PN-D50-03 | No | D-50/D-550 sound library |
| Pre6 | PN-D50-04 | No | D-50/D-550 sound library |
| Int1 | same as Pre1 | Yes | - |
| Int2 | same as Pre2 | Yes | - |
| Int3 | same as Pre3 | Yes | - |
| Int4 | same as Pre4 | Yes | - |
| Int5 | same as Pre5 | Yes | - |
| Int6 | same as Pre6 | Yes | - |
| Int7 | (blank) | Yes | - |
| Int8 | (blank) | Yes | - |

Use the following procedure.

Determining the MIDI Keyboard Routings. (p. 96)



Setting the MIDI Receive Channel (p. 97)



Selecting Patches with the VALUE knob (p. 97)

Determining the MIDI Keyboard Routings.

1.

Press the **[MENU]** button so it's lighted, and access the **MENU** screen.
2.

Turn the **[VALUE]** knob to select "**MIDI Settings**," and press the **[VALUE]** knob.
3.

Turn the **[VALUE]** knob to select "**MIDI Mode**," and press the **[VALUE]** knob.
4.

Turn the **[VALUE]** knob to select a routing.



MIDI Mode

Selects the MIDI keyboard routing. Normally, you should set the MIDI mode to "PC."

Value: PC, Internal

| Display | Description | Routing |
|----------|--|---------|
| PC | When using a USB connection, the MIDI connectors on the rear panel of the VariOS will function as a USB MIDI interface (Roland VariOS External MIDI). | |
| | When USB is not connected (and when your computer is not powered up), the MIDI connectors on the rear panel of the VariOS are connected directly to the sound generator section. | |
| Internal | The MIDI connectors of the rear panel of the VariOS are connected directly to the sound generator section. | |

5. Press the **[MENU]** button to turn off its illumination.

* The “**PC indicator**” on the front panel of the VariOS shows the current MIDI Mode status. When this is lit, “**PC**” mode is selected. When dark, “**Internal**” mode is selected.

Setting the MIDI Receive Channel

The VariOS will receive **Note-on** and **Control change** messages on the channel you specify here. If you’ve connected a MIDI keyboard, set this channel to match the transmit channel of your MIDI keyboard.

1. Press the **[MENU]** button so it’s lighted, and access the **MENU** screen.
2. Turn the **[VALUE]** knob to select “**MIDI Setting**,” and press the **[VALUE]** knob.
3. Turn the **[VALUE]** knob to select “**MIDI CH**,” and press the **[VALUE]** knob.
4. Turn the **[VALUE]** knob to specify the receive channel (1 – 16).

Menu2
MIDI Setting

Menu2-1
MIDI CH

MIDI CH

Sets the **Basic Channel** (MIDI channel on which the VC-1 receives and transmits messages).

Value: 1 – 16


MIDI CH

1

5. Press the **[MENU]** button to turn off its illumination.

Selecting Patches with the VALUE knob


1. Make sure the **PATCH TOP** screen is displayed. If the **PATCH TOP** screen is not displayed, press **[EXIT]** several times until the **PATCH TOP** screen appears.
2. Play the keyboard to hear what the selected patch sounds like. To change to a different patch, turn the **[VALUE]** knob.
 - At this time you can switch more rapidly by holding down **[VALUE]** knob while you perform these operations.
 - Use the **[◀]** or **[▶]** buttons to move the cursor to the value you want to edit. (Patch Bank **↔** Number)



Applying Effects to the Sound

The performance controlling functions (we call them **factors** in this manual) in each Patch can be edited by taking the following procedure.

A patch consists of several **Factors** as show below.



Applying Effects by Turning Knobs


By turning the **[C1]**, **[C2]** and **[C3]** knobs while you play, you can control the various functions that've been assigned to them.


- * *How each Control Function actually affects the sound differs depending on the individual patch. Some Patches may not be affected at all.*

| Display | Description |
|---------------------|--|
| C1 (PITCH) | The volume balance of the Upper and the Lower Tone can be change. VC-1 |
| C2 (TIME) | This sets the volume of the reverb and direct sounds. VC-1 |
| C3 (FORMANT) | This sets the portamento time from one note to another. If Portament Switch (p. 99) is set to OFF , C3 knob may have no effect. VC-1 |

How to Make the Patch Factors

The Display shows several Factors at a time. If necessary, Scroll up or down the Display to find the Factor to be edited.

1. Press the **[MENU]** button so it's lighted, and access the **MENU** screen.
2. Turn the **[VALUE]** knob to select "**Patch Settings**," and press the **[VALUE]** knob.
3. Turn the **[VALUE]** knob to select the factor that you want to edit, and press the **[VALUE]** knob.
4. Turn the **[VALUE]** knob to specify the value, then press **[EXIT]**.
5. Repeat steps 3 – 4 to set patch factors.
6. If you wish to save the changes you've made, perform the Save operation (p. 114). If you return to the **PATCH TOP** screen without saving, the **PATCH TOP** screen will indicate <  >, reminding you that the patch settings have been modified.

* If you turn off the power or select a different patch while the display indicates <  >," your edited patch will be lost.



Menu1
Patch Setting

Chase Switch

Switches the Chase function on and off. The Chase Play function makes it possible to output the Lower Tone slightly later than the Upper Tone, which is actually played on the keyboard. This function, however, is only available in **Dual** or **Whole** Key Mode.

Value: Off, On



Chase Switch
OFF

Portament Switch

Switches the Portamento function on and off. Portamento is a slide from one pitch to another, and is often used for violin performance.

Value: Off, On



Portament Switch
OFF

Key Mode

Key Mode refers to the Upper and Lower Tones are played on the keyboard.

Value: Whole, Dual, Split, Separate, Whole-S, Dual-S, Split-US, Split-LS, Separate-S



Key Mode
Whole


| Display | Description |
|--------------------------------|---|
| Whole | Upper Tone can be played in 16 voice polyphony |
| Dual | Both Upper and Lower Tones are played by each key in 8 voices polyphony. |
| Split | The Split mode divides the keyboard into upper and lower sections, where two different Tones can be played in 8 voices polyphony. That is, the VC-1 works like two 8 voice synthesizers. The Split Point (where the keyboard is divided into two sections) is shown next to the Key Mode indication. |
| Separate | This mode is effective when an external MIDI device is controlling the VC-1. (“ MIDI Implementation ” (p. 140)) |
| Whole-S (Whole Solo) | The Upper Tone is monophonic. |
| Dual-S (Dual Solo) | Both Upper and Lower Tones are monophonic. |
| Split-US (Split Upper Solo) | The Upper Tone is monophonic, and the Lower Tone is 8 voices polyphonic. |
| Split-LS (Split Lower Solo) | The Lower Tone is monophonic, and the Upper Tone is 8 voices polyphonic. |
| Separate-S (Separate Solo) | This mode is effective when an external a MIDI device is controlling the VC-1. (“ MIDI Implementation ” (p. 140)) |

* **Poly Mode** or **Mono Mode** is another element that determines how to output the UPPER and LOWER Tones.

Split Point

The Split Point can be changed as follows.

Value: C2 – C7



Partial Mute

When editing a Partial parameter, nay Partial sound can be muted.

Value (left side): L1, L2, U1, U2

Value (right side): Off, On



Transferring Patches To and From the D-50/550

You can use MIDI to transmit patch data (64 patches) saved on your D-50 and receive the data with the VC-1 (VariOS). This procedure is known as “**bulk load**.” This is an easy and convenient way to take your own original patches (64 patches) created with the D-50 and use them with the VC-1.

Conversely, you can also send patch data edited using the VC-1 via MIDI to the D-50/550. This procedure is called “**bulk dump**.”


* Read this material together with the D-50/550 Owner's Manual.

Transferring Patches from the D-50 to the VC-1

- Patches (64 patches) bulk loaded from the D-50 to the VC-1 are temporarily transferred to the **patch bank that includes the current patch**.

| Currently Patch Sample | → | Destination Patch Bank Sample |
|------------------------|---|-------------------------------|
| I1-11:Fantasia | → | Int1-11 – Int1-88 |
| I6-88:Big Wave | → | Int6-11 – Int6-88 |

- The patches (64 patches) originally residing in the bulk load destination will appear to have been overwritten, but actually nothing will have been lost. The patches are restored when you turn the power off, then on again.
- The transferred patch data (64 patches) will be lost if you turn off the power. Be sure to save the data (“**Saving Transferred Patches with the VC-1**” (p. 104)).
- Patches saved to memory cards (M-256D) used with the D-50/550 cannot be transferred directly from these memory cards to the VC-1. First, transfer the patch data to the D-50/550 from the memory card (M-256D), then transfer the patch data from the D-50/550 to the VC-1.



Use the following procedure.

Transfer the patch from the memory card to the D-50/550 (p. 102)




Transferring Patches from the D-50/550 to the VC-1 (p. 103)



Saving Transferred Patches with the VC-1 (p. 104)


Transfer the patch from the memory card to the D-50/550

Using the D-50



1. Insert the Memory Card (M-256D) into the D-50 Card Slot.
2. Turn the Memory Protect of the D-50 to **OFF**.
 - 2-1.** Press the **[TUNE/FUNCTION]** button.
 - 2-2.** Select “Protect” with the **Selector button** and turn it **OFF** with the joystick.
3. Press the **[DATA TRANSFER]** button.
4. Select “(Card -> Int)” with the corresponding **Selector button**.
5. Press **[ENTER]** button. When the data transfer is completed, the display shows “Complete.”
6. Return the Memory Protect of the D-50 to **On**.
 - 6-1.** Press the **[TUNE/FUNCTION]** button.
 - 6-2.** Select “Protect” with the **Selector button** and turn it **ON** with the joystick.

Using the D-550




1. Insert the Memory Card (M-256D) into the D-550 Card Slot.
2. Press the **[DATA TRANSFER]** button.
3. Using the [◀] or [▶], select “(Card -> Int).”
4. Press the **[ENTER]** button.
5. Press the **[WRITE]** button to turn the Memory Protect **OFF** temporarily.
6. Press the **[ENTER]** button again. When the data transfer is completed, the display shows “Complete.”

Transferring Patches from the D-50/550 to the VC-1


- * You cannot bulk load data when a patch in the Preset Banks (Pre1 – Pre6) is selected.
- * The VC-1 display does not change immediately following the bulk load. This is due to the fact that the work area is the bulk load destination (p. 107). You can confirm the outcome of the transfer by switching patches with the **VALUE dial**.

Using the D-50



1. Use a MIDI cable to connect the D-50's **MIDI OUT** connector to the VariOS's **MIDI IN** connector.
2. Set the D-50 and VariOS to the same MIDI channel (the basic channel; p. 117).
3. Turn the **MIDI Mode** of the VariOS to **Internal** (p. 119)
4. Press the D-50's **[DATA TRANSFER]** button.
5. While pressing the D-50's **[DATA TRANSFER]** button, specify "**B.Dump**" with **Selector button**.
6. Press the D-50's **[ENTER]** button to begin the bulk dump. When the data transfer is completed, the D-50's display shows "**Complete.**"
7. Press the **[EXIT]** button on the D-50 to return to the play mode.

Using the D-550



1. Use a MIDI cable to connect the D-550's **MIDI OUT** connector to the VariOS's **MIDI IN** connector.
2. Set the D-550 and VariOS to the same MIDI channel (the basic channel; p. 117).
3. Turn the **MIDI Mode** of the VariOS to **Internal** (p. 119)
4. Press the D-550's **[DATA TRANS]** button.
5. Select "**(B.Dump)**" with the D-550's **[◀]** or **[▶]** button.
6. Hold down the D-550's **[DATA TRANS]** button and press the D-550's **[ENTER]** button to begin the bulk dump. When the data transfer is completed, the D-550's display shows "**Complete.**"
7. Press the **[EXIT]** button on the D-550 to return to the play mode.

Saving Transferred Patches with the VC-1

The transferred patch data (64 patches) will be lost if you turn off the power. Be sure to save the data.


1. Press the **[MENU]** button so it's lighted, and access the **MENU** screen.
2. Turn the **[VALUE]** knob to select "**Bank Save**," and press the **[VALUE]** knob.
3. The display will ask "Are You Sure?" Press **[VALUE]** knob once again to carry out the bank save operation.
When the operation is completed, the display will indicate "**Completed!**"

Menu6
Bank Save

Bank Save
OK? (Push)

Transferring Patches from the VC-1 to the D-50/550

Using the D-50



1. Use a MIDI cable to connect the VariOS's **MIDI OUT** connector to the D-50's **MIDI IN** connector.
2. Set the D-50 and VariOS to the same MIDI channel (the basic channel; p. 117).
3. Turn the **MIDI Mode** of the VariOS to **Internal** (p. 119).
4. Turn the **Memory Protect** of the D-50 to **OFF**.
 - 4-1. Press the **[TUNE/FUNCTION]** button.
 - 4-2. Select "**Protect**" with the **Selector button** and turn it **OFF** with the joystick.
5. Enable reception of bulk load data on the D-50.
 - 5-1. Press the D-50's **[DATA TRANSFER]** button.
 - 5-2. While pressing the D-50's **[DATA TRANSFER]** button, specify **(B.Load)** with the **Selector button**.
 - 5-3. Press the D-50's **ENTER]** button.
6. Turn the **Exclusive Sw** of the VariOS to **On**.
 - 6-1. Press the VariOS's **[MENU]** button so it's lighted, and access the **MENU** screen.
 - 6-2. Turn the VariOS's **[VALUE]** knob to select "**MIDI Setting**," and press the **[VALUE]** knob.

Menu2
MIDI Setting

6-3. Turn the VariOS's **[VALUE]** knob to select "**Exclusive Sw,**" and press the **[VALUE]** knob.

6-4. Turn the VariOS's **[VALUE]** knob to specify **On**.

Exclusive Sw
On

7. Press the VariOS's **[MENU]** button so it's lighted, and access the **MENU** screen.

Menu3
Utility

8. Turn the VariOS's **[VALUE]** knob to select "**Utility,**" and press the **[VALUE]** knob.

9. Turn the VariOS's **[VALUE]** knob to select "**Bank Dump,**" and press the **[VALUE]** knob.

Menu3-4
Bank Dump

10. Turn the VariOS's **[VALUE]** knob to specify the save-source Patch Bank.

Select Bank

Selects the Patch Bank in the VC-1 with the patch data to transfer to the D-50.

Value: I1 – I8, P1 – P6

Select Bank
I1


11. Press the **[VALUE]** knob, and the display will ask "Are You Sure?" Press **[VALUE]** knob once again to carry out the bank dump operation.

Are You Sure?
DUMP OK? (Push)

12. When the data transfer is completed, the D-50's display shows "Complete."

13. Press the **[EXIT]** button on the D-50 to return to the play mode.

Using the D-550



1. Use a MIDI cable to connect the VariOS's **MIDI OUT** connector to the D-550's **MIDI IN** connector.
2. Set the D-550 and VariOS to the same MIDI channel (the basic channel; p. 117).
3. Turn the **MIDI Mode** of the VariOS to **Internal** (p. 119).

4. Turn the Memory Protect of the D-550 to **OFF**.
 - 4-1. Press the [TUNE] button.
 - 4-2. Select "Protect" with the [◀] or [▶] buttons, and turn it **OFF** with the [VALUE].
5. Enable reception of bulk load data on the D-550.
 - 5-1. Press the D-550's [DATA TRANS] button.
 - 5-2. Select "(B.Load)" with the D-550's [◀] or [▶] buttons, then press the [ENTER] button while holding the [DATA TRANS] button.
 - 5-3. Press the [ENTER] button again.
6. Turn the **Exclusive Sw** of the VariOS to **On**.
 - 6-1. Press the VariOS's [MENU] button so it's lighted, and access the **MENU** screen.
 - 6-2. Turn the VariOS's [VALUE] knob to select "MIDI Setting," and press the [VALUE] knob.
 - 6-3. Turn the VariOS's [VALUE] knob to select "Exclusive Sw," and press the [VALUE] knob.
 - 6-4. Turn the VariOS's [VALUE] knob to select **On**.
7. Press the VariOS's [MENU] button so it's lighted, and access the **MENU** screen.
8. Turn the VariOS's [VALUE] knob to select "Utility," and press the [VALUE] knob.
9. Turn the VariOS's [VALUE] knob to select "Bank Dump," and press the [VALUE] knob.
10. Turn the VariOS's [VALUE] knob to specify the save-source Patch Bank.



Menu2
MIDI Setting



Exclusive Sw
On



Menu3
Utility



Menu3-4
Bank Dump

Select Bank

Selects the Patch Bank in the VC-1 with the patch data to transfer to the D-550.

Value: I1 – I8, P1 – P6



Select Bank
I1


11. Press the [VALUE] knob, and the display will ask "Are You Sure?" Press [VALUE] knob once again to carry out the bank dump operation.
12. When the data transfer is completed, the D-550's display shows "Complete."
13. Press the [EXIT] button on the D-550 to return to the play mode.



Are You Sure?
DUMP OK? (Push)

Overview of the VC-1

Memory Structure



1 Work Area

When the VC-1 is inserted in the VariOS's PC CARD slot, the system program and patch data is loaded from the VC-1 into the VariOS. The section where the system and patch data is loaded is called the **Work Area**. Content loaded to the Work Area is cleared when the VariOS's power is turned off. For this reason, if you remove the VC-1 from the VariOS and switch the power off, then on again, the VariOS reverts to its ordinary state.

In addition, banks (containing data for 64 patches) bulk dumped from an original D-50 (or other MIDI device) are also stored temporarily in the Work Area. Bulk dumped data is cleared if the power is simply turned off, so be sure to save the data to the VC-1 (p. 114).


2 Temporary Area

Patch data selected for performance is further taken from the Work Area and placed in memory called the **Temporary Area**. Editing of tones and factors is performed on patches in this Temporary Area. Edited patch data is lost if the power is simply turned off, so be sure to save these to the VC-1 (p. 114).

The Basic Concept of a Tone

Throughout the process of programming the D-50, the operation remains simple and logical.

You can think of the D-50 having powerful synthesizers built in. Each of these hypothetical synthesizers could behave like a convention analog synthesizer, or a PCM sampled synthesizer. Any combination of two synthesizers can achieve some remarkable cross-modulation effects.




1 Partial

The VC-1 (D-50) appears to have four powerful synthesizers built in. Each of these hypothetical synthesizer could behave like a conventional **analog synthesizer**, or a **PCM sampled synthesizer**. Consequently, They are referred to as **Partials**, since they are far more than just a pure synthesizer. These Partials are combined in pairs to form a **TONE**. A Tone could either be a mix of the two Partials, or they could take advantage of the LA version of cross modulation.


Synthesizer sound generator

A Synthesizer sound generator works like a conventional analog type synthesizer with an oscillator, a filter, an amplifier and two ENV's.



PCM sound generator



A PCM sound generator provides 128 different PCM sampled sounds (= waveform).



2 Structure

Structure, which is one of the Common Parameters, determines which two of the hypothetical synthesizers (a **synthesizer sound generator** or a **PCM sound generator**) are to be used as Partial 1 and Partial 2.

- These two Partial sounds (Partial 1 and Partial 2) can simply be mixed as show below. By mixing two Partials, fatter sounds can be obtained. This is effective for making strings or organ type sounds.
- Partial 1 can be mixed with the ring-modulated sound of Partials 1 and 2. (“**Ring Modulator**” (p. 110))




3 Tone

A **Tone** consists of two **Partials** (Partials 1 and 2) and a **Common** block. Some Common parameters apply to both Partials (Partial 1 and 2) . “**Structure**” is one of the Common parameters. It decides which of the two sound generators is used for each Partial. Other Common parameters are an ENV for pitch, three LFO modules, equalizer, chorus, etc.


Ring Modulator

The **Ring Modulator** multiplies two sounds, creating an unusual and metallic sound that contains complicated harmonics. For instance, two waveforms (① and ②) are multiplied and waveform ③ is created. This is effective for making metallic sounds.




4 Patch

During live performance, you can easily select a **Patch**, which is the combination of two Tones (Upper and Lower), together with programmed E.Q., chorus and reverb. These other parameters are referred to as **Factor**.



Structure of Tone Parameters

Depending on which **generators** are selected in the **Partial Block**, greatly different Tone Parameters will be used. Some Tone Parameters used for the Synthesizer sound generators are irrelevant to the PCM generator. In a Structure with **Ring modulation**, some parameters of Partial 2 are automatically set to those of Partial 1.



WG (Wave Generator)

In the WG (Wave Generator), the pitch and waveform are controlled.

1 Pitch

The basic pitch of a Partial (sound generator) can be set here. The pitch is a Common parameter, and is therefore controlled by **7 P-ENV** and **10 LFO-1**.

2 Waveform, PCM Wave Number

This selects the waveform of the sound source. When a synthesizer sound generator is selected, the waveform can be controlled by the **3 Pulse Width** controls.

3 Pulse Width

This changes the waveform of the sound source. The pulse width is controlled by any **LFO** (= Common parameter).

TVF (Time Variant Filter)

This filter passes lower frequency harmonics and cuts off the higher ones. By changing the cutoff point and the resonance, the waveform changes.

4 Cutoff Frequency

This sets the cutoff point. The cutoff point can be controlled by **8 TVF ENV** and any **LFO** (= Common parameter).

5 Resonance

This emphasizes the cut off point, making more unusual or electronic sounds.

TVA (Time Variant Amplifier)

This controls the volume of the Partial.

6 Level

This determines the volume of the sound. When a synthesizer sound generators used, the level can be controlled with the **9 TVF ENV** and **LFO** (Common Parameter) . When a PCM sound generator is used, the **9 TVA ENV** controls the level.

ENV (Envelope Generator)

This generates a control signal (envelope curve) which controls the pitch, timbre and volume of each Partial (sound generator).

7 P-ENV

This is the ENV which controls pitch. It can be set for two selected Partial at once.

8 TVF ENV

This ENV controls the cutoff point, and can be set for each Partial separately.

9 TVA ENV

This ENV controls the volume level. This is can be set for each Partial separately.

LFO (Low Frequency)

This oscillator generates low frequencies only.

Any of the three LFO's can be used for the two partials, Vibrato, PWM growl or tremolo effects can be obtained using these LFO's

* A different LFO can be used for each section or a **Partial Parameters**.

10 LFO-1

This can control **1 Pitch**, **3 Pulse Width**, **4 Cutoff Frequency** or **6 Level**.

11 LFO-2

This can control **3 Pulse Width**, **4 Cutoff Frequency** or **6 Level**.

12 LFO-3

This can control **3 Pulse Width**, **4 Cutoff Frequency** or **6 Level**.

Creating Patches

When you edit the settings of a patch, the **PATCH TOP** screen displays <⚡> to remind you that the patch's settings have been modified. If <⚡> is displayed, you will lose your edited patch settings if you switch to another patch or turn off the power. If you want to keep a patch whose settings you have edited, assign a name to the patch and then perform the **Save operation**.

Naming a Patch

Before you save the patch, here's how to give it a new name. Editing Patch or Tone names is called **Naming**.

- A Patch name can have up to 16 letters.
1. Make sure that the patch that you want to name is selected.
 2. Press the **[MENU]** button so it's lighted, and access the **MENU** screen.
 3. Turn the **[VALUE]** knob to select "**Utility**," and press the **[VALUE]** knob.
 4. Turn the **[VALUE]** knob to select "**Patch Name**," and press the **[VALUE]** knob.
 5. Use the **[◀]** or **[▶]** buttons to move the cursor to the location where you want to enter a character.
 6. Turn the **[VALUE]** knob to specify the desired character. By turning the **[VALUE]** knob while pressing it, you can conveniently shift between spaces, uppercase characters, lowercase characters, numerals, and symbols.
 7. Press the **[VALUE]** knob, and the display will ask "Are You Sure?" Press the **[VALUE]** knob once again to finalize the name.



If you press the **[EXIT]** button you're returned to the name entry screen.

In any of the name entry screens, you can press the **[EXIT]** button to discard the currently edited name and return to the previous screen.

Saving Patches

Changes you make to sound settings are temporary, and will be lost if you turn off the power or select another sound. If you keep the modified sound, you must save it in the VC-1 (PATCH WRITE).

When you perform the save procedure, the data that previously occupied the save destination will be lost. However, the factory setting data can be recovered by performing the Factory Reset. (“**Reset to Default Factory Settings**” (p. 115))

* *Never insert or remove the VC-1 while the VariOS is turned on. Patches cannot be saved to PC cards other than the VC-1.*

1. Make sure that the patch that you want to save is selected.
2. Press the [MENU] button so it's lighted, and access the MENU screen.
3. Turn the [VALUE] knob to select “Patch Write,” and press the [VALUE] knob.
4. Turn the [VALUE] knob to specify the save-destination patch.



5. Press the [VALUE] knob, and the display will ask “Are You Sure?” Press [VALUE] knob once again to carry out the patch save operation.



Initializing Patch Settings

Initialize means to return the settings of the currently selected patch to a standard set of values. The Initialize operation will affect only the currently selected patch in temporary area; the patches that are stored in internal memory and work area will not be affected. If you wish to restore all of the VC-1's settings to their factory values, perform a **Factory Reset** (p. 115).

1. Press the [MENU] button so it's lighted, and access the **MENU** screen.
2. Turn the [VALUE] knob to select "**Utility**," and press the [VALUE] knob.
3. Turn the [VALUE] knob to select "**Patch Initialize**," and press the [VALUE] knob.
4. The display will ask "OK?" Press [VALUE] knob once again to carry out the Patch initialize operation.

```
Menu3
Utility
```

```
Menu3-2
Patch Initialize
```

```
Initialize OK?
(Push)
```

Reset to Default Factory Settings

This restores all data in the VC-1 to the factory-set condition (Factory Reset). If there is important data you've created that's stored in the VC-1, all such data is discarded when a Factory Reset is performed. If you want to keep the existing data, save it as describe below.

- Transmit it to an original D-50 (or an external MIDI device) and save it (p. 104).
1. Press the [MENU] button so it's lighted, and access the **MENU** screen.
 2. Turn the [VALUE] knob to select "**Utility**," and press the [VALUE] knob.
 3. Turn the [VALUE] knob to select "**Factory Reset**," and press the [VALUE] knob.
 4. Press [VALUE] knob once again to carry out the factory reset operation. When the operation is completed, the display will indicate "**Completed!**"

```
Menu3
Utility
```

```
Menu3-5
Factory Reset
```

```
Factory Reset
OK? (Push)
```

Copying a Patch Bank

This procedure transfers the patch data saved in one of the VC-1's Patch banks (Int1 – Int8 or Pre1 – Pre6) to another (Int1 – Int8).

1. Press the **[MENU]** button so it's lighted, and access the **MENU** screen.
2. Turn the **[VALUE]** knob to select "**Utility**," and press the **[VALUE]** knob.
3. Turn the **[VALUE]** knob to select "**Bank Copy**," and press the **[VALUE]** knob.
4. Turn the VariOS's **[VALUE]** knob to specify the copy-source Patch Bank, and press the **[VALUE]** knob.



```
Menu3
Utility
```



```
Menu3-3
Bank Copy
```

Source Bank

Specify the copy-source Patch Bank
Value: I1 – I8, P1 – P6

5. Turn the **[VALUE]** knob to specify the copy-destination Patch Bank, and press the **[VALUE]** knob.



```
Select
Source Bank    I1
```

Destination Bank

Specify the copy-destination Patch Bank
Value: I1 – I8



```
Select
Dest. Bank     I5
```

6. Press the **[VALUE]** knob, and the display will ask "Are You Sure?" Press **[VALUE]** knob once again to carry out the bank copy operation.
 When the operation is completed, the display will indicate "**Completed!**"



```
Are You Sure?
Copy OK?  (Push)
```

Settings for the Entire VC-1

Settings that affect the entire operating environment of the VC-1, such as tuning and MIDI message reception, are referred to as **System functions**. This section explains how to make settings for the System functions and describes the functions of the different System parameters.

How to Make the System Function Settings

1. Press the [MENU] button so it's lighted, and access the **MENU** screen.
 2. Turn the [VALUE] knob to select "MIDI Settings" or "System," and press the [VALUE] knob.
 3. Turn the [VALUE] knob to select the factor that you want to edit, and press the [VALUE] knob.
 4. Turn the [VALUE] knob to specify the value.
 5. Repeat steps 2 – 4 to set system settings.
 6. After you have edited the settings of the System function, perform the Save operation (p. 120).
- * Changes you make to the System function settings are only temporary – they will be discarded as soon as the power is turned off. If you want to keep any changes you've made in the system settings, you must save them in VC-1.



Menu2
MIDI Setting



Menu4
System

MIDI

MIDI CH (MIDI Channel)

Sets the **Basic Channel** (MIDI channel on which the VC-1 receives and transmits messages).

Value: 1 – 16



MIDI CH
1

Control

Determines how to receive messages from an external MIDI device. ("Key Mode Alteration" (p. 126))

Value: Basic CH, Global CH, Mode Message OFF



Control
Basic CH

| Display | Function |
|--|--|
| Basic CH (Basic Channel mode) | When the VC-1 is being controlled in Mono mode, it receives the Voice messages (except for Note Event, Pitch Bender) on the Basic Channel from the external device. |
| Global CH (Global Channel mode) | When the VC-1 is being controlled in Mono mode, by an external device that has a Global Channel (one number smaller than the basic channel) it can receive all the Voice messages (except for Note Event, Pitch Bender) On the Global Channel. |
| Mode Message OFF (Mode Message OFF mode) | In this mode, the VC-1 does NOT receive the Mode messages from the external MIDI device, but is assigned to the Key mode as set on the VC-1. |

Separate CH (Receive Channel in Separate Mode)

When **SEP** (Separate Mode) or **SEP-S** (Separate Solo Mode) is selected, the Upper and Lower Tones can be controlled on different channels. The Lower Tone is controlled by the basic channel, and the Upper Tone is controlled by the receive channel set here.

Value: 1 – 16

Separate CH

2

ProgramChange Sw (Program Change Switch)

To receive or transmit Program Change messages, set this to **On**. Program Change messages are transmitted only when a Patch is selected by operating the VariOS's panel buttons, or when the Program Change number to be transmitted is altered also on the VariOS's panel. IN other words, Program Change messages are not transmitted by patch selection with the Program Change messages sent from an external MIDI device.

Value: OFF, ON

ProgramChange Sw
Off

Exclusive Sw (Exclusive Switch)

To receive or transmit Exclusive messages (Roland ID Number only), set this to **On**, **P-Dump** or **TxEit**.

Value: OFF, ON, P-Dump, Tx Edit

Exclusive Sw
Off

| Display | Function |
|---------------|--|
| On | Normally. |
| P-Dump | The patch data that you select is transmitted. |
| TxEIT | The parameter data that you edited is transmitted. |

- * When set to **P-Dump**, the Patch you select is transmitted to an external device. However, it cannot be transmitted by Patch Shift with the pedal switch, or by patch selection with the Program Change messages sent from an external device.

BankSelect Sw (Bank Select Switch)

To receive or transmit Bank Select messages, set this to **On**.

Value: OFF, ON

BankSelect Sw
Off

System

Master Tune

Adjusts the overall tuning of the VC-1. The display shows the frequency of the A4 note (center A).

Value: 427 – 452 Hz

Master Tune
440Hz

Sound Character

Sets whether the output characteristics of the sound are the same as those of the D-50 or the VariOS.

Value: D-50, VariOS

Sound Character
D-50

MIDI Mode

Selects the MIDI keyboard routing. Normally, you should set the MIDI mode to "PC."

Value: PC, Internal

MIDI Mode
PC

| Display | Description |
|----------|--|
| PC | When using a USB connection, the MIDI connectors on the rear panel of the VariOS will function as a USB MIDI interface (Roland VariOS External MIDI). |
| | When USB is not connected (and when your computer is not powered up), the MIDI connectors on the rear panel of the VariOS are connected directly to the sound generator section. |
| Internal | The MIDI connectors of the rear panel of the VariOS are connected directly to the sound generator section. |

C1/C2/C3 Knob (Knob Switch) **VC-1**

Enables or disables control of the C1/C2/C3 knobs.

C1/C2/C3 Knob
Enable

Saving the System Settings

Changes you make to the System function settings are only temporary – they will be discarded as soon as the power is turned off. If you want to keep any changes you’ve made in the system settings, you must save them in the VC-1. (System Save)

1. Press the **[MENU]** button so it’s lighted, and access the **MENU** screen.
2. Turn the **[VALUE]** knob to select “**System**,” and press the **[VALUE]** knob.
3. Turn the **[VALUE]** knob to select “**System Save**,” and press the **[VALUE]** knob.
4. The display will ask “Are You Sure?” Press **[VALUE]** knob once again to carry out the system save operation.



```
Menu4
System
```



```
Menu4-5
System Save
```




```
System Save
OK?          (Push)
```

Initializing the System Settings (Init)

The current settings of the system functions can be restored to a set of standard settings, or to the factory settings. (System Initialize)


1. Press the **[MENU]** button so it’s lighted, and access the **MENU** screen.
2. Turn the **[VALUE]** knob to select “**System**,” and press the **[VALUE]** knob.
3. Turn the **[VALUE]** knob to select “**SystemInitialize**,” and press the **[VALUE]** knob.
4. The display will ask “Are You Sure?” Press **[VALUE]** knob once again to carry out the system initialize operation.
5. If you want the factory settings to be in effect the next time the VC-1 (VariOS) is powered up, you must save system.



```
Menu4
System
```



```
Menu4-6
SystemInitialize
```



```
SystemInitialize
OK?          (Push)
```


Connecting to Your Computer via USB

Recovering the System from the CD-ROM

If while running the VC-1 from a computer you happen to delete (format) any of the VC-1's folders or files or change file or folder names, the VC-1 will fail to operate correctly. In such instances, recover the VC-1's program from the CD-ROM included with the VC-1.

Use the following procedure.

Connecting the VariOS to Your Computer via USB (p. 121)



Recovering the System (p. 122)




Canceling the USB Connection (p. 122)

Connecting the VariOS to Your Computer via USB

* First, you must install the driver from the VariOS Driver CD-ROM into your computer (included the VariOS package).

1. Make sure that the power of the VC-1 is turned off.
2. Connect the VariOS and your computer using a USB cable, then start up your computer.
3. Hold down the [MENU], [◀] and [VALUE] knob, turn on the power of VariOS.
4. Insert the **VC-1** into the **PC CARD** slot of the VariOS.
5. The **VC-1** inserted in the VariOS will be recognized by your computer as a drive, and will be mounted as the drive name shown in the following table.



| OS | Drive Name |
|-----------------------|----------------|
| Windows 98, Me, 2000 | Removable Disk |
| Windows XP, Macintosh | VC-1 |

Once the VariOS is connected, you can recover system files by operating your computer. (p. 122)

Recovering the System

1. Insert the V-Card CD-ROM into the CD-ROM drive of your computer (**NOT** VariOS driver CD-ROM!).
2. Using your computer, copy the **VPI-01 for VariOS.BIN** file on the V-Card CD-ROM to the **VPI-01 for VariOS.BIN** file (overwriting it) within the VC-1.

Canceling the USB Connection

When recovery of the system data is finished, stop the USB connection to safely disconnect the USB cable and turn off the power to the VariOS.

1. Perform the “Eject” operation on your computer.
 - 1-1. In the task tray, double-click the eject icon. Then click the item that indicates the PC card drive (this will differ depending on your version of Windows; see below) to unmount the drive.



| OS | VariOS's Drive Name |
|------------------|----------------------------------|
| Windows XP, 2000 | USB high-capacity storage device |
| Windows Me | USB disk |


- 1-2. Windows 98:
In My Computer, right-click the “Removable Disk” icon and execute “Eject.”
- 1-3. Macintosh:
Select the VC-1 drive icon on your desktop, and either choose “Eject” from the “Special” menu, or drag the icon into the trash. The drive icon will disappear from the desktop, and the USB connection will be cancelled.

You can now safely disconnect the USB cable or turn off the power to the V-Synth with the USB cable still connected.

The VC-1's File Structure

As seen from your computer, the VC-1's file structure is as follows.

- You can use the computer to copy (back up) these files to the computer (e.g., the hard disk).
- Do not perform operations on your computer to erase (format) or rename these folders or files.
- If the VC-1 fails to operate correctly, use the CD-ROM included with the VC-1 to perform the VC-1 recovery. This will erase all the data that has been saved on the VC-1.




Exchanging MIDI Messages with Your Computer

What is the USB MIDI Driver?

The USB MIDI Driver is a software which passes data between the VC-1 and the application (sequencer software, UniQuest editor, etc.) that is running on the USB-connected computer.

The USB MIDI Driver sends data from the application to the VC-1, and passes data from the VC-1 to the application.



In order to use the VC-1 as a USB MIDI device from your computer, you must first install the USB MIDI driver. The USB MIDI driver is on the "VariOS Driver CD-ROM." (**NOT** VC-1 CD-ROM!)

The correct driver and the installation procedure will depend on your system and on the other programs you are using. Be sure to read the VariOS User Guide before installation.

- * The most recent version of the USB-MIDI driver can be downloaded from the Roland Website; <http://www.roland.com/products/en/VC-1/>. This URL may change without notice.



| | |
|----------------------------------|------------|
| Key Mode Alteration..... | 126 |
| Sound List..... | 130 |
| Preset Patches | 130 |
| Patch Factors..... | 133 |
| Tone Parameters..... | 134 |
| Common Parameters..... | 134 |
| Partial Parameters..... | 135 |
| System Parameters..... | 137 |
| Waveform..... | 138 |
| MIDI Implementation | 140 |
| Specifications | 149 |
| Index | 150 |

Key Mode Alteration

Poly Mode or Mono Mode is an element that determines how to output the Upper and Lower Tones.

Mono Mode, Poly Mode

There are two ways of the The VC-1 can use either mode.


| Name | Functions |
|------------------|---|
| Poly Mode | Allows the control of more than one Key message on one channel at a time. The VC-1 is 16 or 8 voices polyphonic (depending on the patch used). So the Poly Mode can be used the VC-1 is controlled by a keyboard or sequencer. |
| Mono Mode | Allows only one MIDI message on one channel. The VC-1 is 8 voices polyphonic using 8 MIDI channels. The Mono mode is ideal for a MIDI Guitar System (GR-33, GR-20, etc.) hat has Mono mode, and transmits the messages of each string separately on a different channel. In the other words, Mono mode makes it possible to reproduce guitar sounds without spoiling the natural characteristics of the instrument. |


Select Poly or Mono mode depending on the type of Mode Message sent from the external MIDI device. When Mono mode messages are received by the VC-1, the messages can now be received on a channel group (= eight consecutive MIDI channels, the basic channel being the lowest number).

- * The Mono mode of the VC-1 allows it to receive only the note and bender messages for each channel, therefore it is NOT possible to set a different sound for each note separately.

Using the V-Synth

When the VC-1 (V-Synth) is being controlled by an external MIDI device, the Key mode selected in each Patch affects how the Tones are played and how the control messages run as shown in the following pictures.





→ : Program Change Message

■ : Basic Channel

SP : Split Point


▨ : Global Channel


□ : Number of Voices

▤ : Receive Channel in Separate Mode

Using the VariOS

When the VC-1 (VariOS) is being controlled by an external MIDI device, the Key mode selected in each Patch affects how the Tones are played and how the control messages run as shown in the following pictures.





- : Program Change Message
- SP : Split Point
- : Number of Voices
- : Basic Channel
- ▨ : Global Channel
- ◻ : Receive Channel in Separate Mode

Sound List

Preset Patches

P1 (Preset 1:Original D-50)

| | No.1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|---------------|-----------------------------|-----------------------|---------------------------|----------------------------|--------------------------|-------------------------|-------------------------|---------------------------|
| BANK 1 | Fantasia (D) | Metal Harp (D) | Jazz Guitar Duo (D) | Arco Strings (D) | Horn Section (D) | Living Calliope (D) | D-50 Voices (D) | Slow Rotor (D) |
| 2 | Digital Native Dance (D) | Bass Marimba (D) | Flute-Piano Duo (D) | Combie Strings (D) | Harpsichord Stabs (D) | Griittarr (D) | Nylon Atmosphere (D) | Synthetic Electric (D) |
| 3 | Breathy Chiffer (D) | Gamelan bell (D) | Slap Bass (D) | Pressure Me Strings (D) | Rich Brass (D) | Pipe Solo (D) | Soundtrack (D) | Cathedral Organ (D) |
| 4 | Shamus Theme (D) | Vibraphone (D) | Basin Strat Blues (S) | Pizzagogo (D) | Flutish Brass (D) | Pressure Me Lead (D) | Spacious Sweep (W) | Piano-Fifty (D) |
| 5 | Glass Voices (D) | Hollowed Harp (D) | Ethnic Session (D) | Jete Strings (D) | Stereo Polysynth (D) | Tine Wave (D) | Syn-Harmonium (W) | Rock Organ (D) |
| 6 | Staccato Heaven (D) | Oriental Bells (D) | E-Bass and E-Piano (S) | Legato Strings (D) | JX Horns-Strings (D) | Shakuhachi (D) | Choir (D) | Picked Guitar Duo (D) |
| 7 | Nightmare (D) | Syn Marimba (D) | Slap Bass n Brass (S) | String Ensemble (D) | Velo-Brass (W) | Digital Cello (D) | OK Chorale (D) | Pianissimo (D) |
| 8 | Intruder FX (D) | Steel Pick (D) | Synth Bass (D) | Afterthought (D) | Bones (D) | Bottle Blower (D) | Future Pad (D) | PCM E-Piano (D) |

P2 (Preset 2: New)

| | No.1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|---------------|----------------------|-----------------------|-------------------------|--------------------------|-------------------------|--------------------------|-------------------------|------------------------|
| BANK 1 | Brass Tacks (D) | A Bright Day (D) | Soft EPicenter (D) | Next Stop Nirvana (D) | Pressure Dome (D) | Hard Whoover (D) | Digital Clavi (D) | Chasing Game (D) |
| 2 | Stereo Rhodes (D) | FM Rhodes (D) | Curly Wurly (D) | End of the 7 Era (D) | Christmas Time (D) | Good Vibrations (D) | Fairy Ultra (D) | Thoughts (D) |
| 3 | Music Box (W) | Happy Toy (D) | Space Harp (D) | Wonder Drops (D) | Pluck the Pad (D) | Long Dream (D) | Late 80s Stack (D) | Gin Fizz (D) |
| 4 | Perc Piper (D) | Space Rays (D) | Tandorri Bells (D) | I saw the light (D) | Future is Behind (D) | Bow Street Runner (D) | Tension Sheet (D) | D1080 Pad (D) |
| 5 | Atmostrings (D) | Waving Strings (D) | Organic Strings (D) | Megatronic (D) | PhotonPhaser s (D) | Soft Whoover (D) | LA Supersaw (D) | Dance Choir (D) |
| 6 | Rusty Voices (D) | Solo X Press (D) | Daft Lead (W) | Back 2 Mono (D) | Mono Octabass (W) | Gated FM bass (D) | Acid Bass (W) | Rubber Bass (D) |
| 7 | Purr-Phunk (D) | Atmo Bass (D) | Zawco Brass (D) | D-50 Syn Brass (D) | Ambient Hit (D) | 12str Guitar (D) | Darjiling (D) | Realistic Flute (D) |
| 8 | PiccoBello (D) | Qatsi Organ (D) | Sunken Cathedral (D) | Sorcerers Organ (D) | Voice of Elohim (D) | Sun Safari (D) | Musique Concrete (D) | Jurassic Breath (D) |

P3 (Preset 3:PN-D50-01)

| | No.1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|---------------|--------------------------|----------------------------|---------------------------|----------------------------|------------------------------|--------------------------|-------------------------------|---------------------------|
| BANK 1 | Bouncing Bows (D) | Deep Analog Strings (D) | Psycho Strings (D) | Warm Strings (D) | Deep Strings Ensemble (D) | Symphony Strings (D) | Chase Strings Ensemble (D) | Baroque Strings (D) |
| 2 | Cello (D) | Viola (D) | Solo Violin (D) | Contra Bass (D) | Choir & Strings (D) | Harpsi Strings (D) | Horns & Strings (D) | Pulse Pad (D) |
| 3 | Classical Horn (D) | Fanfare (D) | Tuba (W) | Velo-Brass 2 (W) | Stab Brass (D) | Mallet Horns (D) | Slow Brass Sweep (D) | Slappin Brass (D) |
| 4 | Tenor Saxophone (D) | Alto Saxophone (D) | Soprano Saxophone (D) | E-Piano & Sopranino (S) | Wild Blow (D) | Squeeze de Sax (W) | Harmonica (W) | Whistling Soldiers (S) |
| 5 | Flute-Piccolo (D) | Oboe (D) | Bassoon (D) | Clarinet (D) | Ocarina (W) | Breathing Pipe (D) | Calliope (D) | Wabi Sabi (D) |
| 6 | Synth Lead 1 (D) | Synth Lead 2 (W) | Griittarr 2 (D) | 5th Lead Synth (W) | Analog Solo (D) | Synth Lead 3 (W) | Gotham Low (W) | Taj Mahal (D) |
| 7 | Ham and Organ (D) | Slow Rotor 2 (D) | Slow to Fast Rotor (D) | Good & Old Days (W) | Percussive E-Organ (D) | Slap Bass & Organ (S) | Pipe Organ (W) | Weird Organ (D) |
| 8 | Star Peace Chorus (D) | Spacy Voice (D) | Thinful (D) | Vox Harmonium (D) | Android (D) | Nuns (D) | Pressure Pad (D) | Digital Sound (D) |

P4 (Preset 4:PN-D50-02)

| | No.1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|---------------|---------------------------|----------------------------|-------------------------|----------------------------|--------------------------|----------------------------|---------------------------|-----------------------------|
| BANK 1 | Synthetic Piano 1 (D) | Upright Pianer (D) | Loud Piano (D) | Tack Piano (D) | Synthetic Piano 2 (W) | High Piano (D) | Two Part Invention (D) | Harpsichord Coupler (W) |
| 2 | Electric Piano (D) | Xmod Attack E-Piano (W) | Harmonic E-Piano (D) | Reluctant E-Piano (D) | Tines (D) | Old Clav (W) | Painful Clav (D) | Flanging Clav (D) |
| 3 | Guitar Frets (D) | Jazz Guitar (W) | Spanishart (D) | Acoustic Guitar Box (D) | Harp (W) | Koto (D) | Sitar (D) | Hawaiian Palms (S) |
| 4 | Marimba (D) | Xylophone (D) | Glockenspiel (W) | Jamaican Steel (D) | Perc AAAH (D) | Tremolo Brass Bells (D) | ISIS (D) | Xylo Gate (W) |
| 5 | Samba Drum & Agogo (S) | Drums Set 1 (S) | Drums Set 2 (S) | Percussion Set 1 (S) | Gron Percussion (D) | Bell Tree (W) | Serrengetti (D) | Bellocell (D) |
| 6 | Fingered Bass (D) | Slap Bass 2 (D) | Slap It (D) | Picked Bass (D) | Fretless Bass (D) | Acoustic Bass (D) | Synth Bass 2 (D) | Slap Bass & Syn Bass (S) |
| 7 | Stringz & Bellz (D) | Bright Wave (D) | Gotham Chords (D) | Wonderwave (D) | Gamelan Bells 2 (D) | Ethnic Fifth (W) | Japanese Duo 1 (S) | Japanese Duo 2 (S) |
| 8 | AQUA (D) | Jet Wars (S) | Orchestra Hit (D) | Clock Factory (D) | Gunfire-Ricochet (D) | Fast Forward (W) | Air Raid Siren (D) | Sweep Loop on C (D) |

P5 (Preset 5:PN-D50-03)

| | No.1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|---------------|---------------------------|-----------------------------|-------------------------|--------------------------|---------------------------|---------------------------|----------------------------|---------------------------|
| BANK 1 | String Section (D) | Syn-Strings Hi (D) | Tension Strings (D) | Planetary Strings (D) | Symphony Orchestra (D) | Analog Syn-Strings (D) | Crescendo Strings (D) | Warm Strings Pad (D) |
| 2 | Vibrato Cello (D) | String Quartette (D) | Pizz Typewriter (D) | Strings Horn (D) | Strings Elec Piano (D) | High-Strings Oboe (D) | Cello-Viola Piccolo (D) | Bass-Piano Strings (D) |
| 3 | Powerful Brass (D) | Mute Trumpet (W) | Westerly Brass (D) | Flugel Horn (D) | Eye Brasspad (D) | Trumpeters (D) | Pressure 5th Horns (D) | Pianish Horns (D) |
| 4 | Baritone Saxophone (D) | Silver Saxophone (D) | Saxcessive Tones (D) | Synthesized Sax (W) | Growl Saxophone (D) | Sopranino Sax (D) | Xarmonica (W) | Happy Whistler (D) |
| 5 | Breathy Flute (D) | Bohemian (D) | Recorder (D) | Breeze Pipe (D) | Flutes Ensemble (D) | Woodwinds (S) | Pipe Bags (D) | Vibe n Clarinet (S) |
| 6 | Heavy Metal Lead (D) | Monophonic Lead (D) | Pulse Lead (W) | Squeeze Lead (D) | Energetical Lead (D) | Monotone Lead (D) | Harmonics Lead (D) | Metallic Lead (D) |
| 7 | Jazz Organ (D) | Huge Pipes (D) | Velocity Rotor (D) | Choral Organ (D) | Click Organ (D) | Solid Beat (D) | Wavy Motion (D) | Pressure Generator (D) |
| 8 | Whispy Vox (D) | Alpha Omega Ensemble (D) | Vox n Sawz (D) | 4th Synth Vox (D) | Husky Voices (D) | Stereo Panorama (D) | Voyageur (D) | Glass Voice 2 (D) |

P6 (Preset 6:PN-D50-04)

| | No.1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|--------------|---------------------------|---------------------------|--------------------------|-----------------------------|------------------------|---------------------------|---------------------------|----------------------------|
| BANK1 | Perc E-Piano (D) | Ballad Piano Choir (D) | New Age Piano (D) | Xmod E-Piano (W) | Vividly Piano (D) | Air Piano (D) | Honky-Tonk Piano (D) | Antique harpsichord (D) |
| 2 | Spanish Guitar (D) | Ringmod E-Guitar (D) | Gypsy Guitar (D) | Rock Guitar (D) | Harp Strings (D) | Dulcimer Voice (D) | Comdie Clav (D) | Stereo Clav (D) |
| 3 | Toys in the Attic (D) | Music Toybox (D) | Bells Harmony (D) | Star Chime (D) | African Kalimba (D) | Okinawa Session (S) | Jamaican Sounds (D) | India (S) |
| 4 | Sweet Vibes (D) | Clear Bell Pad (W) | Marimbell (D) | Venetian Cafe (S) | Grand Canyon (S) | Funky Bed Trax (S) | Ohayashi (S) | Koto-Bamboo Flute (S) |
| 5 | Digital Atmosphere (W) | Polyphonic Synth (S) | Pad Combo (D) | Attack-Reso Synth (D) | Velo-Oct Pulse (D) | Perc Release (D) | Steam Synth Pad (D) | Zean- - - (D) |
| 6 | Hopper Bass (D) | Electric Pick Bass (D) | Octave Synth Bass (D) | Natural Bass (D) | Glide Bass (D) | Funky Reso-Bass (D) | Steelblue Bass (D) | Funky Cutting (S) |
| 7 | Soundtrack n Hold (D) | Reso Release (D) | Ballet Voices U-L (D) | Press Pan sampl Hold (D) | Twilight Zone (D) | After Bend-Panning (D) | All Diminish Chord (D) | STAR-TREK Voices (D) |
| 8 | Marshy Zone (D) | Dense Forest (D) | F-1 Grand Prix (D) | Passing Sky (D) | Devildom (S) | Haunted Bells (D) | Vietnam FX (S) | Big Waves (D) |

Patch Factors

| Patch Factors | | Value | Comment | |
|-------------------|--------------------------|--|-------------|-------------|
| PATCH TOP (p. 26) | | | | |
| Chase Switch | Chase Switch | OFF, ON | | |
| Portament Switch | Portamento Switch | OFF, ON | | |
| KEY MODE | Key Mode | WHOLE, DUAL, SPLIT, SEP, WHOL-S, DUAL-S, SPL-US, SPL-LS, SEP-S | | |
| SPLIT | Split Point | C2 – C7 | | |
| BALANCE | Tone Balance | 0 – 100 | | CTRL |
| CONTROL (p. 28) | | | | |
| Bend | Bender Range | 0 – 12 | | CTRL |
| AfterPB | Aftertouch Bend Range | -12 – +12 | | CTRL |
| Hold | Hold Mode | U, L, UL | | |
| Time | Portamento Time | 0 – 100 | | CTRL |
| Mode | Portamento Mode | U, L, UL | | CTRL |
| OUTPUT (p. 29) | | | | |
| Mode | Output Mode | 1 – 4 | | |
| RevType | Reverb Type | 1 – 32 | | |
| Revbal | Reverb Balance | 0 – 100 | | CTRL |
| Vol | Total Volume | 0 – 100 | | CTRL |
| CHASE (p. 31) | | | | |
| Mode | Chase Mode | UL, ULL, ULU | | |
| Level | Chase Level | 0 – 100 | | CTRL |
| Time | Chase Time | 0 – 100 | | CTRL |
| TONE TUNE (p. 32) | | | | |
| LKey | L-Tone Key Shift | -24 – +24 | | CTRL |
| UKey | U-Tone Key Shift | -24 – +24 | | CTRL |
| Ltune | L-Tone Fine Tune | -50 – +50 | | CTRL |
| Utune | U-Tone Fine Tune | -50 – +50 | | CTRL |
| MIDI (p. 32) | | | | |
| TxCH | Transmit CH | B, 1 – 16 | | |
| TxPC | Transmit Program Change | Off, 1 – 100 | | |
| TxBS | Transmit Bank Select | Off, 0 – 99 | VC-1 | |
| SepCH | Separate Mode Receive CH | Off, 1 – 16 | | |

Tone Parameters

Common Parameters

| Parameter | | | Value | Comment | |
|-----------------|---------|-----------------------------|--------------------|---------|------|
| Struct (p. 57) | | | | | |
| Structure | Struct | Structure | 1 – 7 | | |
| Partial Balance | Balance | Partial Balance | 0 – 99 | VC-1 | CTRL |
| P-ENV (p. 58) | | | | | |
| P-ENV | Velo | Velocity Range | 0 – 2 | | CTRL |
| | TKF | Time Keyfollow | 0 – 4 | | CTRL |
| P-ENV Time | T1 | Time1 | 0 – 50 | | CTRL |
| | T2 | Time2 | 0 – 50 | | CTRL |
| | T3 | Time3 | 0 – 50 | | CTRL |
| | T4 | Time4 | 0 – 50 | | CTRL |
| P-ENV Level | L0 | Level0 | -50 – 50 | | CTRL |
| | L1 | Level1 | -50 – 50 | | CTRL |
| | L2 | Level2 | -50 – 50 | | CTRL |
| | SusL | Sustain Level | -50 – 50 | | CTRL |
| | EndL | End Level | -50 – 50 | | CTRL |
| Pitch Mod | LFOD | LFO Depth | 0 – 100 | | CTRL |
| | Lever | Pitch Lever Modulation | 0 – 100 | | CTRL |
| | Aftr | Pitch Aftertouch Modulation | 0 – 100 | | CTRL |
| LFO (p. 60) | | | | | |
| LFO-1 | Wave | Waveform | TRI, SAW, SQU, RND | | CTRL |
| | Rate | Rate | 0 – 100 | | CTRL |
| | Delay | Delay Time | 0 – 100 | | CTRL |
| | Sync | Sync. | Off, On, KEY | | CTRL |
| LFO-2 | Wave | Waveform | TRI, SAW, SQU, RND | | CTRL |
| | Rate | Rate | 0 – 100 | | CTRL |
| | Delay | Delay Time | 0 – 100 | | CTRL |
| | Sync | Sync. | Off, On | | CTRL |
| LFO-3 | Wave | Waveform | TRI, SAW, SQU, RND | | CTRL |
| | Rate | Rate | 0 – 100 | | CTRL |
| | Delay | Delay Time | 0 – 100 | | CTRL |
| | Sync | Sync. | Off, On | | CTRL |

| Parameter | | | Value | Comment | |
|-------------------|---------|----------------|--|---------|------|
| EQ/Chorus (p. 61) | | | | | |
| EQ | LowFreq | Low Frequency | 63, 75, 88, 105, 125, 150, 175, 210, 250, 300, 350, 420, 500, 600, 700, 840 | | |
| | LowGain | Low Gain | -12 – 12 | | CTRL |
| | HiFreq | High Frequency | 250, 300, 350, 420, 500, 600, 700, 840, 1.0, 1.2, 1.4, 1.7, 2.0, 2.4, 2.8, 3.4, 4.0, 4.8, 5.7, 6.7, 8.0, 9.5 | | |
| | HiQ | High Q | 0.3, 0.5, 0.7, 1.0, 1.4, 2.0, 3.0, 4.2, 6.0 | | CTRL |
| | HiGain | High Gain | -12 – 12 | | CTRL |
| Chorus | Type | Chorus Type | 1 – 8 | | |
| | Rate | Chorus Rate | 0 – 100 | | CTRL |
| | Depth | Chorus Depth | 0 – 100 | | CTRL |
| | Balance | Chorus Balance | 0 – 100 | | CTRL |

Partial Parameters

| Parameter | | | Value | Comment | |
|---------------|--------|---------------------------|--|---------|------|
| FORM (p. 64) | | | | | |
| WG Form | Wave | Waveform | SQU, SAW | | CTRL |
| | PCM | PCM Wave No. | 1 – 127 | PCM | CTRL |
| WG PW | PW | Pulse Width | 0 – 100 | | CTRL |
| | Velo | Velocity Range | -7+7 | | CTRL |
| | After | Aftertouch Range | -7+7 | | CTRL |
| | LFO | LFO Select | +1, -1, +2, -2, +3, -3 | | CTRL |
| | LFOD | LFO Depth | 0 – 100 | | CTRL |
| PITCH (p. 66) | | | | | |
| WG Pitch | Coars | Coarse | C1 – C7 | PCM | CTRL |
| | Fine | Fine | -50–50 | PCM | CTRL |
| | KF | Keyfollow | -1, -1/2, -1/4, 0, 1, 1/4, 3/8, 1/2, 5/8, 3/4, 7/8, 1, 5/4, 3/2, 2, s1, s2 | PCM | CTRL |
| WG Mod | LFO | LFO Mode | Off, (+), (-), A&L | PCM | CTRL |
| | ENV | P-ENV Mode | Off, (+), (-) | PCM | CTRL |
| | Bend | Bender Mode | Off, KEY, NOM | PCM | CTRL |
| TVF (p. 68) | | | | | |
| TVF | Freq | Cutoff Frequency | 0 – 100 | | CTRL |
| | Reso | Resonance | 0 – 30 | | CTRL |
| | KF | Keyfollow | -1, -1/2, -1/4, 0, 1, 1/4, 3/8, 1/2, 5/8, 3/4, 7/8, 1, 5/4, 3/2, 2 | | CTRL |
| | BP | Bias Point/Bias Direction | <A1 – <C7, >A1 – >C7 | | CTRL |
| | BLevel | Bias Level | -7 – 7 | | CTRL |

Sound List

| Parameter | | | Value | Comment | |
|---------------|--------|---------------------------|-------------------------|---------|------|
| TVF ENV | Depth | Depth | 0 – 100 | | CTRL |
| | Velo | Velocity Range | 0 – 100 | | CTRL |
| | DKF | Depth Keyfollow | 0 – 4 | | CTRL |
| | TKF | Time Keyfollow | 0 – 4 | | CTRL |
| TVF ENV Time | T1 | Time1 | 0 – 100 | | CTRL |
| | T2 | Time2 | 0 – 100 | | CTRL |
| | T3 | Time3 | 0 – 100 | | CTRL |
| | T4 | Time4 | 0 – 100 | | CTRL |
| | T5 | Time5 | 0 – 100 | | CTRL |
| TVF ENV Level | L1 | Level1 | 0 – 100 | | CTRL |
| | L2 | Level2 | 0 – 100 | | CTRL |
| | L3 | Level3 | 0 – 100 | | CTRL |
| | SusL | Sustain Level | 0 – 100 | | CTRL |
| | EndL | End Level | 0, 100 | | CTRL |
| TVA (p. 73) | | | | | |
| TVA | Level | Level | 0 – 100 | PCM | CTRL |
| | Velo | Velocity Range | -50 – 50 | PCM | CTRL |
| | BP | Bias Point/Bias Direction | <A1 – <C7, >A1 – >C7 | PCM | CTRL |
| | BLevel | Bias Level | -12 – 12 | PCM | CTRL |
| TVA ENV | Velo | Velocity Follow | 0 – 4 | PCM | CTRL |
| | TKF | Time Keyfollow | 0 – 4 | PCM | CTRL |
| TVA ENV Time | T1 | Time1 | 0 – 100 | PCM | CTRL |
| | T2 | Time2 | 0 – 100 | PCM | CTRL |
| | T3 | Time3 | 0 – 100 | PCM | CTRL |
| | T4 | Time4 | 0 – 100 | PCM | CTRL |
| | T5 | Time5 | 0 – 100 | PCM | CTRL |
| TVA ENV Level | L1 | Level1 | 0 – 100 | PCM | CTRL |
| | L2 | Level2 | 0 – 100 | PCM | CTRL |
| | L3 | Level3 | 0 – 100 | PCM | CTRL |
| | SusL | Sustain Level | 0 – 100 | PCM | CTRL |
| | EndL | End Level | 0, 100 | PCM | CTRL |
| MOD (p. 76) | | | | | |
| TVF MOD | LFO | LFO Select | +1, -1, +2, -2, +3, -3 | | CTRL |
| | LFOD | LFO Depth | 0 – 100 | | CTRL |
| | After | Aftertouch Range | -7 – 7 | | CTRL |
| TVA MOD | LFO | LFO Select | +1, -1, +2, -2, +3, -3 | PCM | CTRL |
| | LFOD | LFO Depth | 0 – 100 | PCM | CTRL |
| | After | Aftertouch Range | -7 – 7 | PCM | CTRL |

System Parameters

| Parameter | | Value | Comment | | | |
|------------------------|--------------------------|-------------------------|---------|------|---------|--------|
| Sound Setting (p. 79) | | | | | | |
| Master Tune | Master Tune | 427 – 452 Hz | | | V-Synth | VariOS |
| Sound Character | Sound Character | D-50, V-Synth | VC-1 | | V-Synth | |
| Digital Freq | Digital Output Frequency | 44.1, 48, 96 kHz | VC-1 | | V-Synth | |
| Keyboard (p. 79) | | | | | | |
| Octave | Octave | -3 – 3 | VC-1 | | V-Synth | |
| Transpose | Transpose | -12 – 12 | | | V-Synth | |
| KBD Sens | Keyboard Sens | LIGHT, MEDIUM, HEAVY | VC-1 | | V-Synth | |
| Aftertouch SENS | Aftertouch Sens | 0 – 100 | VC-1 | CTRL | V-Synth | |
| Pedal Polarity (p. 80) | | | | | | |
| Hold | Hold Pedal | STANDARD, REVERSE | VC-1 | | V-Synth | |
| Pedal1 | Control Pedal 1 | STANDARD, REVERSE | VC-1 | | V-Synth | |
| Pedal2 | Control Pedal 2 | STANDARD, REVERSE | VC-1 | | V-Synth | |
| MIDI (p. 80) | | | | | | |
| MIDICH | Basic CH | 1 – 16 | | | V-Synth | VariOS |
| Control | Control | B.CH, G.CH, MdeOff | | | V-Synth | VariOS |
| Separate CH | Separate Mode Receive CH | 1 – 16 | | | V-Synth | VariOS |
| Local | Local Switch | Off, On | | | V-Synth | |
| Prog.C | Program Change Switch | Off, On | | | V-Synth | VariOS |
| Exclusive | Exclusive Switch | Off, On, P-Dump, TxEdit | | | V-Synth | VariOS |
| Bank.S | Bank Select Switch | Off, On | VC-1 | | V-Synth | VariOS |
| USB MIDI | USB MIDI Switch | Off, On | | | V-Synth | |
| SYSTEM (p. 119) | | | | | | |
| Sound Character | Sound Character | D-50, VariOS | VC-1 | | | VariOS |
| MIDI Mode | MIDI Mode | PC, Internal | VC-1 | | | VariOS |
| C1/C2/C3 Knob | Knob Switch | Enable, Disable | VC-1 | | | VariOS |

Waveform

Oneshot

| Number | Display | PCM Name |
|--------|---------|-------------------|
| 1 | Marmba | Marimba |
| 2 | Vibes | Vibraphone |
| 3 | Xylo1 | Xylophone 1 |
| 4 | Xylo2 | Xylophone 2 |
| 5 | Log_Bs | Log bass |
| 6 | Hammer | Hammer |
| 7 | JpnDrm | Japanese Drum |
| 8 | Kaimba | Kalimba |
| 9 | Pluck | Pluck 1 |
| 10 | Chink | Chink |
| 11 | Agogo | Agogo |
| 12 | 3angle | Triangle |
| 13 | Bells | Bell's |
| 14 | Nails | Nail File |
| 15 | Pick | Pick |
| 16 | Lpiano | Low Piano |
| 17 | Mpiano | Mid Piano |
| 18 | Hpiano | High Piano |
| 19 | Harpsi | Harpsichord |
| 20 | Harp | Harp |
| 21 | Orgprc | Organ Percussion |
| 22 | Steel | Steel Strings |
| 23 | Nylon | Nylon Strings |
| 24 | Eguit1 | Electric Guitar 1 |
| 25 | Eguit2 | Electric Guitar 2 |
| 26 | Dirt | Dirty Guitar |
| 27 | P_Bass | Pick Bass |
| 28 | Pop | Pop Bass |
| 29 | Thump | Thump |
| 30 | Uprite | Upright Bass |
| 31 | Clarnt | Clarinet |
| 32 | Breath | Breath |
| 33 | Steam | Steamer |
| 34 | FluteH | High Flute |
| 35 | FluteL | Low Flute |
| 36 | Guio | Guio |
| 37 | IndFlt | Indian Flute |
| 38 | Harmo | Flute Harmonics |
| 39 | Lips1 | Lips 1 |
| 40 | Lips2 | Lips 2 |

| Number | Display | PCM Name |
|--------|---------|------------|
| 41 | Trumpet | Trumpet |
| 42 | Bones | Trombones |
| 43 | Contra | Contrabass |
| 44 | Cello | Cello |
| 45 | VioBow | Violin bow |
| 46 | Violns | Violins |
| 47 | Pizz | Pizzicart |

Loop

| Number | Display | PCM Name |
|--------|---------|-------------------------|
| 48 | Drawbr | Draw bars (Loop) |
| 49 | Horgan | High Organ (Loop) |
| 50 | Lorgan | Low Organ (Loop) |
| 51 | EP_lp2 | Electric Piano (Loop 1) |
| 52 | EP_lp1 | Electric Piano (Loop 2) |
| 53 | CLAVlp | Clavi (Loop) |
| 54 | HC_lp | Harpsichord (Loop) |
| 55 | EB_lp1 | Electric Bass (Loop 1) |
| 56 | AB_lp | Acoustic Bass (Loop) |
| 57 | EB_lp2 | Electric Bass (Loop 2) |
| 58 | EB_lp3 | Electric Bass (Loop 3) |
| 59 | EG_lp | Electric Guitar (Loop) |
| 60 | CELLlp | CELLlp (Loop) |
| 61 | VIOLlp | Violin (Loop) |
| 62 | Reedlp | Lead (Loop) |
| 63 | SAXlp1 | Sax (Loop 1) |
| 64 | SAXlp2 | Sax (Loop 2) |
| 65 | Aah_lp | Aah (Loop) |
| 66 | Ooh_lp | Ooh (Loop) |
| 67 | Manlp1 | Male (Loop 1) |
| 68 | Spect1 | Spectrum 1 (Loop) |
| 69 | Spect2 | Spectrum 2 (Loop) |
| 70 | Spect3 | Spectrum 3 (Loop) |
| 71 | Spect4 | Spectrum 4 (Loop) |
| 72 | Spect5 | Spectrum 5 (Loop) |
| 73 | Spect6 | Spectrum 6 (Loop) |
| 74 | Spect7 | Spectrum 7 (Loop) |
| 75 | Manlp2 | Male (Loop 2) |
| 76 | Noise | Noise (Loop) |

Loop (Some of the sounds 1 to 76, are combined and looped.)

| Number | Display |
|--------|---------|
| 77 | Loop01 |
| 78 | Loop02 |
| 79 | Loop03 |
| 80 | Loop04 |
| 81 | Loop05 |
| 82 | Loop06 |
| 83 | Loop07 |
| 84 | Loop08 |
| 85 | Loop09 |
| 86 | Loop10 |
| 87 | Loop11 |
| 88 | Loop12 |
| 89 | Loop13 |
| 90 | Loop14 |
| 91 | Loop15 |
| 92 | Loop16 |
| 93 | Loop17 |
| 94 | Loop18 |
| 95 | Loop19 |
| 96 | Loop20 |
| 97 | Loop21 |
| 98 | Loop22 |
| 99 | Loop23 |
| 100 | Loop24 |

Newly Added Waveforms

| Number | Display | PCM Name |
|--------|---------|------------------------|
| 101 | Rhodes | Rhodes VC-1 |
| 102 | Wurly | Wurly VC-1 |
| 103 | FM EP | FM Electric Piano VC-1 |
| 104 | M_Box | Music Box VC-1 |
| 105 | Kalmb2 | Kalimba 2 VC-1 |
| 106 | StlGtr | Steel Guitar VC-1 |
| 107 | Sitar | Sitar VC-1 |
| 108 | FM Bs | FM Bass VC-1 |
| 109 | MtlVox | Metal Voice VC-1 |
| 110 | Hit | Hit VC-1 |
| 111 | Sync | Sync VC-1 |
| 112 | FMod1 | FM Modulation 1 VC-1 |
| 113 | FMod2 | FM Modulation 2 VC-1 |
| 114 | Lo3Saw | Low 3 Layered Saw VC-1 |
| 115 | FatSaw | Fat Saw VC-1 |
| 116 | FatSqr | Fat Square VC-1 |
| 117 | FbkOSC | Feedback OSC VC-1 |
| 118 | Phased | Phased Saw VC-1 |
| 119 | TronSt | Tron Strings VC-1 |
| 120 | F_Wine | Fine Wine VC-1 |
| 121 | Fbkwav | Feedbackwave VC-1 |
| 122 | AahMin | Aah Voice Minor VC-1 |
| 123 | VoxChd | Voice Chord VC-1 |
| 124 | Granu | Granular VC-1 |
| 125 | Ringy | Ringy VC-1 |
| 126 | Revrs1 | Reverse 1 VC-1 |
| 127 | Revrs2 | Reverse 2 VC-1 |
| 128 | RevVox | Reversed Voice VC-1 |

MIDI Implementation

Model: VC-1
Date: March 31, 2004
Version: 1.00

1. Data Transmission

■Channel Voice Messages

●Note off (for V-Synth only)

| Status | 2nd byte | 3rd byte |
|--------------------------|---------------------|----------|
| 8nH | kkH | vvH |
| n = MIDI channel number: | 0H - FH (ch.1 - 16) | |
| kk = note number: | 00H - 7FH (0 - 127) | |
| vv = note off velocity: | 00H - 7FH (0 - 127) | |

●Note on (for V-Synth only)

| Status | 2nd byte | 3rd byte |
|--------------------------|---------------------|----------|
| 9nH | kkH | vvH |
| n = MIDI channel number: | 0H - FH (ch.1 - 16) | |
| kk = note number: | 00H - 7FH (0 - 127) | |
| vv = note on velocity: | 01H - 7FH (1 - 127) | |

●Control Change

○Bank Select (Controller number 0, 32)

| Status | 2nd byte | 3rd byte |
|--------------------------|---------------------------------------|----------|
| BnH | 00H | mmH |
| BnH | 20H | llH |
| n = MIDI channel number: | 0H - FH (ch.1 - 16) | |
| mm, ll = Bank number: | 00 00H - 7F 7FH (bank.1 - bank.16384) | |

* Not transmitted when Bank Select Switch (SYSTEM MIDI) is OFF.

* The Patches corresponding to each Bank Select are as follows.

| BANK SELECT | | PROGRAM NUMBER | BATCH BANK | PATCH NUMBER |
|-------------|-----|----------------|------------|--------------|
| MSB | LSB | | | |
| 087 | 000 | 001 - 064 | Internal 1 | 11 - 88 |
| | 001 | 001 - 064 | Internal 2 | 11 - 88 |
| | 002 | 001 - 064 | Internal 3 | 11 - 88 |
| | 003 | 001 - 064 | Internal 4 | 11 - 88 |
| | 004 | 001 - 064 | Internal 5 | 11 - 88 |
| | 005 | 001 - 064 | Internal 6 | 11 - 88 |
| | 006 | 001 - 064 | Internal 7 | 11 - 88 |
| | 007 | 001 - 064 | Internal 8 | 11 - 88 |
| | 008 | 001 - 064 | Preset 1 | 11 - 88 |
| | 009 | 001 - 064 | Preset 2 | 11 - 88 |
| | 010 | 001 - 064 | Preset 3 | 11 - 88 |
| | 011 | 001 - 064 | Preset 4 | 11 - 88 |
| | 012 | 001 - 064 | Preset 5 | 11 - 88 |
| | 013 | 001 - 064 | Preset 6 | 11 - 88 |

* The transmitted value of MSB can be changed by Tx Bank Select (Patch MIDI).

* In that case the transmitted value of LSB is always 0.

○Modulation (Controller number 1) (for V-Synth only)

| Status | 2nd byte | 3rd byte |
|--------------------------|---------------------|----------|
| BnH | 01H | vvH |
| n = MIDI channel number: | 0H - FH (ch.1 - 16) | |
| vv = Modulation depth: | 00H - 7FH (0 - 127) | |

○Volume (Controller number 7) (for V-Synth only)

| Status | 2nd byte | 3rd byte |
|--------------------------|---------------------|----------|
| BnH | 07H | vvH |
| n = MIDI channel number: | 0H - FH (ch.1 - 16) | |
| vv = Volume: | 00H - 7FH (0 - 127) | |

○Hold 1 (Controller number 64) (for V-Synth only)

| Status | 2nd byte | 3rd byte |
|--------------------------|---|----------|
| BnH | 40H | vvH |
| n = MIDI channel number: | 0H - FH (ch.1 - 16) | |
| vv = Control value: | 00H - 7FH (0 - 127) 0-63 = OFF, 64-127 = ON | |

○Portamento Switch (Controller number 65)

| Status | 2nd byte | 3rd byte |
|--------------------------|---|----------|
| BnH | 41H | vvH |
| n = MIDI channel number: | 0H - FH (ch.1 - 16) | |
| vv = Control value: | 00H - 7FH (0 - 127) 0-63 = OFF, 64-127 = ON | |

●Program Change

| Status | 2nd byte |
|--------------------------|------------------------------|
| CnH | ppH |
| n = MIDI channel number: | 0H - FH (ch.1 - 16) |
| pp = Program number: | 00H - 3FH (prog.1 - prog.64) |

* Not transmitted when Program Change Switch (SYSTEM MIDI) is OFF.

●Channel Aftertouch (for V-Synth only)

| Status | 2nd byte |
|--------------------------|---------------------|
| DnH | vvH |
| n = MIDI channel number: | 0H - FH (ch.1 - 16) |
| vv = Aftertouch Value: | 00H - 7FH (0 - 127) |

●Pitch Bender Change (for V-Synth only)

| Status | 2nd byte | 3rd byte |
|------------------------------|--|----------|
| EnH | llH | mmH |
| n = MIDI channel number: | 0H - FH (ch.1 - 16) | |
| mm, ll = Pitch Bender value: | 00 00H - 40 00H - 7F 7FH (-8192 - 0 - +8191) | |

■Channel Mode Messages

●All Sounds Off (Controller number 120) (for VariOS only)

Status 2nd byte 3rd byte
 BnH 78H 00H
 n = MIDI channel number: 0H - FH (ch.1 - 16)

●Reset All Controllers (Controller number 121) (for VariOS only)

Status 2nd byte 3rd byte
 BnH 79H 00H
 n = MIDI channel number: 0H - FH (ch.1 - 16)

●OMNI OFF (Controller number 124) (for V-Synth only)

Status 2nd byte 3rd byte
 BnH 7CH 00H
 n = MIDI channel number: 0H - FH (ch.1 - 16)

●POLY (Controller number 127) (for V-Synth only)

Status 2nd byte 3rd byte
 BnH 7FH 00H
 n = MIDI channel number: 0H - FH (ch.1 - 16)

■System Realtime Messages

●Active Sensing

Status
 FEH

* This message is transmitted at intervals of approximately 250 msec.

●System Exclusive Messages

Status
 F0H :System Exclusive
 F7H :EOX (End Of Exclusive)

Transmitted in the following three cases.

1. When Operating Bulk-Dump
2. If Exclusive of System MIDI is "P-Dump," this unit transmits all parameters in the patch when the patch is changed.
3. If Exclusive of System MIDI is "TxEdit," this unit transmits the parameter when the parameter is edited.

Refer to Section 3 to see details.

2. Receive data

■Channel Voice Messages

●Note off

Status 2nd byte 3rd byte
 8nH kkH vvH
 9nH kkH 00H
 n = MIDI channel number: 0H - FH (ch.1 - 16)
 kk = note number: 00H - 7FH (0 - 127)
 vv = note off velocity: 00H - 7FH (0 - 127)

●Note on

Status 2nd byte 3rd byte
 9nH kkH vvH
 n = MIDI channel number: 0H - FH (ch.1 - 16)
 kk = note number: 00H - 7FH (0 - 127)
 vv = note on velocity: 01H - 7FH (1 - 127)

●Control Change

m Bank Select (Controller number 0, 32)
Status 2nd byte 3rd byte
 BnH 00H mmH
 BnH 20H llH
 n = MIDI channel number: 0H - FH (ch.1 - 16)
 mm, ll = Bank number: 00 00H - 7F 7FH (bank.1 - bank.16384)

- * Not received when the Bank Select Switch (SYSTEM MIDI) is OFF.
- * The Patches corresponding to each Bank Select are as follows.

| BANK SELECT | | PROGRAM NUMBER | BATCH BANK | PATCH NUMBER |
|-------------|-----|----------------|------------|--------------|
| MSB | LSB | | | |
| 087 | 000 | 001 - 064 | Internal 1 | 11 - 88 |
| | 001 | 001 - 064 | Internal 2 | 11 - 88 |
| | 002 | 001 - 064 | Internal 3 | 11 - 88 |
| | 003 | 001 - 064 | Internal 4 | 11 - 88 |
| | 004 | 001 - 064 | Internal 5 | 11 - 88 |
| | 005 | 001 - 064 | Internal 6 | 11 - 88 |
| | 006 | 001 - 064 | Internal 7 | 11 - 88 |
| | 007 | 001 - 064 | Internal 8 | 11 - 88 |
| | 008 | 001 - 064 | Preset 1 | 11 - 88 |
| | 009 | 001 - 064 | Preset 2 | 11 - 88 |
| | 010 | 001 - 064 | Preset 3 | 11 - 88 |
| | 011 | 001 - 064 | Preset 4 | 11 - 88 |
| | 012 | 001 - 064 | Preset 5 | 11 - 88 |
| | 013 | 001 - 064 | Preset 6 | 11 - 88 |

- * The MSB value to be transmitted can be set individually for
- * each patch using Tx Bank Select (PATCH MIDI).
- * In this case, "0" is always output for the LSB.

○Modulation (Controller number 1)

Status 2nd byte 3rd byte
 BnH 01H vvH
 n = MIDI channel number: 0H - FH (ch.1 - 16)
 vv = Modulation depth: 00H - 7FH (0 - 127)

○Portamento Time (Controller number 5)

Status 2nd byte 3rd byte
 BnH 05H vvH
 n = MIDI channel number: 0H - FH (ch.1 - 16)
 vv = Portamento Time: 00H - 7FH (0 - 127)

mm, ll: 00 00H - 40 00H - 7F 7FH
 (-50 - 0 - +50 cent)

○Data Entry (Controller number 6, 38)

Status 2nd byte 3rd byte
 BnH 06H mmH
 BnH 26H llH
 n = MIDI channel number: 0H - FH (ch.1 - 16)
 mm, ll = the value of the parameter specified by RPN/NRPN
 mm = MSB, ll = LSB

○Volume (Controller number 7)

Status 2nd byte 3rd byte
 BnH 07H vvH
 n = MIDI channel number: 0H - FH (ch.1 - 16)
 vv = Volume: 00H - 7FH (0 - 127)

○Hold 1 (Controller number 64)

Status 2nd byte 3rd byte
 BnH 40H vvH
 n = MIDI channel number: 0H - FH (ch.1 - 16)
 vv = Control value: 00H - 7FH (0 - 127) 0-63 = OFF, 64-127 = ON

○Portamento Switch (Controller number 65)

Status 2nd byte 3rd byte
 BnH 41H vvH
 n = MIDI channel number: 0H - FH (ch.1 - 16)
 vv = Control value: 00H - 7FH (0 - 127)
 0 - 63 = OFF, 64 - 127 = ON

○RPN MSB/LSB (Controller number 100, 101)

Status 2nd byte 3rd byte
 BnH 65H mmH
 BnH 64H llH
 n = MIDI channel number: 0H - FH (ch.1 - 16)
 mm = upper byte (MSB) of parameter number specified by RPN
 ll = lower byte (LSB) of parameter number specified by RPN

<<< RPN >>>

Control Changes include RPN (Registered Parameter Numbers), which are extended.

When using RPNs, first RPN (Controller numbers 100 and 101; they can be sent in any order) should be sent in order to select the parameter, then Data Entry (Controller numbers 6 and 38) should be sent to set the value.

This device receives the following RPNs.

| RPN | Data entry | |
|----------|------------|--|
| MSB, LSB | MSB, LSB | Notes |
| 00H, 00H | mmH, llH | Pitch Bender Range |
| | | mm: 00H - 0CH (0 - 12 semitones) |
| | | ll: ignored (processed as 00H) |
| | | Up to 1 octave can be specified in semitone steps. |
| 00H, 01H | mmH, llH | Fine Tuning |

●Program Change

Status 2nd byte
 CnH ppH
 n = MIDI channel number: 0H - FH (ch.1 - 16)
 pp = Program number: 00H - 3FH (prog.1 - prog.64)

* Not received when the Program Change Switch (SYSTEM MIDI) is OFF.

●Channel Aftertouch

Status 2nd byte
 DnH vvH
 n = MIDI channel number: 0H - FH (ch.1 - 16)
 vv = Aftertouch Value: 00H - 7FH (0 - 127)

●Pitch Bender Change

Status 2nd byte 3rd byte
 EnH llH mmH
 n = MIDI channel number: 0H - FH (ch.1 - 16)
 mm, ll = Pitch Bender value: 00 00H - 40 00H - 7F 7FH (-8192 - 0 - +8191)

■Channel Mode Messages**●All Sounds Off (Controller number 120)**

Status 2nd byte 3rd byte
 BnH 78H 00H
 n = MIDI channel number: 0H - FH (ch.1 - 16)

* When this message is received, all notes currently sounding on the corresponding channel will be turned off.

●Reset All Controllers (Controller number 121)

Status 2nd byte 3rd byte
 BnH 79H 00H
 n = MIDI channel number: 0H - FH (ch.1 - 16)

* When this message is received, all controllers on the corresponding channel will be set to their reset values.

■MONO (Controller number 126)

Status 2nd byte 3rd byte
 BnH 7EH mmH
 n = MIDI channel number: 0H - FH (ch.1 - 16)
 mm = mono number: 00H - 10H (0 - 16)

MONO mode, each message is recognized on the channel shown below.

| Message | Control in MIDI function | |
|---------------------|--------------------------|--------|
| | B.CH | G.CH |
| Note on/off | individual | |
| Control Change | basic | Global |
| Mode Message | basic | Global |
| Program Change | basic | Global |
| Aftertouch | basic | Global |
| Pitch Bender Change | individual | |
| Exclusive | basic | Global |

* Global channel is equal to “basic channel - 1.”
And if basic channel is 1, global channel is 16.

●POLY (Controller number 127)

| Status | 2nd byte | 3rd byte |
|--------|----------|----------|
| BnH | 7FH | 00H |

n = MIDI channel number: 0H - FH (ch.1 - 16)

* These Mode Messages (2nd byte = 123-127) are also recognized as All Sounds Off and Reset All Controllers.

■System Realtime Message

●Active Sensing

| Status |
|--------|
| FEH |

* When Active Sensing is received, the unit will begin monitoring the intervals of all further messages. While monitoring, if the interval between messages exceeds 300 ms, the same processing will be carried out as when All Notes Off are received, and message interval monitoring will be halted.

●System Exclusive Message

| Status | |
|--------|-------------------------|
| F0H | :System Exclusive |
| F7H | :EOX (End Of Exclusive) |

Exclusive message can change either each parameter individually or all parameters, of a patch or tone.
Refer to Section 3 to see details.

* Not received when the Exclusive Switch (SYSTEM MIDI) is OFF.

3. Exclusive Communication

■ 3.1 Message structure

All exclusive communications are based on following structure (Roland Exclusive Format Type IV).

| | Byte | Description |
|----|------|--|
| a | F0H | Exclusive status |
| b | 41H | Roland ID # |
| c | dev | Device-ID # = MIDI basic channel -1 |
| d | 14H | Model-ID # (D-50) |
| e | xxH | Command-ID # |
| [f | aaH | Address MSB] [] depend on Command-ID |
| [g | bbH | Address] |
| [h | ccH | Address LSB] |
| [i | ddH | Data] |
| [| : |] |
| j | sum | Checksum |
| k | F7H | EOX (End Of Exclusive) |

Summed value of the all bytes between Command-ID and EOX (f-j) must be 00H (7 bits). It doesn't include Command-ID and EOX.

■ 3.2 Address mapping

●Temporary area

| Address | | Description |
|------------|-----------------|-------------|
| [00-00-00] | Upper Partial-1 | temp-area |
| [00-00-40] | Upper Partial-2 | temp-area |
| [00-01-00] | Upper Common | temp-area |
| [00-01-40] | Lower Partial-1 | temp-area |
| [00-02-00] | Lower Partial-2 | temp-area |
| [00-02-40] | Lower Common | temp-area |
| [00-03-00] | Patch | temp-area |

●Work area

You can transmit/receive data in the currently selected patch bank using the following address.

| Address | Description |
|------------|------------------|
| [02-00-00] | Patch Memory 1-1 |
| [02-03-40] | Patch Memory 1-2 |
| : | : |
| [03-5C-40] | Patch Memory 8-8 |
| [03-60-00] | Reverb Data 17 |
| [03-62-78] | Reverb Data 18 |
| : | : |
| [04-0C-08] | Reverb Data 32 |

Each patch memory consists of the followings.

| Offset | Description |
|------------|-----------------|
| [00-00-00] | Upper Partial-1 |
| [00-00-40] | Upper Partial-2 |
| [00-01-00] | Upper Common |
| [00-01-40] | Lower Partial-1 |
| [00-02-00] | Lower Partial-2 |
| [00-02-40] | Lower Common |
| [00-03-00] | Patch |

■ 3.3 Partial Parameter

| Offset Address | Description | | | | |
|----------------|-------------|----------------|---------------------------|-------------|--|
| 00H | 0vvv vvvv | WG Pitch | Coarse | 0-72 | C1, C#1...C7 |
| 01H | 0vvv vvvv | WG Pitch | Fine | 0-100 | -50..0..+50 |
| 02H | 0vvv vvvv | WG Pitch | Keyfollow | 0-16 | -1, -1/2, -1/4, 0, 1/8, 1/4, 3/8, 1/2, 5/8, 3/4, 7/8, 1, 5/4, 3/2, 2, s1, s2 |
| 03H | 0vvv vvvv | WG Modulation | LFO Mode | 0-3 | Off, (+), (-), A&L |
| 04H | 0vvv vvvv | WG Modulation | P-ENV Mode | 0-2 | Off, (+), (-) |
| 05H | 0vvv vvvv | WG Modulation | Bender Mode | 0-2 | Off, Keyfollow, Normal |
| 06H | 0vvv vvvv | WG Waveform | Waveform | 0-1 | Square, Sawtooth |
| 07H | 0vvv vvvv | WG Waveform | PCM Wave No. | 0-127 | 1..128 |
| 08H | 0vvv vvvv | WG Pulse Width | Pulse Width | 0-100 | 0..100 |
| 09H | 0vvv vvvv | WG Pulse Width | Velocity Range | 0-14 | -7..0..+7 |
| 0AH | 0vvv vvvv | WG Pulse Width | LFO Select | 0-5 | +1, -1, +2, -2, +3, -3 |
| 0BH | 0vvv vvvv | WG Pulse Width | LFO Depth | 0-100 | 0..100 |
| 0CH | 0vvv vvvv | WG Pulse Width | Aftertouch Range | 0-14 | -7..0..+7 |
| 0DH | 0vvv vvvv | TVF | Cutoff Frequency | 0-100 | 0..100 |
| 0EH | 0vvv vvvv | TVF | Resonance | 0-30 | 0..30 |
| 0FH | 0vvv vvvv | TVF | Keyfollow | 0-14 | -1, -1/2, -1/4, 0, 1/8, 1/4, 3/8, 1/2, 5/8, 3/4, 7/8, 1, 5/4, 3/2, 2 |
| 10H | 0vvv vvvv | TVF | Bias Point/Bias Direction | 0-63,64-127 | <A1...<C7, >A1...>C7 |
| 11H | 0vvv vvvv | TVF | Bias Level | 0-14 | -7..0..+7 |
| 12H | 0vvv vvvv | TVF ENV | Depth | 0-100 | 0..100 |
| 13H | 0vvv vvvv | TVF ENV | Velocity Range | 0-100 | 0..100 |
| 14H | 0vvv vvvv | TVF ENV | Depth Keyfollow | 0-4 | 0..4 |
| 15H | 0vvv vvvv | TVF ENV | Time Keyfollow | 0-4 | 0..4 |
| 16H | 0vvv vvvv | TVF ENV Time | T1 | 0-100 | 0..100 |
| 17H | 0vvv vvvv | TVF ENV Time | T2 | 0-100 | 0..100 |
| 18H | 0vvv vvvv | TVF ENV Time | T3 | 0-100 | 0..100 |
| 19H | 0vvv vvvv | TVF ENV Time | T4 | 0-100 | 0..100 |
| 1AH | 0vvv vvvv | TVF ENV Time | T5 | 0-100 | 0..100 |
| 1BH | 0vvv vvvv | TVF ENV Level | L1 | 0-100 | 0..100 |
| 1CH | 0vvv vvvv | TVF ENV Level | L2 | 0-100 | 0..100 |
| 1DH | 0vvv vvvv | TVF ENV Level | L3 | 0-100 | 0..100 |
| 1EH | 0vvv vvvv | TVF ENV Level | Sustain Level | 0-100 | 0..100 |
| 1FH | 0vvv vvvv | TVF ENV Level | End Level | 0-1 | 0, 100 |
| 20H | 0vvv vvvv | TVF Modulation | LFO Select | 0-5 | +1, -1, +2, -2, +3, -3 |
| 21H | 0vvv vvvv | TVF Modulation | LFO Depth | 0-100 | 0..100 |
| 22H | 0vvv vvvv | TVF Modulation | Aftertouch Range | 0-14 | -7..0..+7 |
| 23H | 0vvv vvvv | TVA | Level | 0-100 | 0..100 |
| 24H | 0vvv vvvv | TVA | Velocity Range | 0-100 | -50..0..+50 |
| 25H | 0vvv vvvv | TVA | Bias Point/Bias Direction | 0-63,64-127 | <A1...<C7, >A1...>C7 |
| 26H | 0vvv vvvv | TVA | Bias Level | 0-12 | -12..0 |
| 27H | 0vvv vvvv | TVA ENV Time | T1 | 0-100 | 0..100 |
| 28H | 0vvv vvvv | TVA ENV Time | T2 | 0-100 | 0..100 |
| 29H | 0vvv vvvv | TVA ENV Time | T3 | 0-100 | 0..100 |
| 2AH | 0vvv vvvv | TVA ENV Time | T4 | 0-100 | 0..100 |
| 2BH | 0vvv vvvv | TVA ENV Time | T5 | 0-100 | 0..100 |
| 2CH | 0vvv vvvv | TVA ENV Level | L1 | 0-100 | 0..100 |
| 2DH | 0vvv vvvv | TVA ENV Level | L2 | 0-100 | 0..100 |
| 2EH | 0vvv vvvv | TVA ENV Level | L3 | 0-100 | 0..100 |
| 2FH | 0vvv vvvv | TVA ENV Level | Sustain Level | 0-100 | 0..100 |
| 30H | 0vvv vvvv | TVA ENV Level | End Level | 0-1 | 0, 100 |
| 31H | 0vvv vvvv | TVA ENV | Velocity Follow | 0-4 | 0..4 |
| 32H | 0vvv vvvv | TVA ENV | Time Keyfollow | 0-4 | 0..4 |
| 33H | 0vvv vvvv | TVA Modulation | LFO Select | 0-5 | +1, -1, +2, -2, +3, -3 |
| 34H | 0vvv vvvv | TVA Modulation | LFO Depth | 0-100 | 0..100 |
| 35H | 0vvv vvvv | TVA Modulation | Aftertouch Range | 0-14 | -7..0..+7 |
| 36H | 0vvv vvvv | Extension | | 0-127 | |
| : | : | : | : | : | |
| 3FH | 0vvv vvvv | Extension | | 0-127 | |

■ 3.4 Common Parameter

| Offset Address | Description | | | | |
|----------------|-------------|-----------------|-----------------------------|-------|--|
| 00H | 0vvv vvvv | Tone Name | 1 | 0-63 | '/,A',Z',a',z',1',9',0',,-' |
| : | | | | | |
| : | | | | | |
| 09H | 0vvv vvvv | Tone Name | 10 | 0-63 | |
| 0AH | 0vvv vvvv | Structure | Structure | 0-6 | 1..7 |
| 0BH | 0vvv vvvv | P-ENV Edit | Velocity Range | 0-2 | 0..2 |
| 0CH | 0vvv vvvv | P-ENV Edit | Time Keyfollow | 0-4 | 0..4 |
| 0DH | 0vvv vvvv | P-ENV Time | T1 | 0-50 | 0..50 |
| 0EH | 0vvv vvvv | P-ENV Time | T2 | 0-50 | 0..50 |
| 0FH | 0vvv vvvv | P-ENV Time | T3 | 0-50 | 0..50 |
| 10H | 0vvv vvvv | P-ENV Time | T4 | 0-50 | 0..50 |
| 11H | 0vvv vvvv | P-ENV Level | L0 | 0-100 | -50..0..+50 |
| 12H | 0vvv vvvv | P-ENV Level | L1 | 0-100 | -50..0..+50 |
| 13H | 0vvv vvvv | P-ENV Level | L2 | 0-100 | -50..0..+50 |
| 14H | 0vvv vvvv | P-ENV | Sustain Level | 0-100 | -50..0..+50 |
| 15H | 0vvv vvvv | P-ENV | End Level | 0-100 | -50..0..+50 |
| 16H | 0vvv vvvv | Pitch Mod Edit | LFO Depth | 0-100 | 0..100 |
| 17H | 0vvv vvvv | Pitch Mod Edit | Pitch Lever Modulation | 0-100 | 0..100 |
| 18H | 0vvv vvvv | Pitch Mod Edit | Pitch Aftertouch Modulation | 0-100 | 0..100 |
| 19H | 0vvv vvvv | LFO-1 | Waveform | 0-3 | Triangle, Sawtooth, Square, Random |
| 1AH | 0vvv vvvv | LFO-1 | Rate | 0-100 | 0..100 |
| 1BH | 0vvv vvvv | LFO-1 | Delay Time | 0-100 | 0..100 |
| 1CH | 0vvv vvvv | LFO-1 | Sync. | 0-2 | Off, On, Key |
| 1DH | 0vvv vvvv | LFO-2 | Waveform | 0-3 | Triangle, Sawtooth, Square, Random |
| 1EH | 0vvv vvvv | LFO-2 | Rate | 0-100 | 0..100 |
| 1FH | 0vvv vvvv | LFO-2 | Delay Time | 0-100 | 0..100 |
| 20H | 0vvv vvvv | LFO-2 | Sync. | 0-1 | Off, On |
| 21H | 0vvv vvvv | LFO-3 | Waveform | 0-3 | Triangle, Sawtooth, Square, Random |
| 22H | 0vvv vvvv | LFO-3 | Rate | 0-100 | 0..100 |
| 23H | 0vvv vvvv | LFO-3 | Delay Time | 0-100 | 0..100 |
| 24H | 0vvv vvvv | LFO-3 | Sync. | 0-1 | Off, On |
| 25H | 0vvv vvvv | EQ Edit | Low Frequency | 0-15 | 63, 75, 88, 105, 125, 150, 175, 210, 250, 300, 350, 420, 500, 600, 700, 840 |
| 26H | 0vvv vvvv | EQ Edit | Low Gain | 0-24 | -12..0..+12 |
| 27H | 0vvv vvvv | EQ Edit | High Frequency | 0-21 | 250, 300, 350, 420, 500, 600, 700, 840, 1.0, 1.2, 1.4, 1.7, 2.0, 2.4, 2.8, 3.4, 4.0, 4.8, 5.7, 6.7, 8.0, 9.5 |
| 28H | 0vvv vvvv | EQ Edit | High Q | 0-8 | 0.3, 0.5, 0.7, 1.0, 1.4, 2.0, 3.0, 4.2, 6.0 |
| 29H | 0vvv vvvv | EQ Edit | High Gain | 0-24 | -12..0..+12 |
| 2AH | 0vvv vvvv | Chorus Edit | Chorus Type | 0-7 | 1..8 |
| 2BH | 0vvv vvvv | Chorus Edit | Chorus Rate | 0-100 | 0..100 |
| 2CH | 0vvv vvvv | Chorus Edit | Chorus Depth | 0-100 | 0..100 |
| 2DH | 0vvv vvvv | Chorus Edit | Chorus Balance | 0-100 | 0..100 |
| 2EH | 0vvv vvvv | Partial Mute | | 0-3 | 00, 01, 10, 11 (*1) |
| 2FH | 0vvv vvvv | Partial Balance | | 0-100 | 0..100 |
| 30H | 0vvv vvvv | Extension | | 0-127 | |
| 31H | 0vvv vvvv | Extension | | 0-127 | |
| 32H | 0vvv vvvv | Extension | | 0-127 | |
| 33H | 0vvv vvvv | Extension | | 0-127 | |
| 34H | 0vvv vvvv | Extension | | 0-127 | |
| 35H | 0vvv vvvv | Extension | | 0-127 | |
| 36H | 0vvv vvvv | Extension | | 0-127 | |
| 37H | 0vvv vvvv | Extension | | 0-127 | |
| 38H | 0vvv vvvv | Extension | | 0-127 | |
| 39H | 0vvv vvvv | Extension | | 0-127 | |
| 3AH | 0vvv vvvv | Extension | | 0-127 | |
| 3BH | 0vvv vvvv | Extension | | 0-127 | |
| 3CH | 0vvv vvvv | Extension | | 0-127 | |
| 3DH | 0vvv vvvv | Extension | | 0-127 | |
| 3EH | 0vvv vvvv | Extension | | 0-127 | |
| 3FH | 0vvv vvvv | Extension | | 0-127 | |

■ 3.5 Patch Parameter

| Offset Address | Description | | | | |
|----------------|-------------|---------------------------|--------------------------|-------|---|
| 00H | 0vvv vvvv | Patch Name | 1 | 0-63 | ‘,’A’-’Z’,’a’-’z’,’1’-’9’,’0’,’-’ |
| : | : | : | : | : | : |
| : | : | : | : | : | : |
| 11H | 0vvv vvvv | Patch Name | 18 | 0-63 | : |
| 12H | 0vvv vvvv | Key Mode | | 0-8 | Whole, Dual, Split, Separate, Whole-S, Dual-S, Split-US, Split-LS, Separate-S |
| 13H | 0vvv vvvv | Split Point | | 0-60 | C2, C#2...C7 |
| 14H | 0vvv vvvv | Portamento Mode | | 0-2 | U, L, UL |
| 15H | 0vvv vvvv | Hold Mode | | 0-2 | U, L, UL |
| 16H | 0vvv vvvv | U-Tone Key Shift | | 0-48 | -24..0..+24 |
| 17H | 0vvv vvvv | L-Tone Key Shift | | 0-48 | -24..0..+24 |
| 18H | 0vvv vvvv | U-Tone Fine Tune | | 0-100 | -50..0..+50 |
| 19H | 0vvv vvvv | L-Tone Fine Tune | | 0-100 | -50..0..+50 |
| 1AH | 0vvv vvvv | Bender Range | | 0-12 | 0..12 |
| 1BH | 0vvv vvvv | Aftertouch (Pitch Bender) | | 0-24 | -12..0..+12 |
| 1CH | 0vvv vvvv | Portamento Time | | 0-100 | 0..100 |
| 1DH | 0vvv vvvv | Output Mode | | 0-3 | 1..4 |
| 1EH | 0vvv vvvv | Reverb Type | | 0-31 | 1..32 (17..32 Change Type) |
| 1FH | 0vvv vvvv | Reverb Balance | | 0-100 | 0..100 |
| 20H | 0vvv vvvv | Total Volume | | 0-100 | 0..100 |
| 21H | 0vvv vvvv | Tone Balance | | 0-100 | 0..100 |
| 22H | 0vvv vvvv | Chase Mode | | 0-2 | UL, ULL, ULU |
| 23H | 0vvv vvvv | Chase Level | | 0-100 | 0..100 |
| 24H | 0vvv vvvv | Chase Time | | 0-100 | 0..100 |
| 25H | 0vvv vvvv | MIDI | Transmit CH | 0-16 | Basic, 1..16 |
| 26H | 0vvv vvvv | MIDI | Separate Mode Receive CH | 0-16 | Off, 1..16 |
| 27H | 0vvv vvvv | MIDI | Transmit Program Change | 0-100 | Off, 1..100 |
| 28H | 0vvv vvvv | Chase Switch | | 0-1 | Off, On |
| 29H | 0vvv vvvv | Portamento Switch | | 0-1 | Off, On |
| 2AH | 0vvv vvvv | Separate Switch | | 0-1 | Off, On |
| 2BH | 0vvv vvvv | MIDI | Transmit Bank Select | 0-100 | Off, 0..99 |
| 2CH | 0vvv vvvv | Tone Select | | 0-3 | 00, 01, 10, 11 (*2) |
| 2DH | 0vvv vvvv | Partial Select | | 0-15 | 0000, 0001, 0010, 0011...1111 (*3) |
| 2EH | 0vvv vvvv | Extension | | 0-127 | |
| 2FH | 0vvv vvvv | Extension | | 0-127 | |
| 30H | 0vvv vvvv | Extension | | 0-127 | |
| 31H | 0vvv vvvv | Extension | | 0-127 | |
| 32H | 0vvv vvvv | Extension | | 0-127 | |
| 33H | 0vvv vvvv | Extension | | 0-127 | |
| 34H | 0vvv vvvv | Extension | | 0-127 | |
| 35H | 0vvv vvvv | Extension | | 0-127 | |
| 36H | 0vvv vvvv | Extension | | 0-127 | |
| 37H | 0vvv vvvv | Extension | | 0-127 | |
| 38H | 0vvv vvvv | Extension | | 0-127 | |
| 39H | 0vvv vvvv | Extension | | 0-127 | |
| 3AH | 0vvv vvvv | Extension | | 0-127 | |
| 3BH | 0vvv vvvv | Extension | | 0-127 | |
| 3CH | 0vvv vvvv | Extension | | 0-127 | |
| 3DH | 0vvv vvvv | Extension | | 0-127 | |
| 3EH | 0vvv vvvv | Extension | | 0-127 | |
| 3FH | 0vvv vvvv | Extension | | 0-127 | |

■ 3.6 Reverb Block

| Offset Address | Description | | | | |
|----------------|-------------|-------------|-----|-------|--|
| 00 00H | 0000 aaaa | Reverb Data | 1 | | |
| 00 01H | 0000 bbbb | aaaa bbbb | | 0-255 | |
| 00 02H | 0000 aaaa | Reverb Data | 2 | | |
| 00 03H | 0000 bbbb | aaaa bbbb | | 0-255 | |
| : | | | | | |
| : | | | | | |
| 02 76H | 0000 aaaa | Reverb Data | 188 | | |
| 02 77H | 0000 bbbb | aaaa bbbb | | 0-255 | |

376 bytes of data is mutually related, and each one has no meaning individually.

* 1: table 1 (Common Parameter - Partial Mute)

| BIN | DEC | Description |
|-----|-----|----------------------------|
| 00B | 0 | Partial2 Off, Partial1 Off |
| 01B | 1 | Partial2 Off, Partial1 On |
| 10B | 2 | Partial2 On, Partial1 Off |
| 11B | 3 | Partial2 On, Partial1 On |

* 2: table 2 (Patch Parameter - Tone Select)

| BIN | DEC | Description |
|-----|-----|----------------------|
| 00B | 0 | Upper Off, Lower Off |
| 01B | 1 | Upper Off, Lower On |
| 10B | 2 | Upper On, Lower Off |
| 11B | 3 | Upper On, Lower On |

* 3: table 3 (Patch Parameter - Partial Select)

| BIN | DEC | Description |
|-------|-----|--|
| 0000B | 0 | Upper Partial2 Off, Upper Partial1 Off, Lower Partial2 Off, Lower Partial1 Off |
| 0001B | 1 | Upper Partial2 Off, Upper Partial1 Off, Lower Partial2 Off, Lower Partial1 On |
| 0010B | 2 | Upper Partial2 Off, Upper Partial1 Off, Lower Partial2 On, Lower Partial1 Off |
| 0011B | 3 | Upper Partial2 Off, Upper Partial1 Off, Lower Partial2 On, Lower Partial1 On |
| 0100B | 4 | Upper Partial2 Off, Upper Partial1 On, Lower Partial2 Off, Lower Partial1 Off |
| 0101B | 5 | Upper Partial2 Off, Upper Partial1 On, Lower Partial2 Off, Lower Partial1 On |
| 0110B | 6 | Upper Partial2 Off, Upper Partial1 On, Lower Partial2 On, Lower Partial1 Off |
| 0111B | 7 | Upper Partial2 Off, Upper Partial1 On, Lower Partial2 On, Lower Partial1 On |
| 1000B | 8 | Upper Partial2 On, Upper Partial1 Off, Lower Partial2 Off, Lower Partial1 Off |
| 1001B | 9 | Upper Partial2 On, Upper Partial1 Off, Lower Partial2 Off, Lower Partial1 On |
| 1010B | 10 | Upper Partial2 On, Upper Partial1 Off, Lower Partial2 On, Lower Partial1 Off |
| 1011B | 11 | Upper Partial2 On, Upper Partial1 Off, Lower Partial2 On, Lower Partial1 On |
| 1100B | 12 | Upper Partial2 On, Upper Partial1 On, Lower Partial2 Off, Lower Partial1 Off |
| 1101B | 13 | Upper Partial2 On, Upper Partial1 On, Lower Partial2 Off, Lower Partial1 On |
| 1110B | 14 | Upper Partial2 On, Upper Partial1 On, Lower Partial2 On, Lower Partial1 Off |
| 1111B | 15 | Upper Partial2 On, Upper Partial1 On, Lower Partial2 On, Lower Partial1 On |

4. Supplementary Material

■ Decimal and Hexadecimal Table

(An "H" is appended to the end of numbers in hexadecimal notation.)

In MIDI documentation, data values and addresses/sizes of Exclusive messages, etc. are expressed as hexadecimal values for each 7 bits.

The following table shows how these correspond to decimal numbers.

| D | H | D | H | D | H |
|---|-----|----|-----|----|-----|
| 0 | 00H | 32 | 20H | 64 | 40H |
| 1 | 01H | 33 | 21H | 65 | 41H |
| 2 | 02H | 34 | 22H | 66 | 42H |
| 3 | 03H | 35 | 23H | 67 | 43H |
| 4 | 04H | 36 | 24H | 68 | 44H |
| 5 | 05H | 37 | 25H | 69 | 45H |
| 6 | 06H | 38 | 26H | 70 | 46H |

| D | H | D | H | D | H | D | H |
|----|-----|----|-----|----|-----|-----|-----|
| 7 | 07H | 39 | 27H | 71 | 47H | 103 | 67H |
| 8 | 08H | 40 | 28H | 72 | 48H | 104 | 68H |
| 9 | 09H | 41 | 29H | 73 | 49H | 105 | 69H |
| 10 | 0AH | 42 | 2AH | 74 | 4AH | 106 | 6AH |
| 11 | 0BH | 43 | 2BH | 75 | 4BH | 107 | 6BH |
| 12 | 0CH | 44 | 2CH | 76 | 4CH | 108 | 6CH |
| 13 | 0DH | 45 | 2DH | 77 | 4DH | 109 | 6DH |
| 14 | 0EH | 46 | 2EH | 78 | 4EH | 110 | 6EH |
| 15 | 0FH | 47 | 2FH | 79 | 4FH | 111 | 6FH |
| 16 | 10H | 48 | 30H | 80 | 50H | 112 | 70H |
| 17 | 11H | 49 | 31H | 81 | 51H | 113 | 71H |
| 18 | 12H | 50 | 32H | 82 | 52H | 114 | 72H |
| 19 | 13H | 51 | 33H | 83 | 53H | 115 | 73H |
| 20 | 14H | 52 | 34H | 84 | 54H | 116 | 74H |
| 21 | 15H | 53 | 35H | 85 | 55H | 117 | 75H |
| 22 | 16H | 54 | 36H | 86 | 56H | 118 | 76H |
| 23 | 17H | 55 | 37H | 87 | 57H | 119 | 77H |
| 24 | 18H | 56 | 38H | 88 | 58H | 120 | 78H |
| 25 | 19H | 57 | 39H | 89 | 59H | 121 | 79H |
| 26 | 1AH | 58 | 3AH | 90 | 5AH | 122 | 7AH |
| 27 | 1BH | 59 | 3BH | 91 | 5BH | 123 | 7BH |
| 28 | 1CH | 60 | 3CH | 92 | 5CH | 124 | 7CH |
| 29 | 1DH | 61 | 3DH | 93 | 5DH | 125 | 7DH |
| 30 | 1EH | 62 | 3EH | 94 | 5EH | 126 | 7EH |
| 31 | 1FH | 63 | 3FH | 95 | 5FH | 127 | 7FH |

D: decimal, H: hexadecimal

* Decimal values such as MIDI channel, bank select, and program change are listed as one greater than the values given in the above table.

* A 7-bit byte can express data in the range of 128 steps. For data where greater precision is required, we must use two or more bytes. For example, two hexadecimal numbers aa bbH expressing two 7-bit bytes would indicate a value of $aa \times 128 + bb$.

* In the case of values which have a +/- sign, 00H = -64, 40H = +/-0, and 7FH = +63, so that the decimal expression would be 64 less than the value given in the above chart. In the case of two types, 00 00H = -8192, 40 00H = +/-0, and 7F 7FH = +8191. For example, if aa bbH were expressed as decimal, this would be $aa \times 128 + bb$. For example, if aa bbH were expressed as decimal, this would be $aa \times 128 + bb$.

* Data marked "Use nibbled data" is expressed in hexadecimal in 4-bit units. A value expressed as a 2-byte nibble 0a 0bH has the value of $a \times 16 + b$.

<Example1> What is the decimal expression of 5AH?

From the preceding table, 5AH = 90

<Example2> What is the decimal expression of the value 12 34H given as hexadecimal for each 7 bits?

From the preceding table, since 12H = 18 and 34H = 52

$18 \times 128 + 52 = 2356$

<Example3> What is the decimal expression of the nibbled value 0A 03 09 0DH?

From the preceding table, since 0AH = 10, 03H = 3, 09H = 9, 0DH = 13

$((10 \times 16 + 3) \times 16 + 9) \times 16 + 13 = 41885$

<Example4> What is the nibbled expression of the decimal value 1258?

```

16 ) 1258
    ) 78 ...10
16 ) 4 ...14
    ) 0 ... 4

```

Since from the preceding table, 0 = 00H, 4 = 04H, 14 = 0EH, 10 = 0AH, the result is: 00 04 0E 0AH.

MIDI Implementation Chart

| Function... | | Transmitted | Recognized | Remarks |
|------------------|---------------------------------|---|---|---------------------|
| Basic Channel | Default Changed | 1-16 1-16 | 1-16 1-16 | |
| Mode | Default Messages Altered | Mode 3 Omni Off, Poly ***** | Mode 3 Mono, Poly, Omni Off Mode 1 → Mode 3 Mode 2 → Mode 4 | |
| Note Number : | True Voice | 0-127 * 1 ***** | 0-127 12-108 | |
| Velocity | Note ON Note OFF | O * 1 X | O X | |
| Aftertouch | Key's Ch's | X O * 1 | X O | |
| Pitch Bend | | O | O | |
| Control Change | 0, 32 | O * 2 | O * 2 | Bank Select |
| | 1 | O * 1 | O | Modelation |
| | 5 | O * 1 | O | Portamento Time |
| | 6, 38 | X | O * 3 | Data Entry |
| | 7 | O * 1 | O | Volume |
| | 64 | O * 1 | O | Hold 1 |
| | 65 | O | O | Portamento Switch |
| | 100, 101 | X | O * 3 | RPN LSB, MSB |
| Program Change | : True Number | O * 2 ***** | O 0-127 * 2 | Program Number 1-64 |
| System Exclusive | | O * 2 | O * 2 | |
| System Common | : Song Pos | X | X | |
| | : Song Sel | X | X | |
| | : Tune | X | X | |
| System Real Time | : Clock | X | X | |
| | : Command | X | X | |
| Aux Message | : All Sound Off | O * 4 | O | |
| | : Reset all controllers | O * 4 | O | |
| | : Local ON/OFF | X | X | |
| | : All Notes OFF | X | X | |
| | : Active Sensing | O | O | |
| | : System Reset | X | X | |
| Notes | | * 1 Only V-Synth can be transmitted. * 2 Can be set to O or X manually, and memorized. * 3 RPN = Registered parameter control number. RPN#0: Pitch bend sensitivity RPN#1: Master fine tuning Parameter values are given by Fata Entry. * 4 Only VariOS can be transmitted. | | |

Mode 1 : OMNI ON, POLY

Mode 2 : OMNI ON, MONO

O : Yes

Mode 3 : OMNI OFF, POLY

Mode 4 : OMNI OFF, MONO

X : No

Specifications

VC-1: V-Card D-50 for V-Synth/VariOS

Appearance

PC CARD (68pin, Type II)

Sound Generator

D-50 Compatible LA (Linear Arithmetic) Synthesis

Polyphony

16 voices

Waveforms

Synthesizer: 2

PCM: 128

Internal (User) Memory

Banks: 8

Patches: 512

Preset Memory

Banks: 6

Patches: 384

Accessories

CD-ROM (Card Recovery Data, Editor "UniQuest VC-1")

Card Case

ROLAND SOFTWARE LICENSE AGREEMENT

Owner's Manual

** In the interest of product improvement, the specifications and/or contents of this unit are subject to change without prior notice.*

Index

A

| | |
|--------------------------|---------------|
| AC Inlet | 14, 92 |
| After | 60, 65, 76–77 |
| AfterPB | 28 |
| Aftertouch | 28 |
| Aftertouch Range | 65, 76–77 |
| Aftertouch Sens | 79 |
| ARPEGGIO | 11 |
| ASSIGNABLE CONTROL | 11 |

B

| | |
|--------------------------|---------|
| B.CH | 80 |
| BALANCE | 27 |
| Balance | 57, 63 |
| Bank | 16, 95 |
| Bank Select Switch | 81, 118 |
| Bank.S | 81 |
| BankSelect Sw | 118 |
| Basic CH | 118 |
| Basic Channel | 117 |
| Basic Channel mode | 80 |
| Beep | 18 |
| beep tone | 18 |
| Bend | 28, 67 |
| Bender Mode | 67 |
| Bender Range | 28 |
| Bias Level | 69, 73 |
| Bias Point | 69, 73 |
| BLevel | 69, 73 |
| BP | 69, 73 |
| bulk dump | 36, 101 |
| bulk load | 36, 101 |

C

| | |
|----------------------|---------|
| C1/C2/C3 Knob | 119 |
| C1/C2/C3 Knobs | 90 |
| CD-ROM | 83, 121 |
| CHASE | 27, 31 |
| Chase Level | 31 |
| Chase Mode | 31 |
| Chase Switch | 99 |
| Chase Time | 31 |
| CHORUS | 61 |
| Chorus | 61 |
| Chorus Balance | 63 |
| Chorus Depth | 62 |
| Chorus Edit | 62 |
| Chorus Rate | 62 |
| Chorus Type | 62 |
| Coars | 66 |
| Common | 46, 109 |
| Compare | 55 |
| CONTROL | 28 |

| | |
|------------------------|---------|
| Control | 80, 117 |
| Control change | 97 |
| Control Pedal 1 | 80 |
| Control Pedal 2 | 80 |
| Control Setup | 21 |
| COSM1 | 13 |
| COSM2 | 13 |
| CTRL 1 PEDAL | 14 |
| CTRL 2 PEDAL | 14 |
| CURSOR Buttons | 91 |
| Cursor Buttons | 51 |
| cursor buttons | 51 |
| Cutoff Frequency | 68 |

D

| | |
|-------------------------------|-------------|
| D BEAM | 10 |
| D Beam controller | 20 |
| Delay | 61 |
| Delay Time | 61 |
| Depth | 62, 70 |
| Destination Bank | 39, 43, 116 |
| DIGITAL AUDIO INTERFACE | 14 |
| Digital Freq | 79 |
| Digital Frequency | 79 |
| DIGITAL OUT Connectors | 92 |
| DIRECT OUT | 14 |
| Display | 12, 90 |
| DKF | 70 |
| DUAL | 27 |
| Dual | 100 |
| Dual Solo | 27, 100 |
| DUAL-S | 27 |
| Dual-S | 100 |

E

| | |
|------------------------|-------------|
| editing | 50 |
| EFFECTS | 13 |
| End Level | 59, 72, 75 |
| EndL | 59, 72, 75 |
| ENV | 49, 67, 112 |
| ENV Depth | 70 |
| Envelope | 58, 74 |
| EQ | 61 |
| EQ Edit | 61 |
| Equalizer | 61 |
| Exclusive | 81 |
| Exclusive Sw | 118 |
| Exclusive Switch | 81, 118 |
| EXIT Button | 91 |

F

| | |
|---------------|---------|
| Factor | 47, 110 |
| Factors | 19, 98 |

| | |
|-------------------------------------|---------|
| Factory Reset | 35, 115 |
| Fine | 66 |
| Fine Tuning of the Lower Tone | 32 |
| Fine Tuning of the Upper Tone | 32 |
| Freq | 68 |

G

| | |
|---------------------------|-----|
| G.CH | 80 |
| Global CH | 118 |
| Global Channel mode | 80 |
| Grounding Terminal | 92 |
| growl | 76 |

H

| | |
|----------------------|--------|
| HiFreq | 62 |
| HiGain | 62 |
| High Frequency | 62 |
| High Gain | 62 |
| High Q | 62 |
| HiQ | 62 |
| Hold | 28, 80 |
| Hold Mode | 28 |
| HOLD PEDAL | 14 |
| Hold Pedal | 80 |

I

| | |
|-------------------|---------|
| Indicators | 90 |
| INFO | 18 |
| Initialize | 56, 115 |
| INPUT | 10, 14 |
| INPUT Jacks | 92 |

K

| | |
|-----------------------------------|------------|
| KBD Sens | 79 |
| KEY MODE | 26 |
| Key Mode | 99 |
| Key Shift of the Lower Tone | 32 |
| Key Shift of the Upper Tone | 32 |
| KEYBOARD | 11 |
| Keyboard Sensitivity | 79 |
| Keyfollow (Cutoff Point) | 69 |
| Keyfollow (Depth) | 70 |
| Keyfollow (pitch) | 66 |
| Keyfollow (Time) | 58, 70, 74 |
| KF | 66, 69 |
| Knob Switch | 119 |

L

| | |
|--------------------|------------|
| L0 | 59 |
| L1 | 59, 72, 75 |
| L2 | 59, 72, 75 |
| L3 | 72, 75 |
| LCD CONTRAST | 14 |
| Level | 31, 73 |
| Level 0 | 59 |
| Level 1 | 59, 72, 75 |
| Level 2 | 59, 72, 75 |

| | |
|--------------------------------|----------------------------|
| Level 3 | 72, 75 |
| Lever | 60 |
| LFO | 49, 60, 65, 67, 76-77, 112 |
| LFO Depth | 60, 65, 76-77 |
| LFO Mode | 67 |
| LFO Rate | 60 |
| LFO Select | 65, 76-77 |
| LFO Waveform | 60 |
| LFOD | 60, 65, 76-77 |
| LKey | 32 |
| Local | 81 |
| Local Switch | 81 |
| Low Frequency | 61 |
| Low Frequency Oscillator | 60 |
| Low Gain | 61 |
| LOWER | 26 |
| LowFreq | 61 |
| LowGain | 61 |
| LTune | 32 |

M

| | |
|-----------------------------|-------------|
| MAIN OUT | 14 |
| Master Tune | 79, 119 |
| MdeOFF | 80 |
| MENU Button | 91 |
| MIDI | 32, 80, 117 |
| MIDI CH | 80, 97, 117 |
| MIDI Channel | 80, 117 |
| MIDI Connectors | 14, 92 |
| MIDI Mode | 96, 119 |
| MOD | 76 |
| Mode | 28-29, 31 |
| Mode Message OFF | 118 |
| Mode Message OFF mode | 80 |
| Modulation | 76 |
| Modulation Lever | 13 |
| Mono Mode | 100 |

N

| | |
|---------------|---------|
| Naming | 33, 113 |
| No. | 43 |
| Note-on | 97 |
| Number | 16, 95 |

O

| | |
|--------------------|----|
| Octave | 79 |
| Octave Shift | 79 |
| OSC1 | 13 |
| OSC2 | 13 |
| OUTPUT | 29 |
| OUTPUT Jacks | 92 |
| Output Mode | 29 |

P

| | |
|----------------------|---------|
| parameter | 50 |
| Parameter Copy | 54 |
| Partial | 45, 108 |

Index

| | |
|-----------------------------------|----------------|
| Partial Balance | 57 |
| Partial Mute | 52, 100 |
| Partial Parameters | 63 |
| Partial Select | 52 |
| Partials | 45–46, 108–109 |
| Patch | 47, 110 |
| Patch Bank | 16, 95 |
| Patch number | 17 |
| PATCH PALETTE | 12 |
| Patch Palette | 17 |
| PATCH WRITE | 34, 114 |
| patches | 16, 95 |
| PC CARD | 14 |
| PC CARD Slot | 90 |
| PCM | 64 |
| PCM sound generator | 46, 109 |
| PCM Wave Number | 48, 64, 111 |
| Pedal Polarity | 80 |
| Pedal1 | 80 |
| Pedal2 | 80 |
| P-ENV | 58 |
| P-ENV Edit | 58 |
| P-ENV Level Edit | 59 |
| P-ENV Mode | 67 |
| P-ENV Time Edit | 58 |
| PHONES | 14 |
| PHONES Jack | 91 |
| Pitch | 48, 111 |
| Pitch Aftertouch Modulation | 60 |
| Pitch Bend | 13 |
| Pitch Bender | 28 |
| Pitch Coarse | 66 |
| Pitch Envelope | 58 |
| Pitch Fine | 66 |
| Pitch Lever Modulation | 60 |
| Pitch Mod | 60 |
| Pitch Modulation | 60 |
| Poly Mode | 100 |
| Portament Switch | 99 |
| PORTAMENTO | 27 |
| Portamento Mode | 28 |
| Portamento Time | 28 |
| POWER Switch | 14, 91 |
| Prog.C | 81 |
| Program Change Switch | 81 |
| ProgramChange Sw | 118 |
| Pulse Width | 48, 64, 111 |
| PW | 64 |

R

| | |
|--|--------|
| Rate | 60, 62 |
| Receive Channel in Separate Mode | 32 |
| Reso | 69 |
| Resonance | 69 |
| Reverb | 30 |
| reverb | 29 |
| Reverb Balance | 30 |
| Reverb Type | 30 |
| reverb types | 42 |
| RevType | 30 |

| | |
|----------------------|---------|
| Ring Modulator | 47, 110 |
|----------------------|---------|

S

| | |
|-----------------------------------|----------------|
| Select Bank | 105–106 |
| SEP | 27 |
| Separate | 27, 100 |
| Separate CH | 118 |
| Separate Solo | 27, 100 |
| SeparateCH | 81 |
| Separate-S | 100 |
| SepCH | 32 |
| SEP-S | 27 |
| Sound Character | 79, 119 |
| Sound Setting | 79 |
| Source Bank | 39–41, 43, 116 |
| SPLIT | 27 |
| Split | 100 |
| Split Lower Solo | 27, 100 |
| Split Point | 27, 100 |
| Split Upper Solo | 27, 100 |
| Split-LS | 100 |
| Split-US | 100 |
| SPL-LS | 27 |
| SPL-US | 27 |
| Struct | 57 |
| STRUCTURE | 13 |
| Structure | 46, 57, 109 |
| Structure Number | 57 |
| SusL | 59, 72, 75 |
| Sustain Level | 59, 72, 75 |
| Sync | 61 |
| synthesizer sound generator | 46, 109 |
| System | 78, 117, 119 |
| System Initialize | 82, 120 |
| System Save | 120 |

T

| | |
|------------------------------|------------|
| T1 | 59, 71, 74 |
| T2 | 59, 71, 74 |
| T3 | 59, 71, 74 |
| T4 | 59, 71, 75 |
| T5 | 71, 75 |
| Temporary Area | 44, 107 |
| Time | 28, 31 |
| Time 1 | 59, 71, 74 |
| Time 2 | 59, 71, 74 |
| Time 3 | 59, 71, 74 |
| Time 4 | 59, 71 |
| Time 5 | 71, 75 |
| TIME TRIP PAD | 11 |
| Time Trip pad | 19 |
| Time Variant Amplifier | 73 |
| Time Variant Filter | 68 |
| TKF | 58, 70, 74 |
| Tone | 46, 109 |
| Tone Balance | 27 |
| Tone Copy | 53 |
| Tone Select | 26 |
| TONE TUNE | 32 |

| | |
|--------------------------------------|-----------------|
| Total Volume | 30 |
| Transmit Bank Select Switch | 32 |
| Transmit Channel | 32 |
| Transmit Program Change Number | 32 |
| Transpose | 79 |
| tremolo | 77 |
| TVA | 13, 49, 73, 112 |
| TVA ENV | 74 |
| TVA ENV Level | 75 |
| TVA ENV Time | 74 |
| TVF | 49, 68, 112 |
| TVF ENV | 70 |
| TVF ENV Level | 72 |
| TVF ENV Time | 71 |
| TVF Envelope | 70 |
| TVF MOD | 76 |
| TxBs | 32 |
| TxCH | 32 |
| TxPC | 32 |
| Type | 62 |

U

| | |
|-----------------------|---------|
| UKey | 32 |
| UNDO | 51 |
| Undo | 51 |
| UPPER | 26 |
| USB | 83, 121 |
| USB Connector | 14, 92 |
| USB MIDI | 81 |
| USB MISI Switch | 81 |
| UTune | 32 |

V

| | |
|--------------------------------|-------------------|
| VALUE Dial | 91 |
| VALUE dial | 51 |
| Velo | 58, 65, 70, 73–74 |
| Velocity Follow (Time 1) | 74 |
| Velocity Range | 58, 65, 70, 73 |
| V-LINK | 11 |
| Vol | 30 |
| VOLUME Knob | 91 |
| VOLUME slider | 10 |

W

| | |
|---------------------|-------------|
| Wave | 60, 64 |
| Waveform | 48, 64, 111 |
| WG | 48, 111 |
| WG Form | 64 |
| WG Mod | 67 |
| WG Modulation | 67 |
| WG PITCH | 66 |
| WG Waveform | 64 |
| WHOLE | 27 |
| Whole | 100 |
| Whole Solo | 27, 100 |
| Whole-S | 100 |
| WHOL-S | 27 |
| Work Area | 44, 107 |

Information

When you need repair service, call your nearest Roland Service Center or authorized Roland distributor in your country as shown below.

AFRICA

EGYPT

Al Fanny Trading Office
9, EBN Hagar A1 Askalani Street,
ARD El Golf, Heliopolis,
Cairo 11341, EGYPT
TEL: 20-2-417-1828

REUNION

Maison FO - YAM Marcel
25 Rue Jules Hermann,
Chaudron - BP79 97 491
Ste Clotilde Cedex,
REUNION ISLAND
TEL: (0262) 218-4229

SOUTH AFRICA

That Other Music Shop (PTY) Ltd.
11 Melle St., Braamfontein,
Johannesburg, SOUTH AFRICA
P.O.Box 32918, Braamfontein 2017
Johannesburg, SOUTH AFRICA
TEL: (011) 403 4105

Paul Bothner (PTY) Ltd.
17 Werdmuller Centre,
Main Road, Claremont 7708
SOUTH AFRICA
P.O.Box 23032, Claremont 7735,
SOUTH AFRICA
TEL: (021) 674 4030

ASIA

CHINA

Roland Shanghai Electronics Co., Ltd.
5F, No.1500 Pingliang Road
Shanghai 200090, CHINA
TEL: (021) 5580-0800

Roland Shanghai Electronics Co., Ltd. (BEIJING OFFICE)
10F, No.18 Anhuaxili
Chaoyang District, Beijing 100011
CHINA
TEL: (010) 6426-5050

Roland Shanghai Electronics Co., Ltd. (GUANGZHOU OFFICE)
2/F, No.30 Si You Nan Er Jie Yi
Xiang, Wu Yang Xian Cheng,
Guangzhou 510600, CHINA
Tel: (020) 8736-0428

HONG KONG

Tom Lee Music Co., Ltd. Service Division
22-32 Pan Shan Street, Tsuen
Wan, New Territories,
HONG KONG
TEL: 2415 0911

Parsons Music Ltd.
8th Floor, Railway Plaza, 39
Chatham Road South, T.S.T.,
Kowloon, HONG KONG
TEL: 2333 1863

INDIA

Rivera Digitech (India) Pvt. Ltd.
409, Nirman Kendra Mahalaxmi
Flats Compound Off. Dr. Edwin
Moses Road, Mumbai-400011,
INDIA
TEL: (022) 2493 9051

INDONESIA

PT Citra IntiRama
Jl. Cideng Timur No. 15J-150
Jakarta Pusat
INDONESIA
TEL: (021) 6324170

KOREA

Cosmos Corporation
1461-9, Seocho-Dong,
Seocho Ku, Seoul, KOREA
TEL: (02) 3486-8855

MALAYSIA

BENTLEY MUSIC SDN BHD
140 & 142, Jalan Bukit Bintang,
55100 Kuala Lumpur, MALAYSIA
TEL: (03) 2144-3333

PHILIPPINES

G.A. Yupangco & Co. Inc.
339 Gil J. Puyat Avenue
Makati, Metro Manila 1200,
PHILIPPINES
TEL: (02) 899 9801

SINGAPORE

Swee Lee Company
150 Sims Drive,
SINGAPORE 387381
TEL: 6846-3676

CRISTOFORI MUSIC PTE LTD

Bik 3014, Bedok Industrial Park E,
#02-2148, SINGAPORE 489980
TEL: 6243-9555

TAIWAN

ROLAND TAIWAN ENTERPRISE CO., LTD.
Room 5, 9fl. No. 112 Chung Shan
N.Road Sec.2, Taipei, TAIWAN,
R.O.C.
TEL: (02) 2561 3339

THAILAND

Theera Music Co., Ltd.
330 Veerang NakornKasem, Soi 2,
Bangkok 10100, THAILAND
TEL: (02) 2248821

VIETNAM

Saigon Music
Suite DP-8
40 Ba Huyen Thanh Quan Street
Hochiminh City, VIETNAM
Tel: (08) 930-1969

AUSTRALIA/NEW ZEALAND

AUSTRALIA

Roland Corporation Australia Pty., Ltd.
38 Campbell Avenue
Dee Why West, NSW 2099
AUSTRALIA
TEL: (02) 9982 8266

NEW ZEALAND

Roland Corporation Ltd.
32 Shaddock Street, Mount Eden,
Auckland, NEW ZEALAND
TEL: (09) 3098 715

CENTRAL/LATIN AMERICA

ARGENTINA

Instrumentos Musicales S.A.
Av. Santa Fe 2055
(1123) Buenos Aires
ARGENTINA
TEL: (011) 4508-2700

BRAZIL

Roland Brasil Ltda
Rua San Jose, 780 Sala B
Parque Industrial San Jose
Cotia - Sao Paulo - SP, BRAZIL
TEL: (011) 4615 5666

COSTA RICA

JUAN Bansbach Instrumentos Musicales
Ave.1, Calle 11, Apartado 10237,
San Jose, COSTA RICA
TEL: 258-0211

CHILE

Commercial Fancy II S.A.
Rut.: 96.919.420-1
Nataliel Cox #739, 4th Floor
Santiago - Centro, CHILE
TEL: (02) 688-9540

EL SALVADOR

OMNI MUSIC
75 Avenida Norte y Final
Alameda Juan Pablo II,
Edificio No.4010 San Salvador,
EL SALVADOR
TEL: 262-0788

MEXICO

Casa Veerkamp, s.a. de c.v.
Av. Toluca No. 323, Col. Olivar
de los Padres 01780 Mexico D.F.
MEXICO
TEL: (55) 5668-6699

PANAMA

SUPRO MUNDIAL, S.A.
Boulevard Andrews, Albrook,
Panama City, REP. DE PANAMA
TEL: 315-0101

PARAGUAY

Distribuidora De Instrumentos Musicales
J.E. Oleary y ESQ. Manduvira
Asuncion PARAGUAY
TEL: (021) 492-124

URUGUAY

Todo Musica S.A.
Francisco Asca de Figueroa 1771
C.P.: 11.800
Montevideo, URUGUAY
TEL: (02) 924-2335

VENEZUELA

Musiland Digital C.A.
Av. Francisco de Miranda,
Centro Parque de Cristal, Nivel
C2 Local 20 Caracas
VENEZUELA
TEL: (212) 285-8586

EUROPE

AUSTRIA

Roland Austria GES.M.B.H.
Siemensstrasse 4, P.O. Box 74,
A-6063 RUM, AUSTRIA
TEL: (0512) 26 44 260

BELGIUM/HOLLAND/LUXEMBOURG

Roland Benelux N. V.
Houtstraat 3, B-2260, Oevel
(Westerlo) BELGIUM
TEL: (014) 57581

CZECH REP.

K-AUDIO
Kardasovska 626,
CZ-198 00 Praha 9,
CZECH REP.
TEL: (2) 666 10529

DENMARK

Roland Scandinavia A/S
Nordhavnsvej 7, Postbox 880,
DK-2100 Copenhagen
DENMARK
TEL: 3916 6200

FRANCE

Roland France SA
4, Rue Paul Henri SPAAK,
Parc de l'Esplanade, F 77 462 St.
Thibault, Lagny Cedex FRANCE
TEL: 01 600 73 500

FINLAND

Roland Scandinavia As, Filial Finland
Elannontie 5
FIN-01510 Vantaa, FINLAND
TEL: (09) 68 24 020

GERMANY

Roland Elektronische Musikinstrumente HmbH.
Oststrasse 96, 22844 Norderstedt,
GERMANY
TEL: (040) 52 60090

GREECE

STOLLAS S.A.
Music Sound Light
155, New National Road
Patras 26442, GREECE
TEL: 2610 435400

HUNGARY

Roland East Europe Ltd.
Warehouse Area "DEPO" Pf.83
H-2046 Torokbalint, HUNGARY
TEL: (23) 511011

IRELAND

Roland Ireland
G2 Calmout Park, Calmout
Avenue, Dublin 12
Republic of IRELAND
TEL: (01) 4294444

ITALY

Rolanti Italy S. p. a.
Viale delle Industrie 8,
20020 Arese, Milano, ITALY
TEL: (02) 937-78300

NORWAY

Roland Scandinavia Avd. Kontor Norge
Lilleakerveien 2 Postboks 95
Lilleaker N-0216 Oslo
NORWAY
TEL: 2273 0074

POLAND

MX MUSIC SP.Z.O.O.
Ul. Gbraltarska 4,
PL-03664 Warszawa POLAND
TEL: (022) 679 44 19

PORTUGAL

Tecnologias Musica e Audio, Roland Portugal, S.A.
Cais Das Pedras, 8/9-1 Dto
4050-465 PORTO
PORTUGAL
TEL: (022) 608 00 60

ROMANIA

FBS LINES
Piata Libertatii 1,
535500 Gheorgheni, ROMANIA
TEL: (266) 364 609

RUSSIA

MuTeK
3-Bogatyrskaya Str. 1.k.1
107 564 Moscow, RUSSIA
TEL: (095) 169 5043

SPAIN

Roland Electronics de España, S. A.
Calle Bolivia 239, 08020
Barcelona, SPAIN
TEL: (93) 308 1000

SWEDEN

Roland Scandinavia A/S SWEDISH SALES OFFICE
Danvik Center 28, 2 tr.
S-131 30 Nacka SWEDEN
TEL: (08) 702 00 20

SWITZERLAND

Roland (Switzerland) AG
Landstrasse 5, Postfach,
CH-4452 Ittingen,
SWITZERLAND
TEL: (061) 927-8383

UKRAINE

TIC-TAC
Mira Str. 19/108
P.O. Box 180
295400 Munkachevo, UKRAINE
TEL: (03131) 414-40

UNITED KINGDOM

Roland (U.K.) Ltd.
Atlantic Close, Swansea
Enterprise Park, SWANSEA
SA7 9EF,
UNITED KINGDOM
TEL: (01792) 702701

MIDDLE EAST

BAHRAIN

Moon Stores
No.16, Bab Al Bahrain Avenue,
P.O.Box 247, Manama 304,
State of BAHRAIN
TEL: 211 005

CYPRUS

Radex Sound Equipment Ltd.
17, Diagorou Street, Nicosia,
CYPRUS
TEL: (022) 66-9426

IRAN

MOCO, INC.
No.41 Nike St., Dr.Shariyati Ave.,
Roberoye Cerahe Mirdamad
Tehran, IRAN
TEL: (021) 285-4169

ISRAEL

HaIlit P. Greenspoon & Sons Ltd.
8 Retzi Ha aliya Hashnya St.
Tel-Aviv-Yafo ISRAEL
TEL: (03) 6823666

JORDAN

AMMAN Trading Agency
245 Prince Mohammad St.,
Amman 1118, JORDAN
TEL: (06) 464-1200

KUWAIT

Easa Husain Al Yousifi Est.
Abdullah Salem Street,
Safat, KUWAIT
TEL: 243-6399

LEBANON

Chahine S.A.L.
Gerge Zeidan St., Chahine Bldg.,
Achrafieh, P.O.Box: 16-5857
Beirut, LEBANON
TEL: (01) 20-1441

QATAR

Al Emadi Co. (Badie Studio & Stores)
P.O. Box 62, Doha, QATAR
TEL: 4423-554

SAUDI ARABIA

aDawlah Universal Electronics APL
Corniche Road, Aldossary Bldg.,
1st Floor, Alkhobar,
SAUDI ARABIA

P.O.Box 2154, Alkhobar 31952

SAUDI ARABIA

TEL: (03) 898 2081

SYRIA

Technical Light & Sound Center
Rawda, Abdul Qader Jazairi St.
Bldg. No. 21, P.O.Box 13520,
Damascus, SYRIA
TEL: (011) 223-5384

TURKEY

Ant Muzik Aletleri Ithalat Ve Ithracat Ltd Sti
Siraselvilir Caddesi Siraselvilir
Pasaji No:74/20
Taksim - Istanbul, TURKEY
TEL: (0212) 2449624

U.A.E.

Zak Electronics & Musical Instruments Co. L.L.C.
Zabeel Road, Al Shercoq Bldg.,
No. 14, Grand Floor, Dubai, U.A.E.
TEL: (04) 3360715

NORTH AMERICA

CANADA

Roland Canada Music Ltd. (Head Office)
5480 Parkwood Way Richmond
B.C., V6V 2M4 CANADA
TEL: (604) 270 6626

Roland Canada Music Ltd.

(Toronto Office)

170 Admiral Boulevard
Mississauga On L5T 2N6
CANADA
TEL: (905) 362 9707

U. S. A.

Roland Corporation U.S.
5100 S. Eastern Avenue
Los Angeles, CA 90040-2938,
U. S. A.
TEL: (323) 890 3700

As of April 1, 2004 (Roland)